Warner Home Video B0774D6HBB

Warner Home Video Dark Knight Trilogy Collection (UHD/BD) (4K Ultra HD) Instruction Manual

Model: B0774D6HBB

1. Introduction

Welcome to the Dark Knight Trilogy Collection. This manual provides essential information for the optimal enjoyment and care of your 4K Ultra HD and Blu-ray disc set. Please read these instructions carefully to ensure proper setup and operation.

2. Product Overview

This collection features the complete Dark Knight Trilogy by director Christopher Nolan, starring Christian Bale as Batman. The set includes:

- Batman Begins
- The Dark Knight
- The Dark Knight Rises

The collection is presented in 4K Ultra HD and Blu-ray formats, offering enhanced visual and audio quality for an immersive viewing experience.



Image Description: The cover art for the Dark Knight Trilogy Collection, featuring the iconic Batman symbol against a dark, textured background. The top banner indicates "4K Ultra HD + Blu-ray" and highlights "HDR High Dynamic Range" for brighter, deeper, more lifelike colors. The titles "Batman Begins," "The Dark Knight," and "The Dark Knight Rises" are listed at the bottom.

3. Setup

Follow these steps to set up your Dark Knight Trilogy Collection for playback:

1. **Player Compatibility:** Ensure you have a 4K Ultra HD Blu-ray player and a compatible 4K Ultra HD television or display for optimal 4K viewing. For Blu-ray discs, a standard Blu-ray player and HD television are required.

2. **HDMI Connection:** Connect your player to your display using an HDMI cable. For 4K Ultra HD content, ensure your HDMI cable and ports support HDMI 2.0a/HDCP 2.2 or higher to enable HDR (High Dynamic Range) functionality.
3. **Audio System:** For the best audio experience, connect your player to an audio receiver or sound system. Refer to your audio system's manual for connection details.
4. **Disc Insertion:** Gently insert the desired disc into the disc tray of your player, ensuring the label side is facing up.

4. Operating Instructions

Once the disc is loaded, the player will typically display a main menu. Use your player's remote control to navigate the options:

- **Play Movie:** Select this option to begin playback of the main feature.
- **Scene Selection:** Use this feature to jump to specific chapters or scenes within the film.
- **Audio Options:** Access this menu to choose preferred language tracks or advanced audio formats (e.g., Dolby Atmos, DTS-HD Master Audio, if available on the disc and supported by your system).
- **Subtitles:** Enable or disable subtitles and select your preferred language from this menu.
- **Special Features:** Explore bonus content such as behind-the-scenes documentaries, interviews, deleted scenes, or trailers.

5. Disc Care and Maintenance

Proper care will prolong the life of your discs and ensure optimal playback quality:

- **Handling:** Always handle discs by their edges or the center hole to avoid fingerprints, smudges, and scratches on the playing surface.
- **Storage:** Store discs in their original cases when not in use. Keep them away from direct sunlight, extreme temperatures, and high humidity.
- **Cleaning:** If a disc becomes dirty, gently wipe it with a soft, lint-free cloth. Wipe from the center outwards in a straight line, not in a circular motion. Do not use abrasive materials, solvents, or harsh cleaning chemicals.
- **Protection:** Avoid bending or flexing the discs, as this can cause irreparable damage.

6. Troubleshooting Common Issues

If you encounter problems, consider the following solutions:

- **Disc Not Playing:** Ensure the disc is clean and free of visible scratches. Verify it is inserted correctly into the player. Confirm your player is compatible with 4K Ultra HD or Blu-ray discs.
- **No Picture/Sound:** Check that all HDMI and audio cables are securely connected to both the player and your display/receiver. Confirm your TV/receiver input selection matches the player's connection. Ensure your display and player support the disc's resolution and audio format.
- **Poor Picture Quality:** For 4K UHD content, ensure your player, TV, and HDMI cables all support 4K resolution and HDR. Check your TV's picture settings for optimal display.
- **Skipping/Freezing:** Clean the disc carefully as described in the Maintenance section. If the issue persists, the disc may be damaged, or your player's laser lens may require cleaning or servicing.

7. Product Specifications

Key technical details for the Dark Knight Trilogy Collection:

- **Brand:** Warner Home Video
- **Model Number:** B0774D6HBB
- **Media Format:** 4K Ultra HD, Blu-ray
- **Number of Discs:** 9
- **Run Time:** Approximately 7 hours and 37 minutes (total for main features)
- **Language:** English
- **MPAA Rating:** NR (Not Rated)
- **Release Date:** December 19, 2017
- **Product Dimensions:** 0.7 x 7.5 x 5.4 inches; 10.72 ounces

8. Warranty and Customer Support

For specific warranty information regarding your Dark Knight Trilogy Collection, please refer to any documentation included with your purchase or contact the retailer from whom you purchased the product. For technical support related to disc playback or compatibility issues with your equipment, please consult your 4K Ultra HD Blu-ray player's instruction manual or contact the player manufacturer directly.

This product is manufactured by Warner Home Video.