Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Jakks Games 61734

Jakks Games TP Blaster 61734 Skid Shot Instruction Manual

Model: 61734

Introduction

The Jakks Games TP Blaster 61734 Skid Shot is designed to transform ordinary toilet paper into clean, biodegradable spitballs for recreational play. This manual provides essential information for the safe and proper use, setup, operation, and maintenance of your TP Blaster.



Image: A young boy demonstrates holding the TP Blaster Skid Shot, which uses toilet paper and water to create projectiles.

Safety Information

Adult supervision is suggested during use. Please review all instructions carefully before operating the blaster.

- Do not aim at eyes or face.
- Use only clean, regular toilet paper. 2-ply toilet paper is recommended for optimal performance.
- The blaster uses water to create spitballs. Some water leakage during play is normal.
- Keep fingers and loose clothing away from moving parts.
- This product is intended for ages 8 and up.

What's in the Box

Your Jakks Games TP Blaster 61734 Skid Shot package includes:

- 1 x TP Blaster Skid Shot

The packaging also includes three cutout targets for practice.

Setup

Follow these steps to prepare your TP Blaster for use:

1. **Fill the Water Tank:** Locate the water tank on top of the blaster. Open the cap and fill the tank with clean tap water. Securely close the cap.
2. **Load Toilet Paper:** Place a roll of standard toilet paper onto the designated spindle at the front of the blaster. Feed the end of the toilet paper into the loading mechanism as shown in the diagrams. Ensure the paper is properly aligned for smooth feeding.



Image: Packaging illustration detailing the steps for filling the water tank, loading toilet paper, and firing the blaster.



Image: A detailed view of how toilet paper is loaded into the blaster's feeding mechanism.

Operating Instructions

Once the water tank is filled and toilet paper is loaded, you are ready to operate your blaster:

1. **Prepare to Fire:** Hold the blaster firmly. The loading mechanism will automatically prepare a section of toilet paper.
2. **Aim:** Point the blaster towards your target. Remember to avoid aiming at people's faces or eyes.
3. **Blast:** Pull the trigger to fire a spitball. The blaster uses water to form the toilet paper into a projectile and launch it up to 30 feet.

One roll of toilet paper can produce over 350 spitballs (approximately 2 spitballs per sheet).



Image: A hand gripping the blaster, illustrating the firing position and the visible 'Skid Shot' model name.

Your browser does not support the video tag.

Video: An official product video demonstrating the features and operation of the Toilet Paper Blaster Skid Shot, including loading and firing.

Maintenance

The TP Blaster Skid Shot is designed for easy cleanup. The spitballs are bio-degradable and do not stain surfaces.

- After each use, empty any remaining water from the tank.
- Wipe down the exterior of the blaster with a damp cloth if needed.
- Ensure no toilet paper residue is left in the loading mechanism to prevent blockages.
- Store the blaster in a clean, dry place away from direct sunlight.

Troubleshooting

If you encounter any issues with your TP Blaster, refer to the following common points:

- **Blaster not firing or weak shots:** Ensure the water tank is full and the toilet paper is correctly loaded and feeding smoothly. Check if the toilet paper is too thick; 2-ply is recommended.
- **Water leakage:** A small amount of water leakage is normal during operation as the blaster uses water to form the spitballs. If excessive leakage occurs, ensure the water tank cap is securely closed.
- **Toilet paper jamming:** Ensure the toilet paper is fed straight into the mechanism and is not crumpled. Use fresh, dry toilet paper.

Specifications

Feature	Detail
Model Number	61734
Brand	Jakks Games

Material	Plastic
Maximum Range	30 Feet (9.14 meters)
Power Source	Manual (No batteries required)
Recommended Age	8+ years (72 months to 108 months)
Item Dimensions (L x W x H)	18 x 4 x 10 inches
Item Weight	2.07 Pounds
Included Components	Blaster

Warranty and Support

This product comes with no manufacturer warranty. For any questions or support regarding your Jakks Games TP Blaster 61734 Skid Shot, please refer to the contact information provided on the product packaging or visit the official Jakks Games website.

© 2026 Jakks Games. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0776KJK3J

More documents and user manuals: **https://manuals.plus/**