ZdalaMit NS-RCRUS-17

ZdalaMit NS-RCRUS-17 Replacement Remote Control User Manual

For Insignia Roku TV Models

1. Product Overview

This manual provides instructions for the ZdalaMit NS-RCRUS-17 replacement remote control, designed for use with various Insignia Roku TV models. This remote offers direct functionality without the need for programming or pairing.





Image 1.1: Front view of the ZdalaMit NS-RCRUS-17 Replacement Remote Control, showing all buttons including power, navigation, playback, and dedicated app buttons.

2. Setup

2.1 Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery cover downwards or outwards to open.
3. Insert two (2) 1.5V AAA alkaline batteries, ensuring correct polarity (+ and -) as indicated inside the compartment.
4. Replace the battery cover by sliding it back into position until it clicks securely.

Note: Batteries are not included with the remote control. Only use new alkaline batteries for optimal performance.

2.2 Initial Use

This replacement remote control is pre-programmed and does not require any additional programming or pairing for compatible Insignia Roku TVs. Once batteries are installed, the remote is ready for immediate use.

Important Compatibility Information: This remote is specifically designed for Insignia Roku TVs. It is**not compatible** with Roku players, Roku boxes, or Roku sticks.

Compatible Insignia Roku TV models include, but are not limited to:

- NS-24ER310NA17, NS-32DR310NA17, NS-48DR510NA17
- NS-43DR710NA17, NS-55DR710NA17, NS-50DR710NA17
- NS-43DR620NA18, NS-50DR620NA18, NS-55DR620NA18, NS-65DR620NA18
- NS-50DR620CA18, NS-55DR620CA18, NS-39DR510NA17

3. Operating Instructions

The remote control features standard buttons for navigating your Insignia Roku TV.



Image 3.1: A hand holding the remote control, demonstrating its use to control a television.

- **Power Button ( ):** Turns the TV on or off.
- **Navigation Pad (Up, Down, Left, Right, OK):** Used to navigate menus, select items, and confirm choices.
- **Back Button ( ):** Returns to the previous screen or menu.
- **Home Button (⌂):** Returns to the Roku TV home screen.
- **Volume Buttons (,):** Adjusts the TV volume up or down.
- **Mute Button ( ):** Mutes or unmutes the TV audio.
- **Playback Controls (Rewind, Play/Pause, Fast Forward):** Controls media playback.
- **Instant Replay (↺):** Jumps back a few seconds in video playback.
- **Sleep Timer (☾):** Accesses the sleep timer function.
- **Star Button (✱):** Provides quick access to options within certain apps or menus.

- **Dedicated App Buttons (Netflix, Sling, Hulu, Google Play):** Provides direct access to these streaming applications.

4. Maintenance

4.1 Battery Replacement

When the remote control's performance degrades or it stops responding, replace the batteries with two new 1.5V AAA alkaline batteries. Follow the battery installation steps in Section 2.1.

4.2 Cleaning

To clean the remote control, gently wipe its surface with a soft, dry cloth. Avoid using liquid cleaners, solvents, or abrasive materials, as these can damage the remote's finish or internal components.

5. Troubleshooting

- **Remote not responding:**
  - Ensure batteries are correctly installed and not depleted. Replace with new batteries if necessary.
  - Check for any obstructions between the remote and the TV's infrared sensor.
  - Perform a remote reset: Remove batteries, press all buttons on the remote several times to discharge any residual power, then reinsert batteries.
- **TV not responding or slow response:**
  - Power cycle the TV: Unplug the TV from the power outlet for at least 5 minutes, then plug it back in.
  - Ensure the remote is pointed directly at the TV.
- **Remote does not control Roku player/box/stick:**
  - This remote is designed exclusively for Insignia Roku TVs and is not compatible with standalone Roku streaming devices.

6. Specifications

Feature	Detail
Model Number	NS-RCRUS-17 (Internal: 8541739352)
Power Supply	2 x 1.5V AAA Alkaline Batteries (not included)
Product Dimensions	1.97 x 1.97 x 1.97 inches (approximate)
Item Weight	1.48 ounces
Compatible Devices	Insignia Roku Televisions
Special Feature	Pre-Programmed (No pairing required)



Image 6.1: Front and side view of the remote control with approximate dimensions (length 5.51 inches, width 1.65 inches, thickness 0.78 inches).

7. Warranty and Support

For any questions, concerns, or support regarding your ZdalaMit NS-RCRUS-17 replacement remote control, please contact the seller or manufacturer directly through your purchase platform. Please refer to your purchase documentation for specific warranty details, as these may vary.

© 2024 ZdalaMit. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question