Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

De'Longhi HFX30C15.G

De'Longhi Capsule Electric Space Heater HFX30C15 User Manual

Model: HFX30C15.G | Brand: De'Longhi

1. Product Overview

The De'Longhi Capsule Electric Space Heater, model HFX30C15, is a compact and portable ceramic heater designed to provide instant warmth to small to medium rooms. Its efficient design ensures quick heating and full room circulation, making it an ideal solution for personal comfort in offices, bedrooms, or living areas. This heater features an adjustable electronic thermostat, multiple heat settings, and a fan-only option for year-round use.



Figure 1: Front view of the De'Longhi Capsule Electric Space Heater.

2. Important Safety Information

Please read all safety warnings and instructions before using this appliance to reduce the risk of fire, electric shock, or injury. Keep this manual for future reference.

- **Two-Stage Overheat Protection:** The heater is equipped with thermal shutoff and a thermal fuse to prevent overheating. If the unit overheats, it will automatically shut off.
- **Tip-Over Switch:** An internal tip-over switch automatically turns the unit off if it is accidentally knocked over, enhancing safety.
- **Cool Touch Handle and Controls:** Designed for safe operation and relocation, the handle and controls remain cool to the touch during or after use.
- **Antifreeze Standby Setting:** When the ambient temperature drops below 41°F (5°C), the heater will automatically activate to help prevent pipes from freezing, particularly useful in basements or vacation homes.
- Always plug the heater directly into a wall outlet. Never use with an extension cord or relocatable power tap.
- Do not cover the heater or obstruct its air inlets/outlets.
- Keep combustible materials at least 3 feet (0.9 meters) away from the front, sides, and rear of the heater.



Figure 2: Visual representation of key safety features including overheat protection and tip-over switch.

3. Setup

1. **Unpacking:** Carefully remove the heater from its packaging. Retain packaging for future storage or transport.
2. **Placement:** Place the heater on a firm, level surface. Ensure it is positioned away from curtains, furniture, and other combustible materials. Maintain at least 3 feet (0.9 meters) clearance from all sides.
3. **Power Connection:** Plug the heater directly into a 120V AC, 60Hz electrical outlet. Do not use extension cords, power strips, or surge protectors.



Figure 3: Proper placement of the heater in a room, ensuring adequate clearance.

4. Operating Instructions

The De'Longhi Capsule Heater offers personalized comfort with its intuitive controls.

4.1. Control Panel Overview



Figure 4: Detailed view of the control dial and ergonomic handle.

4.2. Power Settings

- **OFF (O):** Turns the heater off.
- **Fan Only (fan icon):** Activates the fan without heat, providing a cool breeze for air circulation during warmer months.
- **Heat Setting 1 (I):** Provides energy-efficient heating. Ideal for maintaining warmth in smaller spaces.
- **Heat Setting 2 (II):** Delivers maximum heat output (1500 watts) for rapid warming of small to medium rooms.

4.3. Adjustable Thermostat

The adjustable electronic thermostat allows you to set your desired room temperature. The heater will automatically cycle on and off to maintain this temperature, optimizing energy consumption.

1. Turn the thermostat dial clockwise to increase the desired temperature.
2. Turn the thermostat dial counter-clockwise to decrease the desired temperature.

3. For continuous heating, set the thermostat to its maximum setting.
4. For energy saving, utilize the **Eco Plus** setting (if available on your model) which automatically adjusts power output to maintain comfort while minimizing energy use.



Figure 5: The heater's compact design and 1500-watt power for premium heating.

5. Maintenance

Regular maintenance ensures optimal performance and longevity of your De'Longhi heater.

- **Cleaning:** Before cleaning, always unplug the heater from the electrical outlet and allow it to cool down completely. Use a soft, damp cloth to wipe the exterior surfaces. Do not use abrasive cleaners or solvents.
- **Dust Removal:** Periodically use a vacuum cleaner with a brush attachment to remove dust from the air intake and outlet grilles.
- **Storage:** When not in use, especially during off-season, store the heater in its original packaging in a cool, dry place. Ensure the power cord is neatly wrapped and secured.

6. Troubleshooting

If your heater is not operating correctly, consult the following common issues and solutions:

Problem	Possible Cause	Solution
Heater does not turn on.	No power to the unit, tip-over switch activated, or overheat protection activated.	Ensure the heater is securely plugged into a working outlet. Check if the heater is on a stable, level surface. Allow the unit to cool down for 30 minutes if it was recently overheated, then restart.
Heater produces insufficient heat.	Thermostat set too low, or room size is too large for the heater's capacity.	Increase the thermostat setting. Ensure the heater is set to Heat Setting 2 (II) for maximum output. This heater is designed for small to medium spaces.
Heater makes unusual noise.	Normal fan operation, or dust accumulation.	A certain level of fan noise is normal for this type of heater. Clean the air intake and outlet grilles to remove any dust buildup.

7. Specifications

Feature	Detail
Brand	De'Longhi
Model Number	HFX30C15.G
Product Dimensions	7.5"D x 4"W x 11"H
Item Weight	2.9 pounds
Color	Dark Gray
Fuel Type	Electric
Voltage	120 Volts
Amperage	12.5 Amps
Max Temperature Setting	82 Degrees Fahrenheit
Special Features	Ceramic Heating Technology, Tip-Over Protection
Heating Coverage	Small spaces and individual comfort
UPC	044387130158

8. Warranty and Support

The De'Longhi Capsule Electric Space Heater HFX30C15.G comes with a**3-year warranty** from the date of purchase. For warranty claims, technical support, or any questions regarding your product, please contact De'Longhi customer service. Refer to the official De'Longhi website or your purchase documentation for the most current contact information. You can also visit the official De'Longhi Store for more information:De'Longhi Store

© 2024 De'Longhi. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0777TDNPQ

More documents and user manuals: **https://manuals.plus/**