MOOER GE200

MOOER GE200 Multi-FX Processor Instruction Manual

Model: GE200

Introduction

The MOOER GE200 is a versatile multi-effects processor designed for guitarists seeking high-quality amp modeling and a comprehensive array of effects. This unit is suitable for live performances, studio recording, and home practice, offering a compact and robust solution for tone shaping. It integrates advanced features such as a looper, drum machine, and USB connectivity for seamless integration with your setup.

Key Features

- **55 High-Quality Amplifier Models:** Recreate the sound of classic and modern amplifiers with precision.
- **Comprehensive Digital Effects:** A wide range of effects including modulation, delay, reverb, and more.
- **52-Second Looper:** Built-in looper with capabilities for half-speed and reverse effects, ideal for practice and creative performance.
- **Integrated Drum Machine:** Features 40 drum patterns and 10 metronome rhythms to assist with timing and practice.
- **USB Connectivity:** Allows for PC editing of presets and direct audio recording to a computer.
- **3.5-inch Color Display:** Provides a clear and intuitive interface for navigation and parameter adjustment.
- **Built-in Expression Pedal:** Offers real-time control over various effects parameters like wah or volume.
- **Robust Aluminum Chassis:** Durable construction designed for reliability and protection.

Setup Guide

Follow these steps to set up your MOOER GE200 for optimal performance.

1. Power Connection

Connect the included DC 9V 600mA power adapter to the "DC 9V" input on the rear panel of the GE200. Plug the adapter into a suitable power outlet. Ensure the power supply meets the specified voltage and current requirements to prevent damage.



Image: Rear panel of the MOOER GE200, highlighting the various input/output jacks including the DC 9V power input, AUX IN, EXP 2, L(MONO)/OUT-R, Headphone, and USB ports.

2. Audio Connections

- **Guitar Input:** Connect your guitar to the "IN" (L/MONO) jack using a standard 1/4-inch instrument cable.
- **Output to Amplifier/Mixer:** Connect the "OUT" (L/MONO) jack to your guitar amplifier's input or directly to a mixer/audio interface. For stereo output, use both L and R outputs.
- **Headphones:** For silent practice, connect headphones to the dedicated headphone jack.
- **AUX Input:** Use the "AUX IN" jack to connect an external audio source (e.g., MP3 player, phone) for playing along with backing tracks.

3. USB Connection (for PC Editing/Recording)

Connect the GE200 to your computer using a USB cable. This allows you to use the MOOER editing software for deeper parameter control and to use the GE200 as an audio interface for direct recording.

Operating Instructions

The GE200 features an intuitive interface with a color display, navigation knobs, and footswitches for easy operation.



Image: Top-down view of the MOOER GE200, displaying the central color screen, master volume knob, value knob, and the three footswitches labeled REVERSE, TUNER/HALF SPEED, and LOOPER/CTRL/TAP.

- **Color Display:** The central screen shows current preset, effect chain, and parameter values.
- **Value Knob:** Used for navigating menus and adjusting parameter values.
- **Master Volume Knob:** Controls the overall output volume of the unit.

- **Footswitches:** Three assignable footswitches for preset changes, looper control, tuner activation, and tap tempo.
- **Expression Pedal:** Controls parameters like volume, wah, or other assignable effects in real-time.

2. Preset Management

The GE200 stores numerous presets, each containing a complete signal chain of amp models and effects. Use the footswitches to cycle through presets or the value knob to select them directly from the display.

- **Selecting Presets:** In Play mode, use the left and right footswitches to navigate up and down through presets.
- **Editing Presets:** Press the "CHAIN" button to view and edit the effect chain. Use the navigation buttons and value knob to select and adjust individual effects and amp models.
- **Saving Presets:** After making changes, press the "SAVE" button. You can save to an existing slot or a new one.

3. Amp Modeling and Effects

The GE200 offers 55 amplifier models and a wide array of effects. Each effect block (FX/COMP, DS/OD, AMP, CAB, NS, EQ, MOD, DELAY, REVERB, RHYTHM) can be individually configured within a preset.

- **Amp Models:** Select from various amp types to achieve different tonal characteristics.
- **Cabinet Simulation:** Apply cabinet impulse responses (IRs) to simulate different speaker cabinets. The unit supports third-party IR loading.
- **Effect Parameters:** Adjust parameters for each effect block using the value knob once selected on the display.

4. Looper Functionality

The built-in looper allows for recording and overdubbing up to 52 seconds of audio.

- **Activate Looper:** Press the "LOOPER" footswitch (rightmost).
- **Record:** Press the "LOOPER" footswitch once to start recording.
- **Overdub:** Press the "LOOPER" footswitch again to start overdubbing.
- **Play/Stop:** Double-press the "LOOPER" footswitch to stop playback. Press once to resume.
- **Undo/Redo:** Press the "CTRL/TAP" footswitch to undo the last overdub. Press again to redo.
- **Clear:** Hold the "LOOPER" footswitch to clear the loop.
- **Half Speed/Reverse:** Use the "HALF SPEED" (middle) and "REVERSE" (left) footswitches to apply these effects to the loop.

5. Drum Machine

The drum machine provides rhythmic backing for practice.

- **Activate Drum Machine:** Press the "RHYTHM" button.
- **Select Pattern:** Use the value knob to choose from 40 drum patterns or 10 metronome rhythms.
- **Adjust Tempo/Volume:** Adjust the tempo (BPM) and volume of the drum machine using the corresponding parameters on the display.

6. USB Audio and Software

When connected to a computer via USB, the GE200 functions as an audio interface and can be controlled by MOOER's dedicated software.

- **Direct Recording:** Record your guitar directly into a Digital Audio Workstation (DAW) on your computer.
- **Editing Software:** Download and install the MOOER GE200 software from the official MOOER website for advanced preset editing, firmware updates, and IR management.

Maintenance

Proper maintenance ensures the longevity and optimal performance of your GE200.

- **Cleaning:** Use a soft, dry cloth to clean the unit. Avoid abrasive cleaners, solvents, or waxes.
- **Storage:** Store the unit in a cool, dry place away from direct sunlight, extreme temperatures, and high humidity.
- **Handling:** Handle the unit with care. Avoid dropping it or subjecting it to strong impacts.
- **Power Supply:** Always use the specified power adapter. Disconnect power when not in use for extended periods.

Troubleshooting

If you encounter issues with your GE200, refer to the following common problems and solutions.

Problem	Possible Cause	Solution
No Sound Output	Incorrect cable connections, low volume settings, faulty cables, incorrect preset selected.	Check all audio cables (guitar in, output to amp/mixer, headphones). Ensure Master Volume knob is turned up. Verify the selected preset has audible settings. Test with different cables.
Distorted/Unwanted Noise	High gain settings, noisy power supply, ground loop, faulty instrument/cable.	Reduce gain levels on amp models or overdrive effects. Ensure power supply is stable and correct. Utilize the built-in Noise Suppressor (NS) effect. Test with a different guitar or cable.
USB Connection Issues	Incorrect USB cable, driver not installed, software not recognizing device.	Ensure a proper USB data cable is used. Install the latest USB drivers and editing software from the MOOER website. Try a different USB port on your computer. Restart both the GE200 and your computer.
Footswitch Unresponsive	Firmware issue, physical damage.	Perform a factory reset (refer to advanced manual or MOOER support). Check for firmware updates. If physical damage is suspected, contact MOOER support.

Specifications

Specification	Value
Item Weight	3 Pounds (1.36 kg)

Specification	Value
Product Dimensions (L x W x H)	11.7" x 5.7" x 2.3" (29.7 x 14.5 x 5.8 cm)
Power Source	Corded Electric (DC 9V, 600mA)
Hardware Interface	USB
Signal Format	Analog
Number of Amp Models	55
Looper Recording Time	52 seconds
Drum Patterns	40 drum patterns, 10 metronome rhythms

Warranty and Support

For detailed warranty information, please refer to the documentation included with your purchase or visit the official MOOER website. MOOER provides customer support for product inquiries, technical assistance, and warranty claims.
Official MOOER Website: www.mooeraudio.com
It is recommended to register your product on the MOOER website to receive updates and support.

© 2024 MOOER. All rights reserved. Information subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question