Kichler 310152WZC

Kichler 52 Inch Weathered Zinc Ceiling Fan Instruction Manual

Model: 310152WZC | Brand: Kichler

1. Product Overview

The Kichler 52 Inch Weathered Zinc Ceiling Fan (Model 310152WZC) is designed for effective air circulation and cooling in outdoor environments. Featuring a weathered zinc finish and weathered medium oak blades, this fan combines sleek lines and curves, making it suitable for traditional or transitional decor. It operates with a pull chain for speed control and manual reverse function, providing versatile airflow options without integrated lighting.



Figure 1: Front view of the Kichler 52 Inch Weathered Zinc Ceiling Fan.

2. Safety Information

Read all instructions carefully before installation and use. Failure to follow these instructions may result in electric shock, fire, or personal injury.

- Ensure power is disconnected at the circuit breaker before installation or servicing.
- All wiring must be in accordance with national and local electrical codes. If you are unfamiliar with wiring, consult a qualified electrician.
- The fan must be mounted to a structurally sound ceiling joist or outlet box capable of supporting the fan's weight.
- Do not bend blade holders during installation or cleaning.
- Keep hands clear of rotating fan blades.
- This fan is rated for outdoor usage. Ensure all connections are properly sealed for outdoor conditions.

3. Package Contents

Verify that all components are present and undamaged before beginning installation.

- Ceiling Fan Motor Assembly
- Fan Blades (4)
- Blade Holders
- Downrod (4.5 inches, 1 inch O.D.)
- Canopy and Mounting Bracket
- Hardware Pack (screws, washers, wire nuts)
- Pull Chain for speed control
- 78 inch lead wire



Figure 2: Angled view of the Kichler 52 Inch Weathered Zinc Ceiling Fan.

4. Setup and Installation

This ceiling fan is designed for ceiling mount installation. It accommodates ceilings with up to a 30-degree or 7/12 pitch. The included 78-inch lead wire provides flexibility for taller ceilings.

1. **Prepare the Mounting Location:** Turn off power at the circuit breaker. Securely attach the mounting bracket to a ceiling joist or an outlet box rated for fan support.
2. **Assemble the Downrod:** Insert the downrod through the canopy and feed the lead wires through the downrod. Secure the downrod to the fan motor assembly.
3. **Hang the Fan:** Carefully lift the fan assembly and hang it from the mounting bracket using the provided hook or ball-and-socket system.
4. **Electrical Connections:** Connect the fan's electrical wires to the household supply wires according to local electrical codes. Use the provided wire nuts and ensure all connections are secure. The 78-inch lead wire allows for flexible connection points.
5. **Secure the Canopy:** Slide the canopy up to the ceiling and secure it to the mounting bracket with the screws.
6. **Attach Fan Blades:** Attach the fan blades to the blade holders, then secure the blade holders to the motor housing. Ensure

all screws are tightened.

7. **Restore Power:** Once installation is complete, restore power at the circuit breaker.



Figure 3: Bottom view of the Kichler 52 Inch Weathered Zinc Ceiling Fan.

5. Operating Instructions

The Kichler 52 Inch Weathered Zinc Ceiling Fan is controlled via a pull chain. This model does not include integrated lighting.

- **Turning On/Off:** Pull the chain once to turn the fan on. Pull it again to cycle through speeds or turn off.
- **Adjusting Speed:** The pull chain cycles through three distinct fan speeds (High, Medium, Low) and Off. Pull the chain repeatedly until the desired speed is reached.
- **Changing Direction (Manual Reverse):** To change the direction of airflow (e.g., for summer cooling or winter heat distribution), locate the manual reverse switch on the fan motor housing. Ensure the fan is completely off and the blades have stopped rotating before changing the direction switch.

6. Maintenance

Regular maintenance ensures optimal performance and longevity of your ceiling fan.

- **Cleaning:** Periodically clean the fan blades and motor housing with a soft, damp cloth. Avoid using abrasive cleaners or solvents that could damage the finish.
- **Blade Balance:** If the fan wobbles, check that all blade screws are tight and that the blades are properly balanced. Balancing kits are available if needed.
- **Tighten Fasteners:** Annually check all screws and fasteners for tightness. Vibration can cause them to loosen over time.
- **Motor Lubrication:** The fan motor is permanently lubricated and does not require additional oiling.

7. Troubleshooting

If you experience issues with your Kichler ceiling fan, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Fan does not start	No power to the fan; Loose wire connections; Incorrect wiring.	Check circuit breaker and wall switch; Verify all wire connections are secure; Consult an electrician if wiring is suspected.
Fan wobbles excessively	Loose blade screws; Unbalanced blades; Loose mounting bracket.	Tighten all blade screws; Use a blade balancing kit; Ensure mounting bracket is securely fastened.
No airflow or weak airflow	Fan running in reverse; Incorrect speed setting.	Check the manual reverse switch on the motor housing; Adjust fan speed using the pull chain.

8. Specifications

Brand	Kichler
Model Name	310152WZC
Color	Weathered Zinc
Electric Fan Design	Ceiling Fan
Power Source	Corded Electric
Style	Modern
Product Dimensions	52"D x 52"W x 14"H
Room Type	Living Room (also suitable for outdoor use)
Special Feature	Heavy Duty
Recommended Uses	Air Circulation, Cooling
Wattage	78.00 Watts
Number of Blades	4
Air Flow Capacity	5904 Cubic Feet Per Minute
Voltage	120 Volts
Switch Type	Pull Chain
Item Weight	25 Pounds
Indoor/Outdoor Usage	Outdoor
Installation Type	Ceiling Mount
UPC	783927542500

9. Warranty and Support

This Kichler ceiling fan comes with a **1 Year Manufacturer Warranty**. For warranty claims or technical support, please contact Kichler customer service directly. Keep your purchase receipt as proof of purchase.
For further assistance, visit the official Kichler website or refer to the contact information provided with your product packaging.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question