Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Kichler 380949WZC

Kichler 380949WZC Ahrendale Outdoor Fan 1-Light Kit Instruction Manual

Model: 380949WZC

1. Introduction

This manual provides detailed instructions for the safe installation, operation, and maintenance of your Kichler 380949WZC Ahrendale Outdoor Fan 1-Light Kit. Please read all instructions carefully before beginning installation and retain this manual for future reference.

Safety Information

- Always disconnect power at the circuit breaker before installation or servicing.
- All electrical connections must be in accordance with local codes, ordinances, or the National Electric Code (NEC).
- Consult a qualified electrician if you are unsure about wiring procedures.
- This light kit is designed for outdoor use and is wet-rated. Ensure all connections are properly sealed to prevent water intrusion.
- Do not attempt to modify the light kit.

Package Contents

The Kichler 380949WZC Ahrendale Outdoor Fan 1-Light Kit includes the following components:

- Ahrendale Outdoor Fan 1-Light Kit fixture (with integrated LED)
- Mounting hardware (may vary based on fan model)
- Instruction manual



Image 1.1: Kichler 380949WZC Ahrendale Outdoor Fan 1-Light Kit. This image displays the complete light kit assembly, featuring a weathered zinc finish, a wire mesh cage, and an etched cased opal glass diffuser.

2. Setup and Installation

This light kit is designed to be installed on a compatible Kichler Ahrendale ceiling fan. Ensure the ceiling fan is properly installed and secured before proceeding with the light kit installation.

Pre-Installation Steps

1. **Turn off power:** Locate the circuit breaker that supplies power to the ceiling fan and turn it off. Verify power is off using a voltage tester.
2. **Gather tools:** You may need a screwdriver, wire strippers, electrical tape, and a ladder.
3. **Review fan manual:** Refer to your Kichler Ahrendale ceiling fan's instruction manual for specific light kit attachment points and wiring instructions.

Installation Procedure

1. **Prepare the fan:** If your ceiling fan has a temporary cover plate where the light kit will attach, remove it.

2. **Connect wiring:** Carefully connect the electrical wires from the light kit to the corresponding wires from the ceiling fan. Typically, this involves connecting the black wire from the light kit to the black wire from the fan (live/hot), the white wire from the light kit to the white wire from the fan (neutral), and the green or bare copper wire from the light kit to the green or bare copper wire from the fan (ground). Secure connections with wire nuts and electrical tape.
3. **Attach light kit:** Align the light kit with the mounting holes on the ceiling fan's motor housing. Secure the light kit using the provided screws or fasteners, ensuring it is firmly attached.
4. **Install glass diffuser:** Carefully place the etched cased opal glass diffuser into the light kit housing and secure it according to the light kit's design (e.g., by twisting or using retaining clips).
5. **Restore power:** Once installation is complete and all connections are secure, restore power at the circuit breaker.



Image 2.1: Side view of the Kichler 380949WZC light kit, showing the attachment points and the pull chain for operation.

3. Operating Instructions

The Kichler 380949WZC light kit is operated via a pull chain. It features an integrated LED light source that is dimmable.

Light Operation

- **Turning On/Off:** Pull the chain extending from the light kit once to turn the light on. Pull it again to turn the light off.
- **Dimming:** If connected to a compatible dimmable switch (either wall-mounted or integrated into the fan's remote control system, if applicable), the light output can be adjusted. Refer to your fan's remote control or wall switch instructions for dimming functionality. The integrated LED is designed to be dimmable.

Note: While the product specifications mention "Control Method: App", this functionality typically pertains to the ceiling fan itself, not directly to the light kit. The light kit's direct control is via the pull chain or a connected fan control system.

4. Maintenance

Regular maintenance ensures the longevity and optimal performance of your light kit.

Cleaning

- **Disconnect Power:** Always turn off power at the circuit breaker before cleaning.
- **Exterior Surfaces:** Wipe the exterior surfaces with a soft, damp cloth. Do not use abrasive cleaners, solvents, or polishes as they may damage the finish.
- **Glass Diffuser:** The etched cased opal glass diffuser can be carefully removed (if designed for easy removal) and washed with mild soap and water. Ensure it is completely dry before reattaching.
- **Outdoor Use:** For outdoor installations, periodically check for debris accumulation and clean as necessary to maintain appearance and function.

LED Light Source

The Kichler 380949WZC light kit features an integrated LED light source. These LEDs are designed for long life and are **not user-replaceable**. If the LED light source fails, the entire light kit may need to be replaced. Contact Kichler customer support for assistance.

5. Troubleshooting

Before attempting any repairs, always ensure power is disconnected at the circuit breaker.

Problem	Possible Cause	Solution
Light does not turn on.	• No power to the fan/light kit. • Loose wire connection. • Faulty pull chain switch. • Integrated LED failure.	• Check circuit breaker and wall switch. • Turn off power, check all wire connections. • Contact Kichler support or a qualified electrician. • Contact Kichler support for replacement options.
Light flickers or is dim.	• Incompatible dimmer switch. • Loose wire connection. • Voltage fluctuations.	• Ensure dimmer switch is LED-compatible. • Turn off power, check all wire connections. • Consult an electrician to check household wiring.

6. Specifications

Brand	Kichler
Model Number	380949WZC
Product Dimensions	11.75 x 5.25 x 11.75 inches

Item Weight	6.11 pounds
Finish Type	Weathered Zinc
Material	Alloy Steel, Glass
Light Source Type	Integrated LED
Wattage	17 Watts
Brightness	1000 Lumens
Color Temperature	3000 Kelvin (White Light)
Voltage	120 Volts
Indoor/Outdoor Usage	Outdoor (Wet Rated)
Special Features	Energy Efficient, Dimmable, Wet Rated
Control Method	Pull Chain (for light operation)
Shade Material	Glass (Etched Cased Opal)
UPC	783927543033

7. Warranty and Support

Warranty Information

All Kichler products purchased are covered by a **1-year warranty** from the date of original shipment when purchased on Amazon. This warranty covers all items and conditions identified in the original manufacturer's warranty. Additionally, a **30-day replacement parts policy** is in place to ensure a fully working item upon receipt.
The warranty specifically excludes:

- Loss and theft
- Water damage (beyond normal outdoor use for wet-rated products)
- Customer abuse
- Finish deterioration due to UV or coastal exposure

Customer Support

For technical assistance, warranty claims, or replacement parts, please contact Kichler customer support. You can find contact information on the official Kichler website or through your purchase platform.
Kichler Website: www.kichler.com

© 2023 Kichler. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0779PKHGS

More documents and user manuals: **https://manuals.plus/**