Bosch MUM9Y43S00

Bosch MUM9Y43S00 Food Processor Instruction Manual

Model: MUM9Y43S00

Introduction

Thank you for choosing the Bosch MUM9Y43S00 Multi-function Food Processor. This appliance is designed to assist you with various kitchen tasks, offering powerful performance and versatile functionality. To ensure safe and efficient operation, please read this instruction manual thoroughly before first use and keep it for future reference. This food processor features a robust 1300W motor, a stainless steel bowl, and a 3D Planetary Mixing system for optimal results.

Important Safety Instructions

- Always disconnect the appliance from the power supply before assembly, disassembly, or cleaning.
- Do not immerse the motor unit in water or any other liquid. Clean with a damp cloth only.
- Keep hands and utensils away from moving parts and sharp blades during operation.
- Ensure all attachments are correctly fitted before switching on the appliance.
- This appliance is equipped with overload protection. If the motor stops, switch off the appliance, unplug it, and allow it to cool down before restarting.
- Do not operate the appliance with a damaged cord or plug. Contact customer service for repairs.
- This appliance is for household use only. Do not use outdoors.

Product Components

Your Bosch MUM9Y43S00 Food Processor includes several key components designed for various culinary tasks:

- **Motor Unit:** The main body housing the powerful 1300W motor and control panel.
- **Stainless Steel Mixing Bowl:** A durable bowl for mixing, kneading, and whisking.
- **Dough Hook:** Specifically designed for kneading heavy doughs.
- **Whisk:** Ideal for whipping cream, egg whites, and light batters.
- **Beater:** For mixing lighter ingredients and batters.
- **Anti-slip Base:** Ensures stability during operation.
- **Cable Storage:** For neat storage of the power cord.



Image 1: The Bosch MUM9Y43S00 Food Processor, showcasing its robust design and internal gear system for efficient power transmission.



Image 2: A close-up view of the stainless steel mixing bowl, illustrating the dough hook and whisk attachments in action, designed for thorough mixing.



Image 3: An overhead perspective of the Bosch food processor, demonstrating the dough hook effectively kneading dough within the bowl.



Image 4: The mixing arm of the food processor in a raised position, highlighting the attachment mechanism for easy accessory changes.

Setup Guide

1. **Unpacking:** Carefully remove all components from the packaging. Retain packaging for future transport or storage.
2. **Initial Cleaning:** Before first use, clean all parts that will come into contact with food. Refer to the 'Maintenance' section for detailed cleaning instructions.

3. **Placement:** Place the motor unit on a clean, stable, and dry surface. Ensure there is adequate ventilation around the appliance.
4. **Attaching the Bowl:** Place the stainless steel mixing bowl onto the base of the motor unit. Rotate it clockwise until it locks securely into position.
5. **Inserting Accessories:** Lift the mixing arm. Select the desired attachment (dough hook, whisk, or beater) and insert it into the attachment shaft. Rotate until it clicks into place. Lower the mixing arm until it locks.
6. **Power Connection:** Plug the power cord into a suitable electrical outlet.

Operating Instructions

The Bosch MUM9Y43S00 Food Processor features intuitive touch controls and 7 speed settings, along with a unique 3D Planetary Mixing system.

1. **Adding Ingredients:** With the mixing arm raised, add your ingredients to the stainless steel bowl.
2. **Selecting Speed:** Use the touch control panel to select one of the 7 available speed settings. Start with a lower speed and gradually increase as needed.
3. **3D Planetary Mixing:** This system ensures that the mixing tools move in three dimensions, reaching every corner of the bowl for thorough and consistent mixing results.
4. **Specific Functions:**
    - **Kneading:** Use the dough hook for heavy doughs like bread or pizza. Start at a low speed and increase gradually.
    - **Whisking:** Use the whisk attachment for light mixtures such as egg whites, cream, or light batters. Use higher speeds.
    - **Mixing:** Use the beater for cakes, cookies, and other medium consistency batters.
5. **Bluetooth Connectivity:** This appliance may feature Bluetooth connectivity for smart control or recipe integration. Refer to the separate smart appliance guide or app for detailed instructions on pairing and usage.
6. **Stopping Operation:** To stop the appliance, select the 'off' setting on the control panel. Unplug the appliance from the power outlet after use.

Care and Maintenance

Proper cleaning and maintenance will extend the life of your Bosch Food Processor.

- **Motor Unit:** Wipe the motor unit with a damp cloth. Do not use abrasive cleaners or immerse in water.
- **Mixing Bowl and Attachments:** The stainless steel mixing bowl, dough hook, whisk, and beater are dishwasher safe. Alternatively, wash them by hand with warm, soapy water and rinse thoroughly.
- **Drying:** Ensure all parts are completely dry before reassembling or storing the appliance.
- **Cable Storage:** Utilize the integrated cable storage feature to keep the power cord neatly tucked away when not in use.

Troubleshooting

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in; power outage; safety lock not engaged.	Check power connection; ensure mixing arm is fully lowered and locked; check circuit breaker.
Motor stops during operation.	Overload protection activated.	Switch off, unplug, remove some ingredients, and allow motor to cool for 30 minutes before restarting.

Problem	Possible Cause	Solution
Attachments not mixing properly.	Incorrect attachment; insufficient quantity of ingredients.	Ensure correct attachment for the task; add more ingredients if necessary for the attachment to reach.

Technical Specifications

Feature	Detail
Brand Name	Bosch
Model Number	MUM9Y43S00
Color	Silver/White
Materials	Stainless Steel
Special Features	Bluetooth, Includes Bowl, Cable Storage, Overload Protection, Dough Hooks, Whisk, Anti-slip Base
Power	1300 Watts
Control Type	Touch
Item Weight	9500 grams
Model Name	3D Planetary Mixing
Dishwasher Safe Parts	Yes
Global Trade Identification Number	04242002938219
Manufacturer	Bosch
Product Type Name	Full Size Food Processor
Number of Speeds	7
Blade Material	Stainless Steel
Bowl Material	Stainless Steel

Warranty Information

This Bosch appliance comes with a standard manufacturer's warranty. For detailed information regarding warranty terms, conditions, and registration, please refer to the warranty card included with your product or visit the official Bosch website. Keep your proof of purchase for warranty claims.

Customer Support

Should you have any questions, require technical assistance, or need to order spare parts, please contact Bosch customer service. You can find contact details on the official Bosch website or in the documentation provided with your appliance. When contacting support, please have your model number (MUM9Y43S00) and serial number ready.

© 2023 Bosch. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question