ROVSUN SF507-17

ROVSUN Electric Fireplace Stove User Manual

Model: SF507-17

Important Safety Instructions

Please read all instructions carefully before using this electric fireplace stove. Failure to follow these instructions may result in fire, electric shock, or injury.

- Ensure the power outlet is in good condition and not loose. A loose outlet can cause the plug to overheat, posing a fire hazard.
- Do not use an extension cord with this appliance. Plug the unit directly into a 110V AC wall outlet.
- Keep combustible materials such as furniture, pillows, bedding, papers, clothes, and curtains at least 3 feet (0.9 meters) from the front of the heater and away from the sides and rear.
- Do not insert or allow foreign objects to enter any ventilation or exhaust opening as this may cause an electric shock or fire, or damage the heater.
- To prevent a possible fire, do not block air intakes or exhaust openings in any manner. Do not use on soft surfaces, like a bed, where openings may become blocked.
- This electric fireplace is equipped with an overheat protection system that automatically shuts off the unit if the internal temperature becomes too high. If this occurs, unplug the unit, wait 10-15 minutes for it to cool down, and then plug it back in.
- The unit also features tip-over protection, which automatically shuts off the heater if it is accidentally knocked over.

Product Overview

The ROVSUN Electric Fireplace Stove Model SF507-17 combines classic design with modern heating technology. It provides supplemental heat and a realistic flame effect, enhancing the ambiance of any room.

- **Realistic 3D Flame Effect:** Enjoy the visual appeal of glowing logs and dancing flames, which can operate independently of the heating function.

- **Adjustable Heating:** A powerful 1400W heating element with an adjustable thermostat provides warmth for small rooms.
- **Safety Features:** Includes overheat protection and tip-over safety switch for peace of mind.
- **Compact and Portable:** Its freestanding design and compact dimensions make it suitable for various indoor spaces.



A black freestanding electric fireplace stove with a visible flame effect and glowing logs behind a glass door. Heat is shown radiating from the bottom vent.



The electric fireplace stove is shown next to a couple, illustrating its compact size. Dimensions are marked as 17 inches wide, 9 inches deep, and 20 inches high.

Package Contents

Verify that all components are present before assembly and operation:

- 1 x Electric Fireplace Stove
- 4 x Foot
- 1 x User's Manual

Setup and Assembly

Follow these steps to set up your electric fireplace stove:

1. Carefully remove all components from the packaging.
2. Place the main body of the fireplace upside down on a soft, non-abrasive surface to prevent scratching.
3. Attach each of the four feet to the bottom of the fireplace using the provided screws. A long Phillips head screwdriver is recommended for easier assembly. Ensure all screws are tightened securely to prevent wobbling.
4. Carefully turn the assembled fireplace upright and place it on a firm, level surface. Ensure there is adequate clearance from walls and other objects (at least 3 feet from combustibles).
5. Plug the power cord directly into a standard 110V AC wall outlet. Do not use extension cords or power strips.

Operating Instructions

Familiarize yourself with the control panel for optimal use:



A detailed view of the control panel, showing a thermostat knob for temperature adjustment (68°F - 95°F / 20°C - 35°C), a heater mode

button, and a power button.

1. **Power On/Off:** Press the 'Power Button' (usually marked with a circle and vertical line symbol) to turn the unit on or off.
2. **Flame Effect:** The realistic flame effect will activate when the unit is powered on. The flames can be operated independently of the heating function.
3. **Adjusting Heat:** To activate the heater, press the 'Heater Mode Button' (usually marked with a flame symbol).
4. **Temperature Control:** Rotate the 'Thermostat Knob' to adjust the desired room temperature. The temperature range is typically between 68°F (20°C) and 95°F (35°C). The heater will cycle on and off to maintain the set temperature.



A close-up image showcasing the realistic 3D flame effect and glowing artificial logs within the fireplace, designed to mimic a real fire.



An image showing the fireplace in a bedroom setting, highlighting its quiet operation (less than 40dB) compared to other heaters or talking voices, promoting a restful environment.

Maintenance

Regular maintenance ensures the longevity and safe operation of your fireplace stove.

- **Cleaning:** Always unplug the unit before cleaning. Use a soft, damp cloth to wipe the exterior surfaces. Do not use abrasive cleaners or solvents.
- **Storage:** When not in use, store the fireplace in a cool, dry place, preferably in its original packaging, away from dust and moisture.
- **Ventilation:** Ensure that the air intake and exhaust vents are kept clear of dust and debris to maintain proper airflow.

Troubleshooting

If you encounter issues with your ROVSUN Electric Fireplace Stove, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Unit does not turn on.	No power, loose plug, or tripped circuit breaker.	Check if the unit is properly plugged into a functional 110V outlet. Inspect the outlet for looseness. Check your household circuit breaker.
No heat output.	Heater mode not activated, thermostat set too low, or overheat protection engaged.	Ensure the 'Heater Mode Button' is pressed. Adjust the 'Thermostat Knob' to a higher setting. If overheat protection engaged, unplug the unit, wait 10-15 minutes, then plug back in.
Unit shuts off unexpectedly.	Overheat protection or tip-over protection activated.	Unplug the unit and allow it to cool down for 10-15 minutes. Ensure the unit is on a stable, level surface and not obstructed.
Unit feels wobbly after assembly.	Feet not securely attached.	Ensure all screws attaching the feet are fully tightened.
Unit emits a bad smell or smoke.	Initial use odor or internal malfunction.	A slight odor may occur during the first few uses. If smoke or a strong, persistent burning smell occurs, immediately unplug the unit and contact customer support.



An illustration depicting the fireplace stove tilting, with an overlay indicating the automatic shut-off feature for safety, especially around children.

Specifications

Feature	Specification
Brand	ROVSUN
Model Name	SF507-17
Power Source	AC 110V
Power Output	1400W
Heat Output	4800 British Thermal Units (BTU)

Feature	Specification
Product Dimensions	17"W x 9"D x 20"H
Material	Iron & Glass
Finish Type	Painted
Installation Type	Freestanding
Temperature Range	68~95°F / 20~35°C
Noise Level	<40dB
Certifications	CSA
UPC	611890862960

Warranty Information

Specific warranty details for the ROVSUN Electric Fireplace Stove Model SF507-17 may vary. Please refer to the warranty card included with your product or contact ROVSUN customer support for comprehensive warranty information.

Customer Support

For any questions, technical assistance, or service inquiries regarding your ROVSUN Electric Fireplace Stove, please contact ROVSUN customer support. Refer to the contact information provided in your product packaging or on the official ROVSUN website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question