Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

LIGE MLG9846H-WYF-DE

LIGE Quartz Analog Men's Watch User Manual

Model: MLG9846H-WYF-DE

Introduction

Thank you for choosing the LIGE Quartz Analog Men's Watch. This timepiece combines classic design with reliable Japanese quartz movement, offering precision and durability. This manual provides essential instructions for setting up, operating, maintaining, and troubleshooting your watch to ensure its longevity and optimal performance.

Your watch features a date display, luminous hands for visibility in low light, and a water-resistant design suitable for daily use.



Image: Front view of the LIGE Quartz Analog Men's Watch, showcasing its blue dial, gold accents, and two-tone stainless steel band.

Setup

Setting the Time and Date

1. **Pull the Crown:** Gently pull the crown (the knob on the side of the watch) out to position 2 (the furthest position).
2. **Set the Time:** Rotate the crown to move the hands clockwise or counter-clockwise until the desired time is displayed. Ensure you set the correct AM/PM for the date change mechanism.
3. **Set the Date:** Push the crown in halfway to position 1. Rotate the crown to adjust the date. If your watch has a day display, rotate in the opposite direction to set the day.
4. **Push the Crown Back:** Once the time and date are set, push the crown back into its original position (position 0) to start the watch movement and ensure water resistance.



Image: The LIGE watch worn on a wrist, demonstrating its fit and appearance.

Operating

Water Resistance

This LIGE watch is water-resistant up to 30 meters (3 ATM). This means it is suitable for daily use and can withstand splashes or brief immersion in water. However, it is **not recommended** for swimming, diving, or prolonged water activities.

- Do not press any buttons or pull the crown while the watch is submerged in water.
- Avoid exposing the watch to steam or hot water, as this can damage the waterproof seals.
- If the watch comes into contact with saltwater, rinse it with fresh water and dry it thoroughly.



Image: The LIGE watch with a visual representation of its 30-meter water resistance.

Luminous Feature

The watch hands and hour markers are equipped with a luminous coating. After exposure to light, they will glow in the dark, allowing for time reading in low-light conditions. The intensity and duration of the glow depend on the exposure time and intensity of light.



Image: The LIGE watch displaying its luminous hands and markers in a dark environment.

Maintenance

Cleaning

- Wipe the watch case and band regularly with a soft, dry microfiber cloth to remove dust and fingerprints.
- For stubborn dirt, lightly dampen the cloth with water (avoiding soap or harsh chemicals) and gently wipe. Ensure the watch is completely dry afterward.
- Avoid direct contact with solvents, detergents, perfumes, and cosmetics, as these can damage the watch's finish and seals.

Battery Replacement

The watch is powered by a LR44 battery. When the watch stops or the second hand starts skipping, it indicates a low battery. Battery replacement should be performed by a qualified watch technician to ensure proper sealing and functionality.

Attempting to replace the battery yourself may void the warranty and compromise the watch's water resistance.

Troubleshooting

- **Watch Not Running:**
  - Ensure the crown is fully pushed in (position 0).
  - The battery may be depleted. Refer to the Battery Replacement section.
- **Date Not Changing:**
  - Check if the time is set correctly for AM/PM. The date typically changes around midnight.
  - Manually adjust the date using the crown (position 1).
- **Condensation Inside Crystal:**
  - This indicates a breach in the water resistance. Stop using the watch in wet conditions immediately.
  - Seek professional service to prevent further damage to the movement.

Specifications

Feature	Detail
Model Number	MLG9846H-WYF-DE
Movement Type	Japanese Quartz
Display Type	Analog
Case Material	Stainless Steel
Band Material	Stainless Steel
Case Diameter	45 mm
Band Length	21 cm
Water Resistance	30 Meters (3 ATM)
Power Source	Battery (1 LR44 included)
Special Features	Date Display, Luminous Hands



Image: Detailed size specifications of the LIGE watch, including case diameter, band width, and total length.

Warranty and Support

LIGE is committed to providing high-quality products and customer satisfaction. Your watch comes with the following support:

- **60-Day Free Return Service:** For any reason, you can return the product within 60 days of receipt.
- **24-Month Replacement/Full Refund:** In case of quality issues, a replacement or full refund is available for up to 24 months.
- **30-Day Unconditional Refund:** If product quality issues arise (e.g., damage during transport) within 30 days of receipt, a full refund will be provided, with shipping costs covered by LIGE.
- **6-Month Exchange Service:** For any quality problems, an exchange service is available within 6 months.
- **24-Month Product Quality Maintenance:** LIGE offers 24 months of quality maintenance for your product.

For any questions or concerns regarding your product, please contact LIGE customer support. We aim to respond within

24 hours and ensure 100% satisfaction.

© 2023 LIGE. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B077T4252J

More documents and user manuals: **https://manuals.plus/**