MAXX Cold R3313-151

Maxx Cold R3313-151 Shelf Clip

User Manual

Model: R3313-151

Introduction

This manual provides comprehensive instructions for the installation, maintenance, and troubleshooting of the Maxx Cold R3313-151 Shelf Clip. Please read this manual thoroughly before installation to ensure proper use and longevity of the product. This genuine OEM part is designed for specific Maxx Cold upright refrigerators and freezers.

Product Overview

The Maxx Cold R3313-151 Shelf Clip is a replacement component designed to securely hold shelves within compatible Maxx Cold upright refrigeration units. It is a small, white, durable plastic clip, essential for maintaining the structural integrity and functionality of your refrigerator or freezer's shelving system.



Image 1: Side view of the Maxx Cold R3313-151 Shelf Clip. This image shows the clip's profile, highlighting its L-shaped design with

a small hook for shelf support and a tab for insertion into the unit's internal slots.



Image 2: Front view of the Maxx Cold R3313-151 Shelf Clip. This image provides a clearer view of the clip's face, showing the slot where the shelf edge would rest and the overall white color and smooth finish of the plastic.

Compatibility

The R3313-151 shelf clip is specifically designed for use with the following Maxx Cold upright refrigerator and freezer models:

- MCR-23FD
- MCR-49FD
- MCR-72FD
- MCF-23FD
- MCF-49FD
- MCF-72FD
- MCRT-23FD
- MCRT-49FD
- MCRT-72FD
- MCFT-23FD
- MCFT-49FD
- MCFT-72FD

Ensure your model number matches one of the listed units for proper fit and function.

Installation Instructions

Follow these steps to properly install the Maxx Cold R3313-151 Shelf Clip:

1. **Identify Shelf Location:** Determine the desired height for your shelf within the refrigeration unit. The interior walls of Maxx Cold units have pre-drilled slots or rails for shelf clip insertion.
2. **Insert Clip:** Align the tab on the back of the R3313-151 shelf clip with one of the designated slots on the interior wall. Push the clip firmly into the slot until it clicks securely into place. Ensure the L-shaped support arm of the clip is facing upwards and outwards, ready to receive the shelf.
3. **Repeat for Remaining Clips:** For each shelf, you will typically need four shelf clips (one for each corner). Repeat the insertion process for all clips, ensuring they are at the same height and properly aligned to support the shelf evenly.
4. **Place Shelf:** Carefully lower the shelf onto the installed clips. Ensure all four corners of the shelf rest securely on their respective clips. The shelf should sit level and stable.
5. **Verify Stability:** Gently press down on the shelf to confirm it is firmly seated and does not wobble. If the shelf is unstable, re-check the installation of each clip.

Note: Always ensure the refrigeration unit is unplugged or powered off before performing any installation or maintenance to prevent accidental injury.

Operating Instructions

Once installed, the Maxx Cold R3313-151 Shelf Clip operates passively by supporting the shelf. No active operation is required. Ensure that the weight placed on the shelf does not exceed the recommended load capacity of your refrigeration unit's shelving system to prevent damage to the clips or shelves.

Maintenance

Regular maintenance of your shelf clips ensures their longevity and continued performance:

- **Cleaning:** Periodically wipe down the shelf clips with a damp cloth and mild, food-safe detergent. Rinse thoroughly and dry completely before re-inserting shelves. Avoid abrasive cleaners or solvents that could damage the plastic.
- **Inspection:** Regularly inspect the clips for any signs of wear, cracks, or damage. If a clip appears damaged or loose, replace it immediately to prevent shelves from collapsing.
- **Load Management:** Do not overload shelves. Excessive weight can stress the clips and lead to premature failure. Refer to your refrigeration unit's main manual for shelf weight limits.

Troubleshooting

Problem	Possible Cause	Solution
Shelf clip does not fit into slot.	Incorrect model clip; slot obstructed; clip misaligned.	Verify the clip is the correct R3313-151 model for your unit. Clear any debris from the slot. Ensure the clip is aligned correctly before pushing. Do not force the clip.
Shelf is wobbly or unstable after installation.	Clips not fully seated; clips not at the same height; damaged clip.	Ensure all clips are pushed firmly into their slots until they click. Verify all four clips for a shelf are at the exact same height. Inspect clips for damage and replace if necessary.
Clip breaks during installation or use.	Excessive force during installation; shelf overloaded; material fatigue.	Replace the broken clip with a new R3313-151 part. Avoid excessive force during installation. Ensure shelves are not overloaded.

Specifications

Attribute	Detail
Model Number	R3313-151
Part Type	Shelf Clip
Color	White
Material	Plastic
Package Dimensions	2.1 x 1.6 x 0.5 inches
Item Weight	0.63 ounces
Manufacturer	Maxx Cold

Warranty and Support

For information regarding warranty coverage for the Maxx Cold R3313-151 Shelf Clip, please refer to the original documentation provided with your Maxx Cold refrigeration unit or visit the official Maxx Cold website. As a genuine OEM part, it is typically covered under the appliance's warranty terms.
For technical support, replacement parts, or further assistance, please contact Maxx Cold customer service directly. You can often find contact information on the Maxx Cold official website or within the main appliance manual.
Maxx Cold Official Website: Visit the MAXX Cold Store on Amazon

© 2023 Maxx Cold. All rights reserved. This manual is for informational purposes only.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question