Sun Joe CJ603E

Sun Joe CJ603E Corded Electric Wood Chipper Shredder Instruction Manual

Model: CJ603E

Introduction

Thank you for purchasing the Sun Joe CJ603E Corded Electric Wood Chipper Shredder. This manual provides essential information for the safe assembly, operation, and maintenance of your new equipment. Please read it thoroughly before use and keep it for future reference. This chipper shredder is designed to efficiently reduce yard waste such as branches, twigs, and brush into nutrient-rich mulch.

Safety Information

Always prioritize safety when operating power tools. Failure to follow these instructions can result in serious injury or property damage.

- **Read the entire manual:** Understand all operating instructions and safety warnings before using the machine.
- **Wear appropriate personal protective equipment (PPE):** Always wear safety glasses, hearing protection, gloves, and sturdy footwear. Avoid loose clothing that could get caught in moving parts.
- **Keep bystanders clear:** Ensure children, pets, and other people are at a safe distance (at least 50 feet) from the operating area.
- **Inspect the work area:** Remove any rocks, metal, or other debris that could damage the blades or be ejected.
- **Use a proper extension cord:** For cords up to 50 feet, use a 12-gauge wire. For longer cords, use a 10-gauge wire to prevent motor damage and ensure proper power delivery.
- **Never feed material larger than specified:** The maximum branch diameter is 1.7 inches. Forcing larger material can cause jams and damage.
- **Do not operate in wet conditions:** Wet material can clog the machine and create a slip hazard.
- **Disconnect power before maintenance:** Always unplug the unit before clearing jams, cleaning, or performing any maintenance.
- **Use the safety hopper and locking knob:** The integrated safety features are designed to prevent operation when the hopper is open.

Product Overview

The Sun Joe CJ603E is a powerful electric wood chipper shredder designed for efficient yard waste management. Its robust 15-Amp motor can handle branches up to 1.7 inches in diameter, reducing them to 1/21st of their original size. This process transforms garden debris into valuable mulch for your landscape.



Figure 1: Sun Joe CJ603E Electric Wood Chipper Shredder with collection bag.

Key Features:

- **Powerful 15-Amp Motor:** Efficiently chips and shreds branches up to 1.7 inches thick.
- **21:1 Reduction Ratio:** Significantly reduces yard waste volume.
- **Integrated Safety Hopper:** Halts operation immediately when opened for user safety.
- **Portable Design:** Equipped with 7-inch wheels for easy maneuverability.
- **Zero Emissions:** Electric operation eliminates the need for fuel and produces no fumes.

Specifications:

Specification	Value
Model Number	CJ603E
Motor	15-Amp
Max. Cutting Diameter	1.7 inches (4.4 cm)
Reduction Ratio	21:1
No Load Speed	60 RPM
Decibel Rating	94 dB
Item Weight	38.6 pounds
Product Dimensions	8 x 15 x 31 inches
Color	Green

Setup

Follow these steps to assemble your Sun Joe CJ603E chipper shredder:

1. **Attach the Wheels:** Securely fasten the two wheels to the axle using the provided hardware. Ensure they are firmly in place for stability and mobility.
2. **Install the Support Legs:** Attach the support legs to the main body of the chipper shredder using the four nuts provided. Tighten all fasteners to ensure the unit is stable and level.
3. **Connect the Collection Bag:** Hook the collection bag onto the designated attachment points on the chipper shredder. Ensure the bag is securely fastened to catch all processed material.
4. **Verify Safety Features:** Before first use, confirm that the safety hopper and locking knob function correctly, preventing operation when the hopper is not properly closed.





Figure 2: Side view of the Sun Joe CJ603E chipper shredder, illustrating the wheel and leg assembly.

Operating Instructions

Operating your chipper shredder safely and effectively requires adherence to these guidelines:

1. **Preparation:** Place the chipper shredder on a firm, level surface. Ensure the collection bag is properly attached. Connect the unit to a suitable power outlet using an appropriate extension cord.
2. **Starting the Machine:** Press the green 'ON' button to start the motor. Allow the blades to reach full speed before feeding material.
3. **Feeding Material:** Slowly feed branches and twigs into the hopper. The machine is designed to pull material in automatically. Do not force material. Use the included paddle to push material if necessary, keeping hands clear of the hopper opening.
4. **Material Type:** This chipper shredder is best suited for dry, straight branches up to 1.7 inches in diameter. Avoid

feeding wet, green, or excessively leafy material as it can clog the machine.

5. **Clearing Jams:** If the machine jams, immediately press the red 'OFF' button and disconnect power. Use the reverse function if available, or carefully clear the jam with the paddle or a stick, ensuring the blades are completely stopped.
6. **Stopping the Machine:** Press the red 'OFF' button to stop the motor. Disconnect the power cord when finished or before performing any adjustments or maintenance.



Figure 3: Proper technique for feeding branches into the chipper shredder.



Figure 4: Example of processed material (mulch) after shredding.

Maintenance

Regular maintenance ensures the longevity and optimal performance of your chipper shredder.

- **Cleaning:** After each use, disconnect power and clean the hopper and discharge chute. Remove any accumulated debris to prevent clogging and ensure proper airflow.
- **Blade Inspection:** Periodically inspect the cutting blades for sharpness and damage. Dull or damaged blades can reduce efficiency and increase motor strain. Refer to the manual for instructions on blade replacement or sharpening.
- **Counterplate Adjustment:** The chipper features an adjustable counterplate to maintain optimal cutting performance. Adjust it as needed to ensure clean cuts and prevent material from passing through unprocessed.
- **Storage:** Store the chipper shredder in a dry, secure location away from children and adverse weather conditions.



Figure 5: The control panel with safety switch and forward/reverse options.

Troubleshooting

Refer to this table for common issues and their solutions:

Problem	Possible Cause	Solution
Machine does not start	No power, safety switch disengaged, circuit breaker tripped	Check power connection, ensure hopper is closed and locked, reset circuit breaker.
Machine jams frequently	Overfeeding, wet material, dull blades, material too large	Feed material slowly, ensure material is dry, sharpen/replace blades, do not exceed max diameter.
Poor shredding performance	Dull blades, incorrect counterplate adjustment	Sharpen/replace blades, adjust counterplate according to manual.

Excessive vibration	Unbalanced blades, loose components	Inspect blades for damage, check all fasteners for tightness.

Warranty and Support

For warranty information, product registration, or technical support, please refer to the warranty card included with your purchase or visit the official Sun Joe website. Keep your purchase receipt as proof of purchase for warranty claims.

Contact Information:

For assistance, please visit www.sunjoe.com or contact customer service.

© 2026 Sun Joe. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question