**ZdalaMit XRS551-D**

# ZdalaMit XRS551-D Replacement Remote Control User Manual

For Vizio Sound Bar Models: SB4051-D5, SB3851-D0, SB3820-C6, SB4451-C0, SB455-D5, SB3651-E6, SB2821-D6

## 1. Introduction

This manual provides instructions for the ZdalaMit XRS551-D replacement remote control, designed for use with various Vizio Sound Bar models. This remote offers direct functionality without the need for programming or pairing. Simply install batteries, and it is ready for use.






Image 1: Front view of the ZdalaMit XRS551-D replacement remote control, showing all buttons.

## 2. Setup

The ZdalaMit XRS551-D remote control requires two AAA batteries for operation. No programming or pairing is necessary.

### 2.1 Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards to open it.
3. Insert two 1.5V AAA alkaline batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.




Image 2: Back view of the ZdalaMit XRS551-D replacement remote control, illustrating the open battery compartment for AAA battery

insertion.

The remote is now ready for use with your compatible Vizio Sound Bar.

## 3. Operating Instructions

The XRS551-D remote control provides direct access to essential functions of your Vizio Sound Bar. Below is a description of common buttons and their functions:

- **Power Button ( )**: Turns the sound bar on or off.
- **Input Button (⌘)**: Cycles through available audio input sources (e.g., Bluetooth, Optical, AUX).
- **Bluetooth Button (✱)**: Activates Bluetooth pairing mode or switches to the Bluetooth input.
- **Volume Up (+) / Down (-)**: Adjusts the main volume level of the sound bar.
- **Mute Button ( )**: Mutes or unmutes the sound.
- **Playback Controls (Previous, Play/Pause, Next)**: Controls media playback when using compatible input sources like Bluetooth.
- **TVOL (TV Volume)**: Synchronizes the sound bar volume with your TV remote (if supported by your sound bar).
- **TSHD (TruSurround HD)**: Activates or deactivates TruSurround HD audio enhancement.
- **SUB (Subwoofer Level)**: Adjusts the subwoofer output level.
- **BASS**: Adjusts the bass level.
- **TREB (Treble)**: Adjusts the treble level.
- **MOVIE**: Activates the Movie audio preset.
- **MUSIC**: Activates the Music audio preset.

## 4. Maintenance

To ensure the longevity and proper functioning of your remote control, follow these maintenance guidelines:

- **Cleaning**: Use a soft, dry cloth to clean the remote's surface. Avoid using liquid cleaners or abrasive materials.
- **Battery Replacement**: Replace batteries when the remote's performance diminishes or if it stops responding. Always replace both batteries simultaneously with new ones of the same type.
- **Storage**: Store the remote in a cool, dry place away from direct sunlight and extreme temperatures. If storing for extended periods, remove the batteries to prevent leakage.
- **Avoid Drops**: Protect the remote from physical impact, as drops can damage internal components.

## 5. Troubleshooting

If you encounter issues with your ZdalaMit XRS551-D remote control, refer to the following troubleshooting steps:

| Problem | Possible Cause | Solution |
|---|---|---|
| Remote is not responding. | Dead or incorrectly inserted batteries. | Replace batteries with new 1.5V AAA alkaline batteries, ensuring correct polarity. |
| Remote has limited range or intermittent response. | Weak batteries; Obstruction between remote and sound bar; Infrared sensor blocked. | Replace batteries. Ensure a clear line of sight between the remote and the sound bar. Clean any dust or debris from the sound bar's IR sensor. |

| Problem | Possible Cause | Solution |
|---|---|---|
| Specific buttons are not working. | Button malfunction; Sound bar not compatible with specific function. | Test other buttons. Ensure your Vizio Sound Bar model supports the specific function (e.g., TruSurround HD). If multiple buttons fail, consider replacing the remote. |

## 6. Specifications

- **Model**: XRS551-D
- **Power Supply**: 2 x 1.5V AAA Alkaline Batteries (not included)
- **Dimensions**: Approximately 5 x 1 x 0.5 inches (12.7 x 2.54 x 1.27 cm)
- **Item Weight**: Approximately 0.81 ounces (23 grams)
- **Compatible Devices**: Vizio Sound Bars (SB4051-D5, SB3851-D0, SB3820-C6, SB4451-C0, SB455-D5, SB3651-E6, SB2821-D6)
- **Special Feature**: Ergonomic design

## 7. Warranty and Support

This ZdalaMit XRS551-D replacement remote control is designed for reliable performance. For any questions, concerns, or support needs regarding this product, please contact the seller directly through your purchase platform. Specific warranty details may vary by retailer and purchase date.


### Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question