Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Kichler 371065MULTR

Kichler 371065MULTR Wall Control Transmitter

Instruction Manual

1. Product Overview

This Kichler 371065MULTR wall-mounted control is designed for Kichler ceiling fans. It provides convenient control over fan speeds, light operation, and fan power (on/off) directly from your wall switch location.



Image 1.1: Kichler 371065MULTR Wall Control Transmitter. This image displays the white wall control unit with its various buttons and a toggle switch for fan and light operation.

2. Setup and Installation

Important Safety Information: Installation should be performed by a qualified electrician or a knowledgeable individual with experience in electrical wiring. Always turn off power at the circuit breaker before beginning any installation.

1. **Power Disconnection:** Locate the circuit breaker controlling the ceiling fan and light fixture. Turn off the power completely to prevent electrical shock. Verify power is off using a voltage tester.
2. **Remove Existing Switch:** Carefully remove the existing wall switch or cover plate from the wall box. Disconnect the wires from the old switch, noting their connections.
3. **Wiring the New Control:** Connect the wires from the wall box to the Kichler 371065MULTR Wall Control Transmitter according to the wiring diagram provided in the separate installation guide (not included here). Ensure all connections are secure with wire nuts. Typically, this involves connecting line (hot), load (to fan/light), and ground wires.
4. **Mounting:** Gently push the wired control into the wall box. Secure it with the provided screws. Attach the wall plate.
5. **Restore Power:** Turn the power back on at the circuit breaker.

3. Operation

The Kichler 371065MULTR Wall Control Transmitter provides intuitive control over your ceiling fan and light. Refer to the image below for button identification.



Image 3.1: Kichler 371065MULTR Wall Control Buttons. This image highlights the control buttons for fan speed, light, and power.

- **Power Toggle Switch (OFF/ON):** Located at the bottom, this slide switch controls the main power to the fan and light. Slide to 'ON' to enable control, and 'OFF' to completely power down the unit.
- **LIGHT Button:** Press this green button to turn the ceiling fan light on or off.
- **HI Button:** Press to set the ceiling fan to its highest speed.
- **MED Button:** Press to set the ceiling fan to a medium speed.
- **LOW Button:** Press to set the ceiling fan to its lowest speed.
- **FAN OFF Button:** Press to turn the ceiling fan motor off.
- **Indicator Light:** A small red LED at the top indicates the status of the control or power.

4. Maintenance

The Kichler 371065MULTR Wall Control Transmitter requires minimal maintenance.

- **Cleaning:** To clean the surface of the wall control, gently wipe with a soft, dry, or slightly damp cloth. Do not use abrasive cleaners, solvents, or harsh chemicals, as these can damage the finish or internal components.
- **Power Off Before Cleaning:** For safety, it is recommended to turn off power to the control at the circuit breaker before cleaning.

5. Troubleshooting

Problem	Possible Cause	Solution
Fan or Light Not Responding	No power to the control; Incorrect wiring; Fan/light receiver issue.	Ensure the main power toggle switch is in the 'ON' position. Check the circuit breaker for the fan/light. Verify wiring connections (consult an electrician if unsure). Ensure the fan's receiver is functioning correctly.
Fan Operates, But Light Does Not	Light bulb faulty; Loose light wiring; Light receiver issue.	Check and replace the light bulb. Inspect light wiring connections within the fan (with power off).
Control Buttons Are Unresponsive	Power interruption; Internal fault.	Turn off power at the circuit breaker for 30 seconds, then restore power. If the issue persists, contact customer support.

6. Specifications

Feature	Detail
Brand	Kichler
Model Number	371065MULTR
Series	371065MULTR
Item Weight	3.84 ounces
Product Dimensions (LxWxH)	4.5 x 2.75 x 4.5 inches
Color	Metal (finish)
Power Source	Corded-Electric
Voltage	120 Volts
Material	Plastic

7. Warranty Information

Specific warranty details for the Kichler 371065MULTR Wall Control Transmitter are typically provided with the product packaging or available on the official Kichler website. Please refer to these official resources for the most accurate and up-to-date warranty terms and conditions.

8. Customer Support

For further assistance, technical support, or inquiries regarding your Kichler 371065MULTR Wall Control Transmitter, please contact Kichler customer service or visit their official website:

- **Kichler Official Website:** www.kichler.com
- Refer to your product packaging for specific contact numbers or email addresses.

© 2024 Kichler. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07857JX7K

More documents and user manuals: **https://manuals.plus/**