Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ONN ONB-203

ONN Audio Compact Home CD Music Shelf System

Model: ONB-203 (Model Number: 43235-112218)

Brand: ONN

Introduction

The ONN Audio Compact Home CD Music Shelf System is designed to provide a versatile audio experience in a compact form factor. This system features a vertical-loading CD player, digital AM/FM radio, and an auxiliary input for connecting external audio devices. Its stereo dynamic speakers deliver clear sound, making it suitable for various rooms in your home.



Image: The ONN Compact Home CD Music Shelf System with its vertical-loading CD player open, revealing a CD. The main unit is positioned between two stereo speakers, and the remote control is visible in the foreground. This setup highlights the system's compact design and primary components.

Safety Information

- **Power Source:** Use only the provided power adapter. Ensure the voltage matches your local power supply.
- **Ventilation:** Do not block any ventilation openings. Allow adequate space around the unit for proper airflow to prevent overheating.
- **Water and Moisture:** Do not expose the unit to rain, moisture, or dripping/splashing liquids. Do not place objects filled with liquids, such as vases, on the unit.
- **Heat Sources:** Keep the unit away from heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- **Cleaning:** Unplug the unit from the wall outlet before cleaning. Use a soft, dry cloth. Do not use liquid cleaners or aerosol cleaners.
- **Servicing:** Do not attempt to service this product yourself. Refer all servicing to qualified service personnel.
- **Placement:** Place the unit on a stable, flat surface. Avoid placing it in direct sunlight or near strong magnetic fields.

Package Contents

Please check the package carefully to ensure all items are present and in good condition.

- ONN Audio Compact Home CD Music Shelf System Main Unit
- Two (2) Dynamic Stereo Speakers
- Remote Control
- Power Adapter

Setup

1. Placement

The system can be placed on a shelf or mounted on a wall. Ensure the surface is stable and can support the weight of the unit and speakers. For optimal sound, position the speakers equidistant from the main unit and at ear level when seated.

2. Connecting the Speakers

Connect the speaker wires from the two dynamic stereo speakers to the corresponding speaker output jacks on the back of the main unit. Ensure the positive (+) and negative (-) terminals on the speakers match those on the main unit for correct audio phasing.

3. Connecting Power

Insert the DC plug of the power adapter into the DC IN jack on the back of the main unit. Then, plug the power adapter into a standard wall outlet.

4. Remote Control Battery Installation

Open the battery compartment on the back of the remote control. Insert the required batteries (not specified in product details, typically AAA or button cell) ensuring correct polarity (+/-). Close the compartment securely.



Image: A direct front view of the ONN Compact Home CD Music Shelf System, highlighting the central unit's control panel, LCD display, and the two accompanying stereo speakers. This view is useful for identifying buttons and ports.

Operating Instructions

Power On/Off

Press the **POWER** button on the main unit or remote control to turn the system on or off.

CD Playback

1. Press the **FUNCTION** button to select CD mode.
2. Press the **OPEN** button to open the vertical CD compartment.

3. Carefully insert a CD or CD-R/RW disc with the label side facing forward.
4. Close the CD compartment. The system will begin reading the disc.
5. Use the **PLAY/PAUSE** button to start or pause playback.
6. Use the **SKIP/SEARCH** buttons (◀◀ / ▶▶) to skip tracks or fast forward/rewind.
7. Adjust volume using the **VOLUME** controls on the unit or remote.

AM/FM Radio Operation

1. Press the **FUNCTION** button to select FM or AM radio mode.
2. Extend the FM wire antenna fully for better reception. For AM, rotate the unit for best reception.
3. Use the **TUNING** buttons (◀◀ / ▶▶) to manually tune to a station. Press and hold to auto-scan for the next available station.
4. The digital LCD screen will display the current frequency.

Auxiliary Input (AUX IN)

1. Connect an external audio device (e.g., MP3 player, smartphone) to the 3.5mm **AUX IN** jack on the main unit using a 3.5mm audio cable (not included).
2. Press the **FUNCTION** button to select AUX mode.
3. Control playback (play, pause, skip) directly from your connected external device.
4. Adjust volume using the system's **VOLUME** controls or the external device's volume control.

Equalizer Settings (Remote Control)

The remote control provides access to 5 preset equalizer settings to customize your sound experience. Press the **EQ** button on the remote to cycle through the available presets (e.g., Flat, Pop, Rock, Jazz, Classic).



Image: An angled view of the ONN Compact Home CD Music Shelf System with its vertical-loading CD player closed. The image

emphasizes the system's compact and modern design, flanked by its two stereo speakers, with the remote control positioned in front.

Maintenance

- **Cleaning the Unit:** Wipe the exterior of the unit with a soft, dry, lint-free cloth. Do not use abrasive cleaners, waxes, or solvents.
- **CD Care:** Handle CDs by their edges. Keep them clean and free of scratches. Store them in their cases when not in use.
- **Speaker Grilles:** Gently brush off dust from the speaker grilles using a soft brush or vacuum cleaner with a brush attachment.
- **Long-Term Storage:** If the unit will not be used for an extended period, unplug it from the power outlet and store it in a cool, dry place.

Troubleshooting

Problem	Possible Cause	Solution
No power	Power adapter not connected securely; Wall outlet not active.	Ensure power adapter is firmly plugged into the unit and a working wall outlet. Try a different outlet.
No sound	Volume too low; Speakers not connected properly; Incorrect function mode selected.	Increase volume. Check speaker connections. Ensure correct function (CD, FM, AM, AUX) is selected.
CD not playing or skipping	Disc is dirty or scratched; Disc inserted incorrectly; Disc format not supported (e.g., Blu-ray).	Clean the disc with a soft, lint-free cloth. Re-insert the disc with the label side facing forward. Ensure it is a standard audio CD or CD-R/RW.
Poor radio reception	Antenna not extended; Interference from other electronics.	Fully extend the FM wire antenna. For AM, rotate the unit for better reception. Move the unit away from other electronic devices.
Remote control not working	Batteries are dead or inserted incorrectly; Obstruction between remote and unit.	Replace batteries with new ones, ensuring correct polarity. Remove any obstructions between the remote and the unit's sensor. Ensure you are within range.

Specifications

Feature	Detail
Brand	ONN
Model Number	43235-112218
ASIN	B0788BQ2SG
Package Dimensions	19.1 x 10.6 x 4.8 inches
Item Weight	5.31 pounds

Feature	Detail
Connectivity Technology	Auxiliary
Color	Blue
Speaker Type	Stereo
CD Player Type	Vertical-loading CD and CD-R/RW player
Radio Tuner	Digital AM/FM
Display	Blue-backlit LCD screen
Equalizer	5 preset equalizer settings

Warranty and Support

This ONN Audio Compact Home CD Music Shelf System is a renewed product and comes with a **90-day warranty** from the date of purchase. This warranty covers manufacturing defects and malfunctions under normal use.
For technical support, troubleshooting assistance, or warranty claims, please contact the seller or the Amazon Renewed support team through your purchase platform. Please have your product model number (ONB-203 / 43235-112218) and purchase details ready when contacting support.
For more information, you may visit the Amazon Renewed Store.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0788BQ2SG

More documents and user manuals: **https://manuals.plus/**