KYOCERA S2720

Kyocera Cadence S2720 User Manual

Model: S2720 (SG_B07891JPRS_US)

Introduction

This manual provides essential information for setting up, operating, and maintaining your Kyocera Cadence S2720 mobile phone. Please read this manual thoroughly to ensure proper use and to maximize the performance of your device.

Device Overview



This image displays the Kyocera Cadence S2720 flip phone in its open position, revealing its sleek blue casing. The external screen shows the Verizon logo, current date (Thu, Aug 10), time (1:00), and signal strength indicator. A portion of the internal keypad with numbers 5 (MNO) and 9 (WXYZ) and the #SPACE key is visible. The phone's camera lens is visible on the top part of the flip.

The Kyocera Cadence S2720 is a compact flip phone designed for reliable communication. It features a durable build and essential functionalities for daily use.

Setup

What's in the Box

- Kyocera Cadence S2720 Handset
- Adapter
- USB Cable
- Verizon Nano SIM Card (if included with purchase)

Battery Installation and Charging

1. **Open the back cover:** Gently pry open the back cover of the phone using the designated notch.
2. **Insert the battery:** Align the battery contacts with the terminals inside the phone and press down gently until it clicks into place.
3. **Replace the back cover:** Align the cover and press firmly around the edges until it snaps securely.
4. **Charge the battery:** Connect the USB cable to the phone's charging port and the adapter. Plug the adapter into a power outlet. Allow the phone to charge fully before first use. The battery indicator on the screen will show charging status.

SIM Card Installation

1. **Remove the back cover and battery:** Follow the steps above to remove the back cover and battery.
2. **Locate the SIM card slot:** The SIM card slot is typically located near the battery compartment.
3. **Insert the SIM card:** Carefully slide the Nano SIM card into the slot with the gold contacts facing down, ensuring it is correctly oriented as indicated by the diagram near the slot.
4. **Reinstall battery and back cover:** Place the battery back in and secure the back cover.

Operating Your Phone

Power On/Off

- **To Power On:** Press and hold the **Power/End Call** button until the screen lights up.
- **To Power Off:** Press and hold the **Power/End Call** button until the power off options appear, then select "Power Off".

Making and Receiving Calls

- **To Make a Call:** Enter the phone number using the keypad and press the **Call/Send** button.
- **To Answer a Call:** When the phone rings, press the **Call/Send** button.
- **To End a Call:** Press the **Power/End Call** button.

Sending Text Messages

1. From the main screen, navigate to *Messages*.
2. Select *New Message*.
3. Enter the recipient's phone number or select from contacts.
4. Type your message using the keypad.
5. Press *Send*.

Contacts

Store frequently called numbers in your phone's contacts for quick access. You can add, edit, and delete contacts through the *Contacts* menu.

Connectivity Features

- **Wi-Fi:** Your phone supports Wi-Fi connectivity. Access Wi-Fi settings through the main menu to connect to available networks.
- **GPS:** The device is equipped with GPS for location services.
- **Mobile Hotspot:** (If applicable to your model) This feature allows you to share your phone's cellular data connection with other Wi-Fi enabled devices. Refer to your carrier's instructions for activation and usage.

Maintenance

General Care

- Keep the phone dry. Moisture can damage electronic circuits.
- Avoid extreme temperatures. High temperatures can shorten the life of electronic devices and warp or melt certain plastics.
- Do not use harsh chemicals, cleaning solvents, or strong detergents to clean the phone. Wipe it with a soft, damp cloth.
- Handle the phone gently. Do not drop, knock, or shake it.

Battery Care

- Use only Kyocera-approved chargers and batteries.
- Do not short-circuit the battery terminals.
- Do not dispose of batteries in a fire.
- Recycle used batteries according to local regulations.

Troubleshooting

Problem	Possible Solution
Phone does not power on	Ensure the battery is correctly installed and charged. Connect the charger and try again.
No network signal	Check if the SIM card is properly inserted. Move to an area with better network coverage. Restart the phone.
Cannot make or receive calls	Verify network signal. Check if call barring is enabled. Ensure your account is active with your service provider.
Battery drains quickly	Reduce screen brightness. Close unused applications. Limit background data usage. Consider replacing an old battery.
Phone freezes or is unresponsive	Remove and reinsert the battery to perform a soft reset. If the issue persists, consult customer support.

Specifications

Feature	Detail
Product Dimensions	0.3 x 5.6 x 2.8 inches

Feature	Detail
Item Weight	6.4 ounces
Model Number	SG_B07891JPRS_US
Operating System	KaiOS
Wireless Technologies	Cellular, Wi-Fi
GPS	True
Human Interface Input	Microphone, Keypad
Scanner Resolution	320 x 240
Camera Features	Rear
Form Factor	Flip
Color	Blue
Battery Type	1 Lithium Ion battery required
Manufacturer	Kyocera
Date First Available	December 14, 2017

Warranty and Support

For warranty information and customer support, please refer to the documentation provided with your purchase or contact Kyocera customer service directly. You may also visit the official Kyocera website for the most up-to-date support resources.
For service-related inquiries, please contact your mobile service provider (e.g., Verizon).

© 2024 Kyocera. All rights reserved.
This manual is for informational purposes only. Specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

How do I enlarge a photo sent through conversations on the Kyocera Cadence S2720?

To enlarge or view a photo sent through a text message conversation on your Kyocera Cadence S2720, follow these steps:Open the Messages application from the main menu.Select the conversation containing the photo you wish...

Read full answer