Roberts Radio Stream 94i

Roberts Radio Stream 94i User Manual

Model: Stream 94i

Your guide to setting up, operating, and maintaining your Roberts Radio Stream 94i Stereo Internet Radio.

Introduction

The Roberts Radio Stream 94i is a versatile stereo internet radio designed to provide a comprehensive audio experience. It supports FM, DAB, DAB+, WiFi, Ethernet, Bluetooth, and USB connectivity, allowing access to a vast array of radio stations and personal music libraries. This manual provides detailed instructions to help you get the most out of your device.



Figure 1: Front view of the Roberts Radio Stream 94i, showcasing the display, control knobs, and speaker grille.

1. Setup and First Use

Follow these steps to set up your Roberts Radio Stream 94i for the first time.

1.1 Unboxing and Components

Carefully remove all components from the packaging. Ensure you have the following:

- Roberts Radio Stream 94i unit
- Power Adapter
- Remote Control
- User Manual (this document)
- Quick Start Guide

1.2 Connecting Power

Connect the supplied power adapter to the 'DC IN' port on the rear of the radio. Plug the other end into a wall socket. The radio will power on automatically or enter standby mode.



Figure 2: Rear view of the Roberts Radio Stream 94i, showing the DC IN, LAN, USB, Aux In, and Line Out ports.

1.3 Antenna Setup

Extend the telescopic antenna fully for optimal FM and DAB/DAB+ reception. For best results, position the antenna vertically.

1.4 Network Connection (Wi-Fi / Ethernet)

To access Internet Radio and Spotify Connect, the Stream 94i requires a network connection.

- **Wi-Fi:** On first power-up, the radio will guide you through the Wi-Fi setup. Select your network from the list and enter the password using the control knobs.
- **Ethernet:** Alternatively, connect an Ethernet cable from your router to the 'LAN' port on the rear of the radio. The radio will automatically detect the wired connection.

2. Operating Your Radio

This section details the various functions and modes of your Stream 94i.

2.1 Controls and Display

The radio features two main rotary controls (Volume and Tuning/Select/Snooze) and several buttons below the display.



Figure 3: Close-up of the Roberts Radio Stream 94i front panel, highlighting the control knobs and buttons.

- **Volume Knob:** Rotate to adjust volume. Press to mute/unmute.
- **Tuning/Select/Snooze Knob:** Rotate to navigate menus or tune stations. Press to select an option or snooze an

alarm.

- **Power Button ( ):** Press to turn on/off or enter standby.
- **Alarm Button:** Access alarm settings.
- **Info Button:** Display station or track information.
- **Preset Buttons (1-5):** Store and recall favorite stations.
- **Mode Button:** Cycle through available modes (Internet Radio, DAB, FM, Bluetooth, USB, Aux In).
- **Menu Button:** Access the main menu for settings and options.
- **Back Button:** Return to the previous screen or menu.

2.2 Radio Modes

Press the 'Mode' button to switch between the following:

- **Internet Radio:** Access thousands of stations worldwide. Browse by location, genre, or search by name.
- **DAB/DAB+:** Digital radio reception. The radio will scan for available stations.
- **FM:** Analog radio reception. Tune manually or use auto-scan.
- **Bluetooth:** Pair with a smartphone or tablet to stream audio wirelessly.
- **USB:** Play music files from a USB flash drive. Also functions as a charging port for smartphones.
- **Aux In:** Connect external audio devices via a 3.5mm audio cable.

2.3 Saving and Recalling Presets

To save a station as a preset:

1. Tune to the desired station.
2. Press and hold one of the 'Preset' buttons (1-5) until "Preset Saved" appears on the display.

To recall a preset:

1. Simply press the corresponding 'Preset' button (1-5).

2.4 Spotify Connect

The Stream 94i supports Spotify Connect. Ensure your radio is connected to the same Wi-Fi network as your smartphone or tablet running the Spotify app. Select the Stream 94i from the 'Devices Available' list within the Spotify app to stream music directly to your radio.

2.5 Using the Remote Control

The included remote control provides convenient access to most functions. Point the remote directly at the front of the radio for optimal response.



Figure 4: The Roberts Radio Stream 94i shown with its accompanying remote control.

3. Maintenance

Proper care will ensure the longevity of your Roberts Radio Stream 94i.

3.1 Cleaning

Wipe the radio with a soft, dry, lint-free cloth. Do not use abrasive cleaners, waxes, or solvents as these may damage the finish. Ensure the radio is unplugged before cleaning.

3.2 Optional Battery Pack (BP93i)

The Stream 94i can be powered by an optional rechargeable battery pack (BP93i, not supplied). Refer to the battery pack's instructions for installation and charging details. If using the battery, ensure it is fully charged for portable use.

4. Troubleshooting

If you encounter issues with your Stream 94i, refer to the following common problems and solutions.

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
No power	Power adapter not connected or faulty; power outlet not active.	Ensure power adapter is securely connected to the radio and a working wall outlet. Try a different outlet.
No sound	Volume too low; muted; incorrect source selected.	Increase volume. Press the Volume knob to unmute. Press 'Mode' to select the correct audio source.
Poor FM/DAB reception	Antenna not extended; weak signal.	Fully extend the telescopic antenna. Reposition the radio or antenna for better signal. Perform a new auto-scan for DAB stations.
Cannot connect to Wi-Fi	Incorrect password; router issues; radio too far from router.	Double-check Wi-Fi password. Restart your router. Move the radio closer to the router or use an Ethernet cable.
Bluetooth pairing issues	Device not in pairing mode; radio already connected to another device.	Ensure the radio is in Bluetooth mode and your device's Bluetooth is on and discoverable. Disconnect from other Bluetooth devices.

4.1 Factory Reset

If problems persist, a factory reset may resolve them. This will erase all saved settings, presets, and network configurations.

1. Go to the main menu.
2. Navigate to 'System Settings' (or similar).
3. Select 'Factory Reset' and confirm.

5. Specifications

Key technical specifications for the Roberts Radio Stream 94i.

Brand: Roberts Radio

Model Number: Stream 94i

Color: Bois - Cerise (Cherry Wood)

Product Type: Stereo Portable Radio

Connectivity: Bluetooth, Wi-Fi, Ethernet, USB, Aux In, Line Out

Radio Bands: FM, DAB, DAB+, Internet Radio

Audio Codec Support: MP3, WMA, FLAC, AAC, ALAC, WAV

Power Source: AC Adapter (included), Optional BP93i Rechargeable Battery Pack (not included)

Special Features: Integrated Spotify Connect, USB charging port, Alarm function

Components Included: Power adapter, remote control, user manual, quick start guide

6. Warranty and Support

Your Roberts Radio Stream 94i comes with a manufacturer's warranty and support information.

6.1 Manufacturer's Warranty

This product is covered by a **2-year manufacturer's warranty**. Please retain your proof of purchase for warranty claims. The warranty covers defects in materials and workmanship under normal use.

6.2 Customer Support

For technical assistance, troubleshooting beyond this manual, or warranty inquiries, please contact Roberts Radio customer support. Refer to the official Roberts Radio website for the most up-to-date contact information and support resources.

7. Official Product Videos

There are no official product videos from the seller available for embedding at this time.

© 2024 Roberts Radio. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question