Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ZdalaMit AH59-02547B

ZdalaMit AH59-02547B Replacement Remote Control User Manual

For Samsung Sound Bar Models: AH68-02644D-00, HW-F450ZA, HW-F450, PS-WF450, HWF450ZA, HWF450, PSWF450, AH59-02612B

1. Introduction

This manual provides instructions for the ZdalaMit AH59-02547B replacement remote control. This remote is designed to function as a direct replacement for the original remote controls of various Samsung Sound Bar models. No programming or pairing is required for its operation.

2. Setup

2.1 Battery Installation

The remote control requires two (2) AAA alkaline batteries (not included) for operation. Follow these steps to install the batteries:

1. Locate the battery compartment on the back of the remote control.
2. Press down on the latch and slide the battery cover downwards to open it.
3. Insert two new 1.5V AAA alkaline batteries, ensuring the positive (+) and negative (-) terminals match the diagrams inside the compartment.
4. Slide the battery cover back into place until it clicks securely.



Image: Back of the remote control with the battery compartment open, illustrating correct battery placement.

2.2 Initial Use

Once batteries are correctly installed, the remote control is ready for use. No programming or pairing with your Samsung Sound Bar is required. Point the remote directly at your sound bar and begin operation.

3. Operating Instructions

The AH59-02547B remote control features standard buttons for controlling your Samsung Sound Bar. Refer to the image below for button layout and descriptions.



Image: Front view of the remote control with all buttons labeled.

3.1 Button Functions

- **POWER (Red Button)**: Turns the Sound Bar on or off.
- **TV POWER (Red Button)**: Turns the connected TV on or off.
- **SOURCE / TV SOURCE**: Selects the input source for the Sound Bar or TV.
- **AUTO POWER**: Toggles the Auto Power Link feature.
- **SPEAKER**: Adjusts speaker settings.
- **SoundShare**: Activates or deactivates the SoundShare feature.
- **Anynet+**: Controls Anynet+ (HDMI-CEC) compatible devices.
- **REPEAT**: Repeats playback (if applicable).
- **VOL +/-**: Adjusts the main volume level of the Sound Bar.
- **TV VOL +/-**: Adjusts the volume level of the connected TV.
- **TV CH +/-**: Changes channels on the connected TV.
- **AUDIO SYNC**: Adjusts audio delay for synchronization.
- **MUTE**: Mutes or unmutes the Sound Bar audio.
- **TV MUTE**: Mutes or unmutes the TV audio.
- **TV INFO**: Displays information about the current TV program.
- **TV PRE-CH**: Returns to the previous TV channel.
- **DIMMER**: Adjusts the brightness of the Sound Bar display.
- **Playback Controls (Rewind, Play/Pause, Fast Forward, Stop)**: Controls media playback.
- **SOUND EFFECT**: Cycles through available sound effects/modes.
- **SMART VOLUME**: Toggles Smart Volume feature.
- **Navigation Buttons (Up, Down, Left, Right)**: Navigates menus and selections.
- **MUTE (Center Button)**: Mutes or unmutes the Sound Bar audio.
- **S/W LEVEL +/-**: Adjusts the subwoofer volume level.
- **3D SOUND PLUS**: Activates or deactivates 3D Sound Plus.
- **DRC (Dynamic Range Control)**: Toggles Dynamic Range Control.

4. Maintenance

4.1 Battery Replacement

Replace batteries when the remote control's response becomes sluggish or stops working. Always replace both batteries at the same time with new 1.5V AAA alkaline batteries. Do not mix old and new batteries, or different types of batteries.

4.2 Cleaning

To clean the remote control, use a soft, dry cloth. Do not use liquid cleaners, sprays, or abrasive materials, as these can damage the remote's surface or internal components.

5. Troubleshooting

- **Remote not responding:**
  - Check if the batteries are inserted correctly with the correct polarity (+/-).
  - Replace the batteries with new ones.
  - Ensure there are no obstructions between the remote control and the Sound Bar's sensor.
  - Make sure you are within the effective range of the Sound Bar.
- **Specific buttons not working:**
  - This remote is a replacement and may not support all advanced functions of every original remote. Verify if the function is supported by your Sound Bar model.
  - Clean the remote control surface, especially around the unresponsive buttons, to ensure no debris is interfering.

6. Specifications

Feature	Detail
Model	AH59-02547B
Compatible Models	Samsung Sound Bar AH68-02644D-00, HW-F450ZA, HW-F450, PS-WF450, HWF450ZA, HWF450, PSWF450, AH59-02612B
Power Supply	2 x 1.5V AAA Alkaline Batteries
Dimensions	Approximately 5 x 2 x 0.5 inches (12.7 x 5.1 x 1.3 cm)
Weight	Approximately 1.41 ounces (40 grams) without batteries
Color	Black

7. Warranty Information

This product is typically covered by a standard manufacturer's warranty against defects in materials and workmanship. Please refer to your purchase documentation or contact the seller for specific warranty terms and conditions. Keep your proof of purchase for warranty claims.

8. Customer Support

If you encounter any issues or have questions regarding your ZdalaMit AH59-02547B remote control that are not addressed in this manual, please contact the seller or manufacturer for assistance. Provide your product model number

and details of the issue for efficient support.

© 2023 ZdalaMit. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B078M917Y9

More documents and user manuals: **https://manuals.plus/**