Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Kichler 43692OZ

Kichler Shailene 43692OZ 18-inch 3-Light Semi-Flush Mount Ceiling Light Instruction Manual

Model: 43692OZ | Brand: Kichler

1. Introduction

This manual provides detailed instructions for the safe installation, operation, and maintenance of your Kichler Shailene 43692OZ 18-inch 3-Light Semi-Flush Mount Ceiling Light. Please read all instructions carefully before beginning installation and retain this manual for future reference.

The Kichler Shailene semi-flush mount fixture features an Olde Bronze finish, a white microfiber shade, and a satin etched white diffuser, designed to provide ambient lighting in various indoor settings.



Image 1.1: Kichler Shailene 18-inch 3-Light Semi-Flush Mount Ceiling Light, showcasing its Olde Bronze finish and white shade.

2. Safety Information

WARNING: Risk of electric shock. Disconnect power at the circuit breaker or fuse box before installation or servicing. Do not attempt installation if you are not familiar with electrical wiring procedures. Consult a qualified electrician.

- Ensure all electrical connections comply with local codes and ordinances.
- Use only the specified bulb type and wattage (E26, up to 75W equivalent per bulb).
- Do not exceed the maximum wattage indicated on the fixture.
- Handle glass components with care to prevent breakage.
- Keep flammable materials away from the light fixture.

3. Package Contents

Carefully unpack your fixture and check that all parts are included. If any parts are missing or damaged, contact Kichler customer service before proceeding with assembly.

- Mounting Strap
- Strap Mounting Screws
- Mounting Screws
- Lockwasher
- Lock up Knobs
- Wire Nuts
- Trim
- Finial
- Bead Pipe
- Shade(s) (White Microfiber)
- Satin Etched White Diffuser
- Instruction Manual (This document)

Note: Bulbs are not included and must be purchased separately.

4. Specifications

Feature	Specification
Model Number	43692OZ
Brand	Kichler
Fixture Type	Semi-Flush Mount Ceiling Light
Finish	Olde Bronze
Shade Material	White Microfiber
Diffuser Material	Satin Etched White Glass
Dimensions (Overall)	18" Width x 11.25" Height

Feature	Specification
Bulb Base	E26 (Medium)
Number of Lights	3
Max Wattage per Bulb	75W Equivalent
Total Max Wattage	225W
Voltage	120V AC
Special Feature	Dimmable (with compatible bulbs and dimmer switch)
Assembly Required	Yes
Item Weight	5.8 pounds



Image 4.1: Dimensional view of the Kichler Shailene fixture, indicating its 18-inch width and 11.25-inch height.

5. Setup and Installation

Professional installation is recommended for electrical fixtures. If you are not comfortable with electrical wiring, please consult a qualified electrician.

Required Tools (Not Included):

- Phillips head screwdriver
- Flathead screwdriver
- Wire strippers

- Electrical tape
- Safety glasses
- Ladder

Installation Steps:

1. **Turn Off Power:** Locate the circuit breaker or fuse box controlling the light fixture's power supply. Turn off the power completely before starting any work.
2. **Prepare Mounting:** Attach the mounting strap to the junction box using the provided strap mounting screws. Ensure the strap is securely fastened.
3. **Wire Connections:** Connect the fixture's wires to the corresponding house wires using wire nuts. Connect the black (hot) wire from the fixture to the black (hot) wire from the junction box. Connect the white (neutral) wire from the fixture to the white (neutral) wire from the junction box. Connect the bare copper or green (ground) wire from the fixture to the bare copper or green (ground) wire from the junction box. Secure all connections with electrical tape.
4. **Attach Fixture to Mounting Strap:** Carefully align the fixture's canopy with the mounting strap. Secure the fixture to the mounting strap using the mounting screws and lock up knobs. Ensure the fixture is flush against the ceiling and stable.
5. **Install Diffuser and Shade:** Place the satin etched white diffuser into the fixture. Then, carefully position the white microfiber shade over the diffuser and secure it with the finial and bead pipe. Ensure the shade is properly seated and stable.
6. **Install Bulbs:** Screw three E26 base bulbs (not included, up to 75W equivalent each) into the sockets. Do not overtighten.
7. **Restore Power:** Once installation is complete and all components are secure, restore power at the circuit breaker or fuse box.



Image 5.1: The Kichler Shailene fixture installed on a ceiling, demonstrating its semi-flush mount design.

6. Operating Instructions

The Kichler Shailene 3-Light Semi-Flush Mount Ceiling Light operates like a standard hardwired light fixture. Once installed and powered, it can be controlled by a wall switch.

- **Turning On/Off:** Use the wall switch connected to the fixture to turn the light on or off.
- **Dimmable Feature:** This fixture is dimmable. To utilize the dimming function, ensure you are using dimmable E26 bulbs and have a compatible dimmer switch installed on your wall. Follow the dimmer switch manufacturer's instructions for operation.
- **Bulb Replacement:** To replace bulbs, first turn off power at the circuit breaker. Allow bulbs to cool completely. Unscrew the finial, remove the shade and diffuser, then carefully unscrew the old bulbs and replace them with new E26 bulbs (up to 75W equivalent). Reassemble the diffuser, shade, and finial, then restore power.

7. Maintenance

Regular cleaning will help maintain the appearance and performance of your light fixture.

- **Cleaning Instructions:** Be certain the electric current is turned off before cleaning. Clean metal components with a soft cloth moistened with a mild liquid soap solution. Wipe clean and buff with a very soft dry cloth.
- **Shade Care:** The white microfiber shade can be gently dusted with a soft, dry cloth. Avoid using harsh chemicals or abrasive cleaners on the shade.
- **Glass Diffuser Care:** The satin etched glass diffuser can be cleaned with a soft cloth and a mild glass cleaner. Ensure the diffuser is completely dry before reassembling.

8. Troubleshooting

If you encounter issues with your Kichler Shailene light fixture, refer to the following common troubleshooting steps:

Problem	Possible Cause	Solution
Light does not turn on	1. Power is off at the circuit breaker. 2. Loose wire connections. 3. Faulty bulb(s). 4. Faulty wall switch.	1. Check the circuit breaker and ensure it is in the ON position. 2. Turn off power, check all wire connections, and re-secure if loose. 3. Replace bulb(s) with new, working ones. 4. Test the wall switch or consult an electrician.
Light flickers	1. Loose bulb(s). 2. Incompatible dimmer switch or bulbs. 3. Loose wire connections.	1. Turn off power, tighten bulbs. 2. Ensure dimmable bulbs are used with a compatible dimmer. Replace if necessary. 3. Turn off power, check and secure wire connections.
Humming noise from fixture	1. Incompatible dimmer switch or bulbs. 2. Loose components.	1. Ensure dimmable bulbs are used with a compatible dimmer. Replace if necessary. 2. Turn off power, check for any loose parts and tighten them.

If these steps do not resolve the issue, please contact Kichler customer support.

9. Warranty and Support

Warranty Information:

The Kichler Shailene 43692OZ Semi-Flush Mount Ceiling Light comes with a**1-year limited warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use. It does not cover damage resulting from improper installation, accident, misuse, abuse, or unauthorized modifications.

Please retain your proof of purchase for warranty claims.

Customer Support:

For technical assistance, replacement parts, or warranty inquiries, please contact Kichler customer service. You can find contact information on the official Kichler website or through your retailer.

Visit the Kichler Store for more information:Kichler Official Store

© 2023 Kichler Lighting. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B078RXBJDL

More documents and user manuals: **https://manuals.plus/**