ADESSO WKB-1100CB

Adesso WKB-1100CB Wireless Keyboard and Mouse Combo Instruction Manual

Model: WKB-1100CB | Brand: ADESSO

Introduction

The Adesso WKB-1100CB is a compact and portable wireless keyboard and mouse combo designed for efficiency and convenience. This manual provides detailed instructions for setting up, operating, maintaining, and troubleshooting your device to ensure optimal performance.

Key features include a mini-size design for space-saving, wireless connectivity up to 30 feet, spill-resistant keyboard, quiet membrane key switches, and an enhanced optical mouse for precise navigation. The combo also features a battery-saving mode to extend usage time.



Figure 1: Adesso WKB-1100CB Wireless Keyboard and Mouse Combo. This image displays the compact black wireless keyboard and the accompanying black wireless mouse, showcasing their ergonomic design.

Setup Guide

Follow these steps to set up your Adesso WKB-1100CB wireless keyboard and mouse combo.

1. **Unpack Contents:** Carefully remove the keyboard, mouse, and USB receiver from the packaging. Verify that all components are present. The package should include:
    - 1 x Wireless Keyboard
    - 1 x Wireless Mouse
    - 1 x USB Receiver
    - 2 x AA Batteries (pre-installed or included)
    - 1 x Instruction Guide (this manual)
2. **Install Batteries:**
    - **For the Keyboard:** Locate the battery compartment on the underside of the keyboard. Open the cover and insert the AA batteries, ensuring correct polarity (+/-). Close the cover securely.
    - **For the Mouse:** Locate the battery compartment on the underside of the mouse. Open the cover and insert the AA battery, ensuring correct polarity (+/-). Close the cover securely.
3. **Connect USB Receiver:** Plug the small USB receiver into an available USB port on your computer. The system should automatically detect and install the necessary drivers. No additional software installation is typically required.
4. **Power On:** Ensure the keyboard and mouse are powered on. There may be an ON/OFF switch on the underside of each device.
5. **Test Connection:** Once the receiver is plugged in and devices are powered on, the keyboard and mouse should be ready for use. Test by typing on the keyboard and moving/clicking the mouse.



Figure 2: Underside of the Adesso WKB-1100CB Keyboard. This image shows the bottom of the keyboard, highlighting the battery compartment and the model number label.

Operating Instructions

The Adesso WKB-1100CB combo is designed for intuitive use. Here are some operational details:

- **Wireless Range:** The keyboard and mouse operate wirelessly with a range of up to 30 feet (approximately 9 meters) from the USB receiver. This allows for flexible positioning and use.
- **Keyboard Hotkeys:** The keyboard includes popular hotkey commands conveniently located for quick access to functions such as media control, volume adjustment, and more. Refer to the key legends for specific functions.
- **Membrane Key Switches:** The keyboard features membrane key switches that provide a responsive and quiet typing experience, suitable for various environments.
- **Enhanced Optical Mouse:** The mouse is equipped with an enhanced optical engine, ensuring accurate and precise tracking on a variety of surfaces, including marble, wood, and leather.
- **Battery Saving Feature:** To conserve battery life, both the keyboard and mouse will enter a power-saving sleep mode after a period of inactivity. To wake them up, simply press any key on the keyboard or move/click the mouse.

Maintenance

Proper maintenance ensures the longevity and optimal performance of your Adesso WKB-1100CB combo.

- **Spill-Resistant Design:** The keyboard features a spill-resistant design, which helps to prevent damage from accidental liquid spills by allowing fluids to drain away. In case of a spill, immediately disconnect the keyboard from the computer and allow it to dry completely before re-connecting. Do not submerge the keyboard in liquid.



Figure 3: Water being poured onto the Adesso keyboard. This image demonstrates the keyboard's spill-resistant capability, with water flowing over the keys.



Figure 4: Close-up of water droplets on the Adesso keyboard. This image provides a detailed view of water beading on the keyboard surface, illustrating its resistance to spills.

- **Cleaning:** To clean the keyboard and mouse, use a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these can damage the surfaces. For the keyboard, you can use compressed air to remove debris from between the keys.
- **Battery Replacement:** When the performance of your keyboard or mouse diminishes, it is likely time to replace the batteries. Follow the "Install Batteries" steps in the Setup Guide. Dispose of old batteries responsibly according to local regulations.
- **Storage:** When not in use for extended periods, it is recommended to turn off the devices to further conserve battery life. Store the combo in a cool, dry place away from direct sunlight and extreme temperatures.

Troubleshooting

If you encounter issues with your Adesso WKB-1100CB combo, refer to the following common problems and solutions:

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Keyboard/Mouse not responding	• Low or dead batteries • USB receiver not properly connected • Out of wireless range • Interference from other wireless devices	• Replace batteries in both keyboard and mouse. • Ensure the USB receiver is firmly plugged into a working USB port. Try a different USB port. • Move the keyboard/mouse closer to the USB receiver (within 30 feet). • Minimize interference by moving other wireless devices away from the receiver.
Lagging or intermittent connection	• Distance from receiver • Obstructions between devices and receiver • Weak signal	• Reduce the distance between the devices and the USB receiver. • Ensure there are no large metal objects or other electronic devices blocking the signal path. • Consider using a USB extension cable to position the receiver in a more open area, closer to the devices.
Keys or mouse buttons feel sticky/unresponsive	• Debris under keys/buttons • Liquid residue	• Clean the keyboard and mouse as described in the Maintenance section. • Ensure the keyboard is completely dry after any spills.
Mouse cursor erratic or not tracking	• Dirty optical sensor • Unsuitable surface	• Clean the optical sensor on the underside of the mouse with a soft, lint-free cloth. • Use the mouse on a clean, non-reflective, and uniform surface.

Specifications

Detailed technical specifications for the Adesso WKB-1100CB Wireless Keyboard and Mouse Combo:

Feature	Detail
Brand	ADESSO
Model Number	WKB-1100CB
Connectivity Technology	Radio Frequency (Wireless)
Wireless Range	Up to 30 feet (9 meters)
Keyboard Type	Mini-size, Spill Resistant, Membrane Key Switches
Mouse Type	Enhanced Optical Sensor

Feature	Detail
Color	Black
Item Weight	10.4 ounces (approx. 295 grams)
Product Dimensions (LxWxH)	14.8 x 5.7 x 1.8 inches (approx. 37.6 x 14.5 x 4.6 cm)
Power Source	Battery Powered
Batteries Required	2 AA batteries (included)
Compatible Devices	Laptop, Personal Computer
Hardware Platform	PC; Windows; Mac; Linux; Unix
Operating System Compatibility	Windows XP and newer (compatible with various OS platforms)

Warranty and Support

Adesso products are designed for reliability and performance. For warranty information and technical support, please refer to the official Adesso website or contact their customer service directly.

- **Official Website:** Visit www.adesso.com for the latest product information, drivers, FAQs, and support resources.
- **Customer Service:** For direct assistance, please contact Adesso customer support. Contact details can typically be found on their official website under the "Support" or "Contact Us" section.
- **Product Registration:** Registering your product may provide additional benefits and streamline future support requests. Check the Adesso website for product registration options.

© 2024 ADESSO Inc. All rights reserved. Adesso and the Adesso logo are trademarks of Adesso Inc.
This manual is for informational purposes only. Specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question