Willz WLR31TS1

Willz WLR31TS1 Compact Refrigerator Instruction Manual

Model: WLR31TS1

Product Overview

The Willz WLR31TS1 Compact Refrigerator is a 3.1 Cu.Ft dual-door unit featuring an adjustable mechanical thermostat and a true freezer compartment. Its stainless steel look and reversible doors offer versatile placement options for various environments such as kitchens, offices, or dorms.



Front view of the Willz WLR31TS1 Compact Refrigerator, showcasing its stainless steel finish and dual-door design.

Key Features:

- Stainless Steel Look
- Adjustable Mechanical Thermostat Control
- 2 Liter Bottle Door Storage
- 1 Crystal Crisper with Glass Cover
- 1 Full Slide Out Glass Shelf
- True Top Mount Freezer Compartment
- Reversible Door
- Interior Light
- 2 Leveling Front Legs

Setup and Installation

Unpacking:

1. Carefully remove all packaging materials, including the base and any adhesive tape.
2. Inspect the refrigerator for any shipping damage. Report any damage to your retailer immediately.
3. Retain packaging materials for future transport or service needs.

Placement:

Choose a location with a firm, level floor that can support the weight of the refrigerator when fully loaded. Ensure adequate air circulation around the unit. Avoid direct sunlight or heat sources.

- Allow at least 4 inches of space from the back and sides for proper ventilation.
- The unit dimensions are approximately 19.13"D x 21.1"W x 32.8"H.



The compact refrigerator shown with its approximate dimensions and the EnergyGuide label, indicating its energy efficiency.

Leveling:

The refrigerator is equipped with two leveling front legs. Adjust these legs to ensure the unit is stable and level. Proper leveling helps the door close and seal correctly.

Electrical Connection:

Connect the refrigerator to a dedicated 120 Volts / 60Hz power outlet. Do not use extension cords or adapter plugs. Allow the unit to stand upright for at least 2-4 hours before plugging it in to allow the refrigerant to settle.

Operating Instructions

Temperature Control:

The refrigerator features an adjustable mechanical thermostat control. The temperature range is from 32°F to 47°F. Turn the thermostat dial to your desired setting. A higher number indicates a colder temperature.

Storage:

- **Glass Shelves:** The removable glass shelf can be adjusted to different heights to accommodate various food items.
- **Crystal Crisper:** Use the crystal crisper with its glass cover for storing fruits and vegetables to maintain their freshness.
- **Door Storage:** The door features compartments suitable for 2-liter bottles and other smaller items.
- **True Freezer:** The top-mount freezer compartment is designed for freezing and storing frozen foods.

Interior Light:

The refrigerator compartment is equipped with an interior light that illuminates when the door is opened.

Maintenance and Care

Defrosting:

This refrigerator uses a manual defrost system. Frost will accumulate on the freezer walls. When the frost layer is about 1/4 inch thick, it should be defrosted. To defrost, unplug the unit, remove all food, and allow the frost to melt naturally. Do not use sharp objects to remove ice.

Cleaning:

- Unplug the refrigerator before cleaning.
- Clean the interior and exterior surfaces with a soft cloth and a mild detergent solution.
- Removable shelves and the crisper can be washed with warm, soapy water.
- Ensure all parts are dry before returning them to the refrigerator.
- Regularly clean the back of the unit to prevent dust accumulation on the condenser coils, which can affect efficiency.

Troubleshooting

If your refrigerator is not operating correctly, please check the following common issues before contacting customer support:

- **Refrigerator not operating:** Check if the power cord is securely plugged into a live outlet. Ensure the circuit breaker has not tripped.
- **Temperature is not cold enough:** Adjust the thermostat to a colder setting. Ensure the door is closing properly and not being opened too frequently. Check for excessive food load.

- **Unusual noises:** Slight humming from the compressor is normal. Ensure the refrigerator is level and not touching any walls or cabinets.
- **Excessive frost build-up:** This indicates a need for manual defrosting. Ensure the door seal is intact and not allowing warm air to enter.

Specifications

Feature	Detail
Brand Name	Willz
Model Info	WLR31TS1
Capacity	3.1 Cubic Feet
Item Weight	52.9 pounds
Product Dimensions	19.13"D x 21.1"W x 32.8"H
Annual Energy Consumption	357 Kilowatt Hours Per Year
Refrigerant	R600a
Voltage	120 Volts / 60Hz
Installation Type	Freestanding
Defrost System	Manual Defrost
Door Hinges	Reversible
Color	Stainless Steel Look
Material Type	Iron

Warranty and Support

Your product package includes a Warranty Card. Please refer to this card for detailed information regarding your product's warranty coverage and terms.

For any further assistance, technical support, or service inquiries, please contact Willz Customer Support. Contact information can typically be found on the Warranty Card or the official Willz website.

Note: Always consult the full User's Manual provided with your product for complete safety information and operating instructions.

© 2023 Willz. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question