Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

JustFine SG_B078ZHBHWH

JustFine Replacement Remote Control Instruction Manual

Brand: JustFine | **Model:** SG_B078ZHBHWH

Introduction

This manual provides essential instructions for the setup, operation, and maintenance of your JustFine replacement remote control. This remote is designed to be compatible with various Samsung Sound Bar Systems, including models HW-JM4000C, HW-K450, HWK551, HWKM36, HWKM370, and HW-KM45C.
The remote control is pre-programmed and requires no additional setup or coding for use with compatible sound bar systems. Simply install the batteries, and it is ready for operation.

Setup

Battery Installation

The remote control requires one CR2032 coin cell battery (not included). Follow these steps to install the battery:

1. Locate the circular battery compartment cover on the back of the remote control.
2. Use a coin or a flat-head screwdriver to turn the cover counter-clockwise until it loosens.
3. Remove the cover and insert one CR2032 battery with the positive (+) side facing upwards.
4. Replace the battery compartment cover and turn it clockwise until it is securely fastened.



Image: Back of the remote control with the battery compartment. The label reads: "CAUTION: RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE. DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTION."

Important: Ensure the battery is inserted with the correct polarity. Dispose of used batteries according to local regulations.

Initial Use

Once the battery is installed, the remote control is ready for immediate use. No programming or pairing is required. Point the remote directly at your Samsung Sound Bar System to operate it.

Operating Instructions

The remote control features 12 buttons for various functions. While the exact layout may vary, the primary functions typically include:

- **Power Button:** Turns the sound bar system on or off.
- **Volume Up/Down:** Adjusts the sound bar's volume level.
- **Mute Button:** Silences or restores the sound.
- **Source/Function Button:** Cycles through available input sources (e.g., HDMI, Optical, Bluetooth).
- **Sound Mode Button:** Changes the sound effect or mode (e.g., Standard, Music, Movie).
- **Bass/Treble Control:** Adjusts bass or treble levels (if available on your sound bar model).
- **Navigation Buttons (Up/Down/Left/Right/Enter):** Used for menu navigation if your sound bar has an on-screen display.



Image: Front view of the remote control, displaying its button layout.

For specific button functions related to your sound bar model, please refer to your original Samsung Sound Bar System manual.

Maintenance

Cleaning

To clean the remote control, gently wipe it with a soft, dry cloth. Do not use liquid cleaners, abrasive pads, or chemical solvents, as these can damage the remote's surface or internal components.

Battery Replacement

Replace the CR2032 battery when the remote control's responsiveness decreases or it stops functioning. Refer to the "Battery Installation" section for detailed instructions. Always use the correct battery type and dispose of old batteries responsibly.

Troubleshooting

- **Remote not responding:**
  - Check if the battery is installed correctly with the positive (+) side facing up.
  - Replace the battery with a new CR2032 battery.
  - Ensure there are no obstructions between the remote control and the sound bar's infrared receiver.
  - Make sure you are within the maximum operating range (up to 10 meters).
- **Limited range or intermittent response:**
  - Replace the battery.
  - Ensure the remote is pointed directly at the sound bar.
  - Avoid strong light sources (like direct sunlight or bright fluorescent lights) that might interfere with the infrared signal.

Specifications

Brand	JustFine
Model Name	SG_B078ZHBHWH
Compatible Devices	Samsung Sound Bar Systems (HW-JM4000C, HW-K450, HWK551, HWKM36, HWKM370, HW-KM45C)
Connectivity Technology	Infrared
Controller Type	Button Control
Button Quantity	12
Maximum Range	10 Meters
Battery Type	CR2032 Coin Cell (*Note: Product specifications listed "AA Alkaline", but user reviews and image suggest CR2032. Please verify upon receipt.*)
Color	Black
Special Feature	Ergonomic

Warranty Information

This JustFine replacement remote control comes with a 30-day quality warranty from the date of purchase. This warranty covers manufacturing defects and ensures the product functions as intended under normal use. For warranty claims or issues, please contact customer support.

Customer Support

Should you encounter any problems or have questions regarding your JustFine replacement remote control, please do not hesitate to contact our customer support team. We are committed to providing assistance and resolving any concerns you may have.
Please refer to your purchase documentation or the seller's contact information for the most direct way to reach us.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question