Milwaukee 2724-20

Milwaukee M18 FUEL 2724-20 Cordless Handheld Blower Instruction Manual

Model: 2724-20 | Brand: Milwaukee

1. Important Safety Information

Read and understand all safety warnings, instructions, illustrations, and specifications provided with this power tool. Failure to follow all instructions listed below may result in electric shock, fire, and/or serious injury.

General Safety Precautions:

- Always wear eye protection.
- Keep hair, loose clothing, fingers, and all parts of body away from openings and moving parts.
- Do not operate power tools in explosive atmospheres, such as in the presence of flammable liquids, gases, or dust.
- Maintain proper footing and balance at all times. Do not overreach.
- Remove the battery pack before making any adjustments, changing accessories, or storing the tool.
- Use only with specified battery pack and charger.

Battery Tool Use and Care:

- Recharge only with the charger specified by the manufacturer.
- Use power tools only with specifically designated battery packs.
- When battery pack is not in use, keep it away from other metal objects.
- Do not use a battery pack or tool that is damaged or modified.
- Do not expose a battery pack or tool to fire or excessive temperature.

2. Package Contents

The Milwaukee M18 FUEL Cordless Handheld Blower typically includes the following components:

- Milwaukee M18 FUEL Handheld Blower (Tool Only)
- Blower Nozzle

Note: Battery pack and charger are sold separately and are not included with the tool-only purchase.

3. Product Features

The Milwaukee M18 FUEL Cordless Handheld Blower is designed for efficient and powerful clearing tasks. Key features include:

- **M18 FUEL Technology:** Delivers powerful performance and extended run-time.
- **Brushless Motor:** Provides increased efficiency, longer motor life, and more power.
- **Variable Speed Trigger:** Allows for precise control over airflow.
- **Speed Lock Button:** Enables continuous operation without holding the trigger.
- **Lightweight and Compact Design:** Enhances user comfort and reduces fatigue during prolonged use.
- **Interchangeable Battery System:** Compatible with all Milwaukee M18 battery packs.



Image: Close-up view of the blower's handle, showing the variable speed trigger and the speed lock button for continuous operation.

4. Setup

4.1 Attaching the Nozzle:

1. Align the nozzle with the blower's air outlet.
2. Push the nozzle firmly onto the outlet until it clicks into place, ensuring a secure connection.



Image: The Milwaukee M18 FUEL Handheld Blower fully assembled with its nozzle, ready for use.

4.2 Installing the Battery Pack:

1. Ensure the blower is turned off.
2. Slide a charged Milwaukee M18 battery pack into the battery port on the rear of the blower until it locks securely.
3. To remove, press the release button on the battery pack and slide it out.

5. Operating Instructions

5.1 Powering On and Speed Control:

1. To start the blower, press the variable speed trigger. The airflow speed will increase as the trigger is pressed further.
2. The blower features multiple speed settings (e.g., "turtle" for lower power, "bunny" for higher power) which can be toggled using the speed control button located on the handle.

5.2 Continuous Operation:

1. For continuous operation without holding the trigger, press the trigger to the desired speed and then engage the speed lock button.
2. To disengage the speed lock, simply press the trigger again.



Image: A user operating the Milwaukee M18 FUEL Blower to efficiently clear leaves from a paved sidewalk.



Image: A man utilizing the Milwaukee M18 FUEL Blower to clear grass clippings from the edge of a curb and driveway.

6. Maintenance

6.1 General Cleaning:

- Always remove the battery pack before cleaning.
- Keep the tool's air vents clear and free of debris to prevent overheating.
- Wipe down the exterior with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners.

6.2 Battery Care:

- Store battery packs in a cool, dry place away from direct sunlight and extreme temperatures.
- Do not store battery packs in a discharged state for extended periods.
- Follow the charging instructions provided with your Milwaukee M18 charger.

7. Troubleshooting

7.1 Blower Not Starting:

- Ensure the battery pack is fully charged and properly inserted.
- Check for any obstructions in the air intake or nozzle.
- Verify that the trigger is fully depressed.

7.2 Reduced Airflow:

- Check the battery charge level; low battery can reduce performance.
- Clear any debris from the nozzle or air intake.
- Ensure the speed setting is appropriate for the task.

8. Specifications

Brand	Milwaukee
Model Number	2724-20
Power Source	Battery Powered (18 Volts)
Air Flow Capacity	450 CFM
Speed	120 MPH
Item Weight	6.98 pounds
Product Dimensions	23.5"L x 7.5"W x 11"H
Special Features	Compact Design, Lightweight, Portable, Rechargeable

9. Warranty and Support

For detailed warranty information, product registration, or technical support, please refer to the official Milwaukee website or contact their customer service. Keep your purchase receipt as proof of purchase for warranty claims.

Online Support: Visit the official Milwaukee Tool website for FAQs, service center locations, and product manuals.

Customer Service: Contact Milwaukee customer support for assistance with product operation, troubleshooting, or warranty service.

© 2025 Milwaukee Tool. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question