ONKRON TS1881

ONKRON Mobile TV Stand TS1881 Instruction Manual

Model: TS1881

1. Introduction

Thank you for choosing the ONKRON Mobile TV Stand TS1881. This stand is designed to provide a versatile and portable solution for displaying televisions ranging from 50 to 86 inches. It features adjustable height, integrated shelves for media devices, and locking wheels for easy mobility and stability. Please read this manual thoroughly before assembly and use to ensure safe and correct operation.



Image 1.1: The ONKRON Mobile TV Stand TS1881, showcasing its design with a television, laptop, and webcam mounted.

2. Important Safety Information

WARNING: Failure to read and follow all instructions may result in serious personal injury, property damage, or voiding of warranty.

- Ensure the TV stand is assembled correctly according to the instructions.
- Do not exceed the maximum weight capacity of 233 lbs (105 kg) for the TV or 11 lbs (5 kg) per shelf.
- Verify that your TV's VESA mounting pattern is compatible (200x200mm to 800x500mm).
- Always lock the wheels when the stand is stationary to prevent accidental movement.
- Keep children and pets away from the stand during assembly and when moving the unit.
- Use caution when moving the stand, especially on uneven surfaces.
- Do not attempt to modify the stand or use it for purposes other than intended.

3. Package Contents

Before beginning assembly, ensure all parts are present and undamaged. Refer to the diagram below for a visual representation of the components.



Image 3.1: Exploded view of all components and hardware included with the TS1881 TV stand.

The package includes:

- Base unit
- Vertical columns
- TV mounting brackets
- Two adjustable shelves (one for media, one for webcam)
- Four locking wheels
- Assorted screws, washers, and tools for assembly

4. Setup and Assembly

Assembly typically requires two people. Follow the numbered steps provided in the included assembly guide. Ensure all connections are secure before mounting the television.

1. **Assemble the Base:** Attach the vertical columns to the base unit using the provided hardware. Ensure the columns are firmly secured.

2. **Install Wheels:** Insert and secure the four locking wheels into the base.
3. **Attach TV Brackets:** Secure the TV mounting brackets to the back of your television using the appropriate VESA screws. Refer to your TV's manual for correct screw length.
4. **Mount TV to Stand:** Carefully lift the television and hook the TV brackets onto the vertical columns of the stand. Secure the TV in place with the safety screws.
5. **Install Shelves:** Attach the media shelves to the desired height on the vertical columns. The upper shelf is designed for a webcam or small camera.



Image 4.1: Visual representation of VESA compatibility (200x200 to 800x500) and maximum TV weight (200 lbs) for the TS1881 stand.



Image 4.2: Close-up of the adjustable shelves, each supporting up to 11 lbs, and the wheel lock mechanism.

5. Operating Instructions

5.1 Adjusting Height

The TV stand allows for height adjustment of the television from 53.1 inches to 65 inches. To adjust, loosen the securing bolts on the vertical columns, carefully raise or lower the TV to the desired height, and then firmly tighten the bolts to secure it in place. It is recommended to have assistance when adjusting the height with a TV mounted.



Image 5.1: Illustration of the adjustable height range for the TS1881 stand.

5.2 Mobility and Locking Wheels

The stand is equipped with four rubberized wheels for easy movement. To move the stand, unlock all four wheels. To secure the stand in a stationary position, press down on the locking mechanism on each wheel until it clicks into place. This prevents unintended movement.



Image 5.2: The TS1881 stand demonstrating easy mobility, integrated cable channels, and floor-safe wheels.

5.3 Using the Shelves

The stand includes two height-adjustable shelves. Each shelf can support up to 11 lbs (5 kg). The upper shelf is specifically designed to accommodate a PTZ camera or webcam. Ensure items placed on the shelves do not exceed the weight limit and are positioned securely.

5.4 Cable Management

Integrated cable channels within the vertical columns allow for neat routing and concealment of power and video cables, contributing to a tidy setup and reducing trip hazards.

5.5 Portrait Mode (Optional)

For certain applications, the stand supports mounting a TV in portrait orientation, depending on the TV's VESA pattern and size. This is typically suitable for VESA patterns up to 400x400mm.



Image 5.3: The TS1881 stand configured to hold a television in portrait orientation.

6. Maintenance

To ensure the longevity and proper function of your ONKRON Mobile TV Stand TS1881, follow these maintenance guidelines:

- **Cleaning:** Wipe down the stand with a soft, damp cloth. Avoid using abrasive cleaners or solvents that could damage the finish.
- **Hardware Check:** Periodically check all screws and bolts to ensure they remain tight. Re-tighten if necessary.
- **Wheel Inspection:** Inspect the wheels for any debris or damage that might impede smooth movement. Clean as needed.
- **Weight Limits:** Always adhere to the specified weight limits for the TV and shelves to prevent structural damage.

7. Troubleshooting

If you encounter issues with your ONKRON Mobile TV Stand TS1881, refer to the following common problems and

solutions:

- **Stand is unstable:**
  - Ensure all assembly bolts are securely tightened.
  - Verify that the TV weight does not exceed the maximum capacity.
  - Check that the stand is on a flat, level surface.
- **Wheels do not roll smoothly:**
  - Check if the wheel locks are engaged. Disengage them for movement.
  - Inspect wheels for any trapped debris (e.g., hair, carpet fibers) and clean if necessary.
- **TV cannot be mounted:**
  - Confirm your TV's VESA pattern is within the supported range (200x200mm to 800x500mm).
  - Ensure the TV weight is within the maximum limit of 233 lbs.
- **Shelves are loose:**
  - Re-tighten the screws securing the shelves to the vertical columns.
  - Ensure items on the shelves do not exceed the 11 lbs weight limit per shelf.

If problems persist, please contact ONKRON customer support for further assistance.

8. Specifications

Brand	ONKRON
Model Number	TS1881
Compatible TV Sizes	50 - 86 inches
Maximum TV Load	233 lbs (105 kg)
VESA Compatibility	200x200mm to 800x500mm
Height Adjustment	53.1 inches to 65 inches
Shelf Load Capacity	11 lbs (5 kg) per shelf
Material	Alloy Steel
Product Dimensions	41.73 x 29.13 x 7.01 inches (packaged)
Item Weight	70.4 pounds



Image 8.1: Supported VESA mounting patterns for the TS1881 stand.

9. Warranty and Customer Support

ONKRON products undergo multi-stage quality control and are designed for durability. For specific warranty details, please refer to the warranty card included with your product or visit the official ONKRON website. If you have any questions, require assistance with assembly, or need troubleshooting support, please contact ONKRON customer service. Our experts are ready to assist you.

Contact Information: Refer to the ONKRON official website or product packaging for the most current customer support contact details.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question