Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Arzum AR1035

Arzum Prochopp Eco Color Glass 600W Food Chopper User Manual

Model: AR1035

1. Important Safety Instructions

Please read all instructions carefully before using the Arzum Prochopp Eco Color Glass 600W Food Chopper. Keep this manual for future reference.

- Always unplug the appliance from the power outlet before cleaning, assembling, or disassembling parts.
- Do not immerse the motor unit in water or any other liquid. Clean with a damp cloth only.
- Keep hands and utensils out of the chopping bowl while operating to prevent injury and damage to the appliance.
- Blades are sharp. Handle with extreme care when assembling, disassembling, or cleaning.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Ensure the lid is securely locked in place before operating the chopper. The appliance features a safety lock mechanism.
- Do not operate the appliance with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner.
- For household use only. Do not use outdoors.

2. Product Overview

Familiarize yourself with the components of your Arzum Prochopp Eco Food Chopper.



Figure 2.1: Main components of the Arzum Prochopp Eco Food Chopper, showing the red motor unit, the transparent chopping bowl, and the clear lid.

A. Motor Unit: The red main body containing the 600W motor and operation switch.

B. Chopping Bowl: Transparent plastic bowl with a capacity of 1 liter, used for holding ingredients.

C. Double-sided Stainless Steel Blade: Sharp blade assembly for chopping.

D. Lid: Clear lid with a safety lock mechanism that fits on top of the chopping bowl.

E. Anti-slip Plastic Stands: Located at the base of the chopping bowl for stability during operation.



Figure 2.2: Close-up view of the Arzum Prochopp Eco components, highlighting the main body (motor), double-sided stainless steel blade, 1-liter transparent bowl, and anti-slip plastic stands.

3. Setup and Assembly

Follow these steps to correctly assemble your food chopper before use.

1. Place the transparent chopping bowl (B) on a stable, flat surface. Ensure the anti-slip stands (E) are firmly gripping the surface.
2. Carefully place the double-sided stainless steel blade (C) onto the central shaft inside the chopping bowl. Ensure it is seated correctly.
3. Add the ingredients you wish to chop into the bowl. Do not exceed the maximum fill line indicated on the bowl.
4. Place the lid (D) onto the chopping bowl, aligning the tabs on the lid with the slots on the bowl. Twist the lid clockwise until it locks securely into place. The safety lock mechanism prevents operation if the lid is not properly secured.
5. Position the motor unit (A) on top of the assembled lid. Ensure the motor unit is properly seated and engaged with the blade shaft through the lid's opening.



Figure 3.1: The Arzum Prochopp Eco Food Chopper fully assembled and ready for use, showing the motor unit securely placed on top of the lid and chopping bowl.

4. Operating Instructions

Operating your Arzum Prochopp Eco Food Chopper is simple and efficient.

1. Ensure the chopper is fully assembled as described in Section 3.
2. Plug the power cord into a suitable electrical outlet.
3. To operate, press and hold the power button located on top of the motor unit. The blades will begin to rotate, chopping the ingredients.
4. Use short pulses for coarse chopping or hold for longer periods for finer results. Do not operate continuously for more than 30 seconds to prevent motor overheating. Allow a short break between cycles.
5. Once the desired consistency is achieved, release the power button.
6. Unplug the appliance from the power outlet before disassembling.
7. Carefully remove the motor unit, then unlock and remove the lid.
8. Carefully remove the blade assembly before emptying the chopped ingredients.

Note: *The appliance is designed with a safety lock. If the motor unit or lid is not correctly positioned, the chopper will not operate.*

5. Maintenance and Cleaning

Proper cleaning and maintenance will ensure the longevity of your Arzum Prochopp Eco Food Chopper.

- **Motor Unit:** Wipe the motor unit with a damp cloth. Do not immerse it in water or any other liquid.
- **Chopping Bowl, Lid, and Blades:** These parts are not dishwasher safe. Hand wash them with warm, soapy water immediately after use. Rinse thoroughly and dry completely before storing.
- **Handling Blades:** Always handle the sharp blades with extreme caution. Use a brush to clean them if necessary, avoiding direct contact with your fingers.
- **Storage:** Store the assembled chopper or its components in a dry, safe place, out of reach of children.

6. Troubleshooting

If you encounter issues with your Arzum Prochopp Eco Food Chopper, refer to the following common problems and solutions.

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in; Lid or motor unit not properly assembled; Power outage.	Ensure the power cord is securely plugged in. Check that the lid is locked and the motor unit is correctly seated. Verify power supply.
Blades are not rotating.	Ingredients are too large or too much; Blade is jammed.	Unplug the appliance. Remove some ingredients or cut them into smaller pieces. Clear any obstructions around the blade.
Motor smells or overheats.	Continuous operation for too long; Overloaded.	Stop operation immediately. Unplug the appliance and let it cool down for at least 15-20 minutes. Reduce the amount of ingredients for the next use. Use pulse function.

7. Specifications

Brand: Arzum

Model: AR1035

Power/Wattage: 600 watts

Volume Capacity: 1 Liter (chopping bowl)

Material: Plastic (bowl), Stainless Steel (blades)

Color: Red

Special Features: Safety Lock

Item Weight: 1.24 Kilograms

Product Dimensions: 65 x 44.5 x 29 cm (approximate, based on package dimensions)

Product Care: Hand Wash (bowl, lid, blades), Wipe Clean (motor unit)

Dishwasher Safe: No

8. Warranty and Support

Your Arzum Prochopp Eco Food Chopper comes with a manufacturer's warranty and dedicated support.

- **Warranty:** This product is covered by a two-year warranty. Please retain your proof of purchase for warranty claims.
- **Customer Support:** For any inquiries, technical assistance, or warranty service, please contact the Arzum customer service hotline at 15789.

© 2024 Arzum. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0799DR1J6

More documents and user manuals: **https://manuals.plus/**