AICOOK 7539774722

AICOOK Espresso Machine Instruction Manual

Model: 7539774722

Product Overview

The AICOOK Espresso Machine is designed for convenient preparation of espresso, cappuccino, and latte beverages. It features a 15-bar pump, a one-touch digital screen for operation, and an integrated automatic milk frother.



Figure 1: Key components of the AICOOK Espresso Machine, including the One-Touch Intuitive Display, Portafilter, Removable Drip Tray, Removable Water Reservoir, Adjustable Steam Wand, and On/off Button.

Setup

Before first use, or after a long period of inactivity, perform an initial cleaning cycle with water only to prepare the boiler.

Initial Preparation Steps:

1. Fill the espresso machine's water reservoir and milk reservoir. Ensure both are securely in place.
2. Select the appropriate filter (single or double shot) and fill it with coffee grounds. Tamp the coffee grounds firmly using the provided measuring scoop.
3. Lock the portafilter into the grouphead by aligning it and rotating it to the right until secure.
4. Place a cup under the portafilter and turn the machine on.
5. Perform a water-only cycle by selecting an espresso option without coffee to flush the system.



Figure 2: The 1.8L removable water reservoir, designed for easy filling and cleaning, with a clear water window.

Operating Instructions

The AICOOK Espresso Machine features a one-touch digital screen for simplified beverage selection.

Brewing a Beverage:

1. Ensure the machine is powered on and has completed its preheating cycle (indicator light will be steady).
2. Prepare the portafilter with coffee grounds as described in the Setup section.
3. Place your cup on the drip tray. The cup holder can be adjusted for larger cups.
4. Select your desired drink from the one-touch digital screen (e.g., Single Cup Espresso, Double Cup Cappuccino, Single Cup Latte).
5. The machine will automatically brew the selected beverage.

Using the Frothing Wand:

- To create foamed milk for cappuccinos or lattes, ensure the milk reservoir is filled with milk.
- Adjust the Froth Control Knob to the right for more foam or to the left for less foam, according to your preference.
- Select a milk-based drink option from the digital screen. The machine will automatically froth and dispense milk.



Figure 3: The intuitive one-touch digital display for selecting various espresso, cappuccino, and latte options, along with a cleaning function.



Figure 4: Details of the double spout portafilter, the automatic milk frother with adjustable foam level, and the removable drip tray for easy cleaning.

Maintenance

Regular cleaning ensures optimal performance and longevity of your espresso machine.

Cleaning Schedule:

- **Daily:** After each use, clean the portafilter and ensure no coffee dregs remain on the seal ring. Wipe the exterior with a damp cloth.
- **Regularly:** Clean the removable drip tray and water reservoir. These components are designed for easy removal and washing.
- **Descaling:** Clean the internal boiler system every 80 brew cycles if using soft water, or every 40 brew cycles if using hard water. Refer to the descaling solution instructions for proper use.

Important Cleaning Notes:

- To prevent leaks, ensure coffee grounds are tamped correctly and do not exceed the maximum level of the filter.
- Always clean coffee dregs from the seal ring with a paper towel after each use.

Troubleshooting

This section addresses common issues you might encounter.

Problem	Possible Cause	Solution
Machine does not start or respond to touch screen.	Insufficient preheating time.	Allow the machine to preheat for approximately 5 minutes before pressing any buttons.
Espresso is lukewarm.	Machine not fully preheated or cup not pre-warmed.	Ensure the machine has fully preheated. Pre-warm your espresso cup with hot water before brewing.
Water leaks from the portafilter area.	Improperly tamped coffee grounds or dirty seal ring.	Ensure coffee grounds are tamped firmly and do not exceed the filter's max level. Clean any coffee dregs from the seal ring after each use.
Milk frother not producing enough foam.	Froth Control Knob setting or milk type.	Adjust the Froth Control Knob to increase foam. Ensure fresh, cold milk is used.

Specifications

- **Brand:** AICOOK
- **Model Number:** 7539774722
- **Capacity:** 1.8 liters (Water Reservoir)
- **Color:** Black
- **Special Feature:** Automatic Milk Frother
- **Coffee Maker Type:** Espresso Machine
- **Operation Mode:** Fully Automatic
- **Wattage:** 1350 watts
- **Voltage:** 120 volts
- **Human Interface Input:** Buttons (Digital Touch Screen)
- **Filter Type:** Reusable
- **UPC:** 748440118748

Warranty and Support

The AICOOK Espresso Machine comes with a 2-year replacement or repayment warranty for defective products. This warranty demonstrates our commitment to product quality.
For customer service inquiries or support, please contact our customer service team. Assistance is available 24 hours a day.
Energy Saver Feature: The espresso machine is designed to automatically stop brewing once the cycle is complete and will enter a "sleep state" after 25 minutes of inactivity to conserve energy.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question