Signature Design by Ashley D736-76

Signature Design by Ashley Tyler Creek Storage Display Cabinet D736-76 User Manual

Model: D736-76

Introduction Safety Information Assembly Operation Maintenance Troubleshooting Specifications Warranty & Support

1. Introduction

This manual provides essential instructions for the assembly, operation, and maintenance of your Signature Design by Ashley Tyler Creek Storage Display Cabinet, Model D736-76. Please read this manual thoroughly before assembly and use to ensure proper function and safety.





Figure 1: Front view of the Tyler Creek Storage Display Cabinet.

2. Safety Information

WARNING: Failure to follow these safety instructions could result in injury or damage to the product.

- Always follow the assembly instructions carefully.
- Ensure all hardware is securely tightened before use. Periodically check and re-tighten as necessary.
- This cabinet includes an anti-tipping kit. It is crucial to install this kit to prevent the cabinet from tipping over, especially in households with children or pets.
- Do not overload shelves or drawers. Distribute weight evenly.

- Keep small parts and packaging materials away from children.
- Do not stand or climb on the cabinet.

3. Assembly Instructions

Minor assembly is required for this product. It is recommended to have two people for assembly. Please ensure you have sufficient space and all components before beginning.

3.1 Package Contents

Before starting, verify that all parts and hardware listed in the included installation manual are present. If any parts are missing or damaged, do not proceed with assembly and contact customer support.

3.2 Assembly Steps Overview

1. Unpack all components and lay them out on a soft, clean surface to prevent scratches.
2. Follow the step-by-step diagrams in the detailedInstallation Manual (PDF).
3. Attach the side panels with the distinctive X-shaped lattice design to the shelves using the provided hardware.
4. Assemble the drawers, ensuring the smooth ball-bearing glides are correctly installed.
5. Secure the back panel to the assembled frame.
6. Install the anti-tipping kit to a wall stud for maximum stability.
7. Ensure all screws and fasteners are tightened, but do not overtighten.



Figure 2: Side view highlighting the X-shaped lattice design.



Figure 3: Detail of the storage drawers and open shelves.

4. Operating Instructions

The Tyler Creek Storage Display Cabinet is designed for versatile storage and display in various rooms.

4.1 Using the Shelves

The cabinet features three open shelves, ideal for displaying decorative items, books, or dinnerware. Ensure items are placed securely and weight is distributed to prevent instability.

4.2 Using the Drawers

Two floating drawers operate on smooth ball-bearing glides, providing concealed storage. The top drawer is lined, suitable for protecting delicate items like silverware. To open, gently pull the antiqued bronze-tone knob. To close, push until the drawer is fully seated.



Figure 4: Close-up of the smooth gliding drawers.

5. Maintenance and Care

Proper care will extend the life and appearance of your cabinet.

- **Cleaning:** For general cleaning, use a dry, soft cloth. Avoid abrasive cleaners or harsh chemicals that may damage the finish.
- **Spills:** Wipe spills immediately with a dry cloth.
- **Sunlight:** Avoid prolonged exposure to direct sunlight to prevent fading.
- **Humidity:** Maintain consistent humidity levels to prevent wood from warping or cracking.
- **Hardware:** Periodically check and tighten all hardware to ensure stability.

6. Troubleshooting

If you encounter any issues with your cabinet, refer to the following common solutions:

Problem	Possible Cause	Solution
Cabinet feels wobbly or unstable.	Loose hardware; uneven floor; anti-tipping kit not installed.	Ensure all screws are tightened. Place shims under legs if floor is uneven. Install the anti-tipping kit as per instructions.
Drawers do not slide smoothly.	Obstruction in glides; glides misaligned; drawer overloaded.	Check for any objects blocking the glides. Re-align glides if necessary. Reduce weight in the drawer.
Minor scratches or blemishes on finish.	Normal wear and tear; accidental damage.	Use a furniture touch-up pen or wax crayon matching the finish.

7. Specifications

Feature	Detail
Brand	Signature Design by Ashley
Model Number	D736-76

Feature	Detail
Color	Black
Material	Wood, Engineered Wood, and Veneers
Product Dimensions (D x W x H)	15.75"D x 28"W x 75"H
Item Weight	101 pounds
Number of Drawers	2
Number of Shelves	3
Additional Features	Anti-Tipping Kit Included
Mounting Type	Floor Mount
Style Name	Farmhouse

8. Warranty & Support

8.1 Manufacturer Warranty

For detailed information regarding the manufacturer's warranty, please refer to the product description on the store page or contact Signature Design by Ashley customer service directly.

8.2 Customer Support

If you require further assistance, have questions about assembly, or need to report missing/damaged parts, please contact Signature Design by Ashley customer support. You may also refer to the official User Manual (PDF) for additional information.

© 2026 Signature Design by Ashley. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question