Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Schleich 42408

Schleich Farm World Adventure Tree House Playset Instruction Manual

Model: 42408

1. Introduction

This manual provides detailed instructions for the assembly, operation, and maintenance of your Schleich Farm World Adventure Tree House playset. Please read these instructions carefully before use to ensure safe and enjoyable play. The Schleich Farm World Adventure Tree House is a 28-piece playset designed to inspire imaginative play for children aged 3 to 8 years. It features a multi-level tree house with various accessories and animal figures, creating a vibrant farm world environment.

2. Safety Information

WARNING: CHOKING HAZARD - Small parts. Not for children under 3 years.

- Always supervise children during play.
- Ensure all parts are securely assembled before play begins.
- Keep packaging materials away from children to prevent suffocation.
- This product is intended for indoor use.
- Regularly inspect the playset for any damage or loose parts. Discontinue use if damage is found.

3. Package Contents

Verify that all 28 pieces listed below are present in your package:



Figure 3.1: All 28 components of the Adventure Tree House playset.

- 1x Tree House structure
- 1x Blue Slide
- 1x Pulley system
- 1x Rope Ladder
- 1x Tire Swing
- 1x Green Ground Plate
- 1x Viewing Platform
- 1x Hedgehog Home
- 1x Birdhouse
- 1x Puppy figure (Beagle)
- 1x Squirrel figure
- 1x Boy figure
- 1x Girl figure

- 4x Railings
- 2x Chairs (tree stumps)
- 1x Storage Box
- 1x Sticker Sheet
- 1x Tray (for pulley)
- 1x Telescope
- 2x Cups
- 1x Hedgehog figure
- 1x Blue Bird figure
- 1x Instruction Manual (this document)

4. Assembly Instructions

Follow these steps to assemble your Adventure Tree House playset:

1. **Step 1: Base Assembly**
   Place the green ground plate on a flat, stable surface. Insert the main tree trunk into the designated slot on the ground plate until it clicks securely into place.
2. **Step 2: Tree House Structure**
   Attach the main tree house cabin to the tree trunk. Ensure the connection points align and snap firmly.
3. **Step 3: Platforms and Roof**
   Secure the various platforms around the tree trunk. Place the red roof onto the main cabin. Attach the smaller viewing platform to the upper branch.



Figure 4.1: The assembled Adventure Tree House.

4. **Step 4: Attach Accessories**
    - Connect the blue slide to the side of the tree house.
    - Hang the rope ladder from the main platform.
    - Attach the tire swing to the designated hook on a lower branch.
    - Install the pulley system on the upper branch, ensuring the tray can move freely.
    - Place the birdhouse and hedgehog home in their respective spots.
    - Position the railings around the platforms as desired.
5. **Step 5: Place Figures and Small Items**
   Arrange the boy and girl figures, puppy, squirrel, hedgehog, and blue bird. Place the telescope on the viewing platform, and the tree stump chairs and cups on the main platform.



Figure 4.2: Detail of the telescope and squirrel on the upper platform.

5. Operating Instructions (Play Features)

The Adventure Tree House offers various interactive elements for engaging play:

- **Slide:** Figures can slide down the blue slide from the main platform.
- **Rope Ladder:** Figures can "climb" up and down the rope ladder to access different levels.
- **Tire Swing:** Figures can be placed on the tire swing for dynamic play.
- **Pulley System:** Use the pulley to lift or lower the tray between the ground and the main platform, simulating transporting items.
- **Telescope:** The telescope on the viewing platform allows figures to "observe" the surroundings.
- **Figures and Animals:** The included boy, girl, puppy, squirrel, hedgehog, and bird figures can be positioned throughout the playset to create various scenarios.



Figure 5.1: Children engaging with the playset.

6. Care and Maintenance

- **Cleaning:** Wipe the playset and figures with a damp cloth. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** Store the playset in a cool, dry place away from direct sunlight to prevent material degradation.
- **Inspection:** Periodically check all connections and parts for wear or damage. Replace any broken parts immediately.

7. Specifications

Feature	Detail
Product Model	42408
Product Dimensions	4.13 x 15.75 x 13.58 inches
Item Weight	3.41 pounds
Recommended Age	36 months - 8 years
Number of Pieces	28
Manufacturer	Schleich

8. Warranty and Support

Schleich products are manufactured with high-quality standards. For information regarding warranty, returns, or customer support, please visit the official Schleich website or contact their customer service department directly.
You can find more information and contact details on theSchleich Brand Store on Amazon.

© 2024 Schleich. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B079NH9LDV

More documents and user manuals: **https://manuals.plus/**