Cuisinart CSB-179P1

Cuisinart CSB-179 Smart Stick Variable Speed Hand Blender User Manual

Model: CSB-179P1

Introduction

The Cuisinart CSB-179 Smart Stick Variable Speed Hand Blender is a versatile and durable kitchen essential designed to meet the demands of modern home chefs. Featuring a powerful yet quiet 300-watt DC motor, this hand blender offers variable speed control, allowing you to switch seamlessly from low to high speeds for various tasks.
Its long stainless steel blending shaft is ideal for reaching deep into bowls, pots, and pitchers. The included attachments—a mixing/measuring cup, chopper/grinder, and chef's whisk—expand its functionality, making quick work of pureeing soups, emulsifying mayonnaise, whipping meringues, and more, consistently delivering chef-caliber results.

Product Components

The Cuisinart CSB-179 Smart Stick Variable Speed Hand Blender comes with several key components designed for versatile kitchen tasks:

- Main Motor Body
- 8-inch Stainless Steel Blending Shaft
- 3-cup Chopper/Grinder Attachment
- Chef's Whisk Attachment
- Deluxe Mixing/Measuring Cup



The Cuisinart Smart Stick Hand Blender with its complete set of accessories.

Setup

Before using your Cuisinart Smart Stick Hand Blender for the first time, please follow these steps:

1. **Initial Cleaning:** Wash all detachable parts (blending shaft, chopper/grinder bowl, whisk, and measuring cup) in warm, soapy water. Rinse thoroughly and dry completely. The main motor body should be wiped clean with a damp cloth. Do not immerse the motor body in water.
2. **Assembly:** Ensure the unit is unplugged from the power outlet. To attach the blending shaft or any other accessory, align it with the motor body and twist until it clicks securely into place. To detach, press the release buttons on the side of the motor body and pull the attachment off.



Proper assembly of the blending shaft to the motor body.

Operating Instructions

The Cuisinart Smart Stick Hand Blender offers intuitive controls for various food preparation tasks:

- **Power On/Off and Pulse:** The main control features a push-button for continuous operation. For pulse action, repeatedly press and release the button.
- **Variable Speed Control:** Adjust the blending speed from low to high using the slide control located on the handle. This allows for precise control over your blending consistency.
- **Lock/Unlock Button:** For safety, the blender is equipped with a lock/unlock button. This must be pressed to unlock the unit before the power button will operate.
- **Using the Blending Shaft:** Ideal for pureeing soups directly in the pot, blending smoothies in the measuring cup, or emulsifying sauces. Insert the blending shaft into your ingredients, ensuring the blade guard is fully submerged before activating.
- **Using the Chopper/Grinder Attachment:** Attach the motor body to the chopper/grinder bowl. This attachment is perfect for chopping nuts, vegetables, herbs, and grinding spices.
- **Using the Chef's Whisk Attachment:** Connect the whisk to the motor body. Use it for whipping cream, beating eggs, or preparing light batters and meringues.



The Smart Stick offers 6 versatile functions for various food preparation tasks.



Key features and controls of the Cuisinart Smart Stick Hand Blender.

Maintenance and Cleaning

Proper maintenance ensures the longevity and performance of your hand blender:

- **Motor Body:** Always unplug the unit before cleaning. Wipe the motor body and gearbox with a damp cloth or sponge. Never immerse the motor body in water or any other liquid.
- **Blending Shaft:** The stainless steel blending shaft can be washed in hot water by hand using mild detergent.
- **Chopper/Grinder Bowl, Whisk, and Measuring Cup:** These attachments are dishwasher safe. For best results and to prevent damage, place them on the top rack of your dishwasher.
- **Storage:** Ensure all parts are completely dry before storing. Store the blender and its attachments in a clean, dry

place.

Troubleshooting

If your Cuisinart Smart Stick Hand Blender is not operating as expected, please review the following common issues:

- **Unit Not Turning On:** Ensure the unit is properly plugged into a working electrical outlet. Verify that both the lock/unlock button and the power button are pressed simultaneously to activate the blender.
- **Attachments Not Engaging:** Check that the blending shaft or desired attachment is securely twisted and clicked into place on the motor body.
- **Motor Overheating:** If the motor feels hot or stops working, unplug the unit immediately and allow it to cool down for at least 15-20 minutes before attempting to use it again. Avoid continuous operation for extended periods.
- **Ineffective Blending/Chopping:** Ensure that ingredients are cut into appropriate sizes for the attachment being used. Do not overfill the chopper bowl or blending cup. For thicker mixtures, add a small amount of liquid to aid blending.

For persistent issues, refer to the full user manual or contact Cuisinart customer support.

Specifications

Feature	Detail
Brand	Cuisinart
Model Number	CSB-179P1
Color	Stainless Steel
Power Source	DC Motor (300 Watts)
Number of Speeds	Variable Speed
Blending Shaft Length	8 inches
Material	Stainless Steel (Blade & Shaft)
Product Dimensions	2.25"D x 2.25"W x 15.5"H
Item Weight	3.3 pounds
BPA Free	Yes

Warranty and Support

The Cuisinart CSB-179 Smart Stick Variable Speed Hand Blender comes with a**Limited 3-Year Warranty**. Please refer to the official user manual for complete details regarding warranty policies and troubleshooting steps.
For further assistance or to download the full instruction manual, you can visit the official Cuisinart website or access the PDF directly via this link: Cuisinart CSB-179 User Manual (PDF)

© 2023 Cuisinart. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question