Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ZdalaMit 43223-5376

ZdalaMit AKB73756502 Replacement Remote Control User Manual

For LG LA64 Series and LA62 Series LED TVs

Introduction

This manual provides instructions for the setup, operation, and maintenance of your ZdalaMit AKB73756502 replacement remote control. This remote is designed to be compatible with various LG LA64 Series and LA62 Series LED TV models. Compatible LG TV models include: 47LA641V, 42LA641V, 47LA640V, 55LA640V, 32LA620V, 42LA620V, 47LA620V, 50LA620V, 55LA620V, 60LA620V, 32LA620S, 42LA620S, 47LA620S, 42LA640S, 55LA620S, 47LA6208, 55LA6208, 55LA6408, and replaces original remotes like AKB73756567, AKB73756542, AKB73615315, AKB73615316, AKB73655806.

Setup

The ZdalaMit AKB73756502 replacement remote control requires no programming or pairing. Simply insert batteries, and it is ready for use.

Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or press the latch and lift to open.
3. Insert two (2) 1.5V AAA alkaline batteries, ensuring the positive (+) and negative (-) terminals match the diagrams inside the compartment.
4. Close the battery compartment cover securely.



Figure 1: Battery compartment with AAA batteries.

Note: Batteries are not included with the remote control and must be purchased separately.

Operating Instructions

This remote control functions identically to the original LG remote it replaces. Point the remote directly at your LG LED TV for optimal performance.

Key Functions Overview



Figure 2: Front view of the remote control.

- **Power Button (●):** Turns the TV on or off.
- **Number Buttons (0-9):** Selects channels directly.
- **Volume Up/Down (+/-):** Adjusts the TV volume.
- **Channel Up/Down (P▲/P▼):** Changes TV channels sequentially.
- **Mute:** Silences or restores TV audio.
- **Input:** Selects video input sources (HDMI, AV, etc.).
- **Smart/Home:** Accesses the TV's Smart features or Home menu.
- **Navigation Pad (Up, Down, Left, Right, OK):** Navigates menus and confirms selections.
- **Back/Exit:** Returns to the previous menu or exits the current menu.
- **Guide:** Displays the electronic program guide.

- **Color Buttons (Red, Green, Yellow, Blue):** Functions vary depending on the TV menu or application.
- **Text/T.OPT:** Accesses Teletext or TV options.
- **Subtitle:** Toggles subtitles on or off.
- **Media Playback Controls (Play, Pause, Stop, Rewind, Fast Forward, Record):** Controls media playback.
- **Settings:** Opens the TV's settings menu.

Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the remote control. Do not use liquid cleaners or abrasive materials.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries at the same time with new ones.
- **Storage:** If the remote control will not be used for an extended period, remove the batteries to prevent leakage and damage.
- **Avoid Damage:** Do not drop the remote control or expose it to extreme temperatures, humidity, or direct sunlight.

Troubleshooting

Problem	Possible Cause	Solution
Remote not working.	Dead or incorrectly installed batteries.	Replace batteries with new 1.5V AAA alkaline batteries, ensuring correct polarity.
Remote has limited range or intermittent response.	Weak batteries; Obstruction between remote and TV; Remote sensor on TV is blocked.	Replace batteries. Ensure a clear line of sight to the TV's IR sensor. Remove any obstructions.
Specific buttons not responding.	Button malfunction; Remote damage.	Check if other buttons work. If only specific buttons fail, the remote may be damaged. Consider replacing the remote.
Remote works but TV does not respond.	TV is off or unplugged; TV's IR sensor is faulty.	Ensure TV is powered on. Test with another remote if available. Consult your TV's manual for troubleshooting its IR sensor.

Specifications

- **Model Number:** 43223-5376 (AKB73756502)
- **Brand:** ZdalaMit
- **Power Supply:** 2 x 1.5V AAA Alkaline Batteries (not included)
- **Compatible Devices:** LG LA64 Series, LA62 Series LED TVs
- **Dimensions:** Approximately 9 x 2 x 0.5 inches
- **Item Weight:** Approximately 3.2 ounces (without batteries)
- **Special Feature:** Pre-programmed, no setup required

Warranty and Support

For any queries or support regarding your ZdalaMit AKB73756502 replacement remote control, please contact the seller or manufacturer directly. Information regarding specific warranty terms may be available from your point of purchase.

The manufacturer is ZdalaMit Factory.

© 2023 ZdalaMit. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B079PZHNMT

More documents and user manuals: **https://manuals.plus/**