ZdalaMit RM-X151

ZdalaMit RM-X151 Replacement Remote Control User Manual

For Sony CD Player Radio Stereo Models

Introduction

This manual provides instructions for the ZdalaMit RM-X151 replacement remote control. This remote is designed to function with various Sony CD Player Radio Stereo models without requiring any programming or pairing. Please refer to the compatibility list to ensure your device is supported.

Setup

1. Battery Installation

The RM-X151 remote control requires **one (1) AAA battery** for operation. To install the battery:

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch to open it.
3. Insert one AAA battery, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover until it clicks securely into place.

Note: Ensure the battery is inserted with the correct polarity to prevent damage to the remote control.

2. Compatibility

This replacement remote control is compatible with the following Sony CD Player Radio Stereo models:

- CDX-GT200
- CDX-GT20W
- CDX-GT400
- CDX-GT300
- CDX-GT350S
- CDM8910
- CDX-GT520
- CDX-GT52W
- CDX-GT340

- CDX-GT240
- CDX-GT33W
- CDX-GT34W
- CDX-S2210S
- CDX-GT55UIW
- CDX-GT550UI
- CDX-GT600UI

No programming or pairing is required for these models. Simply insert the battery and the remote is ready for use.

Operating Instructions

The ZdalaMit RM-X151 remote control features a standard layout for intuitive operation of your compatible Sony CD Player Radio Stereo. Below is a description of the main buttons and their functions.



Image: ZdalaMit RM-X151 Replacement Remote Control. This image displays the full layout of the remote control, showing all buttons and their labels. The remote is black with grey and white buttons.

- **OFF:** Powers off the connected Sony CD Player Radio Stereo unit.
- **ATT (Attenuate):** Mutes or significantly reduces the audio volume. Press again to restore previous volume.
- **SOURCE:** Cycles through available audio sources (e.g., CD, Radio, AUX).
- **SEL (Select):** Used to select menu options or confirm settings.
- **MODE:** Changes the operating mode of the unit (e.g., Radio bands, CD playback modes).
- **Directional Pad (Up, Down, Left, Right arrows) and Center Button:**
  - **Up/Down Arrows:** Navigate through menus, radio presets, or tracks.
  - **Left/Right Arrows (Rewind/Fast Forward):** Skips tracks or fast forwards/rewinds within a track during CD playback.
  - **Center Button:** Play/Pause or confirm selection.
- **DSPL (Display):** Changes the information shown on the unit's display.
- **SCRL (Scroll):** Scrolls through text or lists on the display.
- **Number Buttons (1-6):** Used for direct track selection on CD or preset station selection on radio.
- **VOL (+ / -):** Adjusts the master volume level of the audio output. Press '+' to increase volume, '-' to decrease volume.

Maintenance

Proper maintenance ensures the longevity and optimal performance of your remote control.

- **Cleaning:** Wipe the remote control with a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water or a mild cleaning solution, then wipe dry immediately. Avoid using abrasive cleaners or solvents.
- **Battery Care:**
  - Replace batteries when the remote's response becomes sluggish or inconsistent.
  - Remove batteries if the remote control will not be used for an extended period to prevent battery leakage.
  - Dispose of used batteries according to local regulations.
- **Storage:** Store the remote control in a cool, dry place away from direct sunlight and extreme temperatures.
- **Avoid Drops:** Protect the remote from physical impact, as drops can damage internal components.

Troubleshooting

If you experience issues with your ZdalaMit RM-X151 remote control, please refer to the following common solutions:

Problem	Possible Cause / Solution
Remote control is not working.	• **Batteries:** Check if the batteries are inserted correctly with the correct polarity (+/-). Replace with fresh AAA batteries. • **Line of Sight:** Ensure there is a clear line of sight between the remote control and the infrared receiver on your Sony unit. Obstructions can block the signal. • **Distance:** You may be too far from the unit. Move closer to the Sony CD Player Radio Stereo.
Remote control works intermittently.	• **Low Batteries:** Batteries may be running low. Replace them. • **Interference:** Strong light sources (e.g., direct sunlight, fluorescent lights) can interfere with the infrared signal. Try operating the remote in a different environment.
Certain buttons do not respond.	• **Compatibility:** While this remote is broadly compatible, some specific functions might not be supported by all Sony models. Verify your unit's original remote functions. • **Physical Damage:** Inspect the button for any physical damage or debris that might be preventing it from pressing correctly.
Remote listed as compatible but does not work.	• **Double-check Model:** Carefully verify that your Sony CD Player Radio Stereo model number exactly matches one of the listed compatible models. • **Unit's IR Receiver:** Ensure the infrared receiver on your Sony unit is not obstructed or damaged. • **Contact Support:** If all troubleshooting steps fail, please contact customer support for further assistance.

Specifications

- **Model:** RM-X151
- **Brand:** ZdalaMit
- **Power Source:** 1 x AAA Battery (not always included, but required)
- **Color:** Black
- **Special Feature:** Pre-Programmed (No setup required for compatible models)
- **Max Number of Supported Devices:** 1 (Controls one Sony CD Player Radio Stereo unit)

- **Compatible Devices:** Sony CD Player Radio Stereo units (specific models listed in Compatibility section)
- **Product Dimensions:** Approximately 4 x 2 x 0.5 inches
- **Item Weight:** Approximately 1.06 ounces
- **Manufacturer:** ZdalaMit Factory
- **Date First Available:** February 9, 2018

Support

For any queries or further assistance regarding your ZdalaMit RM-X151 replacement remote control, please contact the seller or manufacturer's customer support. While a specific warranty period is not detailed, general product support is available for troubleshooting and inquiries.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question