Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

USHA 3720

Usha 3720 700-Watt 2-Slice Pop-up Toaster Instruction Manual

Model: 3720

Introduction

Thank you for purchasing the Usha 3720 700-Watt 2-Slice Pop-up Toaster. This manual provides important information regarding the safe operation, maintenance, and care of your new appliance. Please read these instructions thoroughly before first use and retain them for future reference.

Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed, including the following:

- Read all instructions before operating the toaster.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or toaster in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Do not use the toaster for other than intended use.
- Oversize foods, metal foil packages, or utensils must not be inserted in a toaster as they may create a fire or risk of electric shock.
- A fire may occur if toasters are covered or touching flammable material, including curtains, draperies, walls, and the like, when in operation.
- Do not attempt to dislodge food when the toaster is plugged in.
- Do not operate the toaster unattended.

Product Overview

Familiarize yourself with the components of your Usha 3720 Pop-up Toaster.



Figure 1: Front-side view of the Usha 3720 Toaster, showing the two toasting slots, browning control dial, and lever.

- **Toasting Slots:** Two slots for inserting bread slices.
- **Browning Control Dial:** Adjusts the desired level of toast browning from 1 (lightest) to 7 (darkest).
- **Cancel Button:** Stops the toasting cycle at any time.
- **Toasting Lever:** Lowers the bread into the toaster and initiates the toasting cycle. Also functions as a high-lift lever.
- **Crumb Tray:** Collects crumbs for easy cleaning. Located at the bottom of the toaster.



Figure 2: Close-up view of the Usha 3720 Toaster with the crumb tray partially pulled out for cleaning.

Setup

1. **Unpacking:** Carefully remove the toaster and all packaging materials. Ensure all components are present.
2. **Placement:** Place the toaster on a stable, flat, heat-resistant surface, away from flammable materials like curtains. Ensure adequate ventilation around the appliance.
3. **First Use:** Before toasting bread for the first time, operate the toaster without bread in a well-ventilated area. Set the browning control to a medium setting (e.g., 3 or 4) and run two to three toasting cycles. This will burn off any manufacturing residues and eliminate initial odors.

Operating Instructions

1. **Plug In:** Connect the power cord to a suitable 240V AC electrical outlet.
2. **Insert Bread:** Place one slice of bread into each toasting slot. Ensure the slices are not too thick or irregularly shaped, as this may cause them to get stuck.
3. **Select Browning Level:** Turn the browning control dial to your desired setting. Setting 1 is for light toast, and Setting 7 is for dark toast. A medium setting (3-4) is recommended for most bread types.
4. **Start Toasting:** Press the toasting lever down until it locks into place. The toasting cycle will begin, and the indicator light (if present) will illuminate.
5. **Cancel Function:** To stop the toasting cycle at any time, press the "Cancel" button. The bread will automatically pop up.
6. **Retrieve Toast:** Once the toasting cycle is complete, the toast will automatically pop up. The toaster features a higher lift function for smaller bread slices, allowing for easier and safer removal.

Maintenance and Cleaning

Regular cleaning ensures optimal performance and extends the life of your toaster.

1. **Unplug and Cool:** Always unplug the toaster from the power outlet and allow it to cool completely before cleaning.
2. **Empty Crumb Tray:** Pull out the crumb tray located at the bottom of the toaster. Dispose of the crumbs and wipe the tray clean with a damp cloth. Ensure the tray is completely dry before reinserting it.
3. **Clean Exterior:** Wipe the exterior of the toaster with a soft, damp cloth. Do not use abrasive cleaners or metal scouring pads, as they may scratch the surface.
4. **Internal Cleaning:** Never insert metal objects into the toasting slots to clean them. If bread gets stuck, unplug the toaster and carefully remove the bread after it has cooled.
5. **Do Not Immerse:** Never immerse the toaster, cord, or plug in water or any other liquid.

Troubleshooting

Problem	Possible Cause	Solution
Toaster does not turn on.	Not plugged in; power outage; faulty outlet.	Ensure the toaster is securely plugged into a working outlet. Check your household's circuit breaker.
Bread does not toast evenly.	Uneven bread thickness; first use residue; internal element issue.	Ensure bread slices are of uniform thickness. Run a few empty cycles for initial use. If problem persists, contact customer support.
Bread is stuck in the toaster.	Oversized bread; foreign object.	Unplug the toaster and allow it to cool. Carefully remove the bread using non-metallic tongs. Do not force the bread.
Smoke coming from toaster.	Crumbs accumulated; food stuck; first use residue.	Immediately press the Cancel button and unplug. Allow to cool. Clean the crumb tray thoroughly. Remove any stuck food. If it's the first use, some smoke is normal.

Specifications

- **Model:** Usha 3720
- **Power:** 700 Watts
- **Voltage:** 240 Volts
- **Slot Count:** 2
- **Browning Settings:** 7
- **Material:** Plastic
- **Product Dimensions (D x W x H):** 12.5 x 19 x 16 Centimeters
- **Item Weight:** 1167 Grams
- **Special Features:** Higher Lift for Smaller Bread Slices, Removable Crumb Tray
- **Manufacturer:** Usha International Ltd

Warranty and Support

Your Usha 3720 Pop-up Toaster comes with a warranty. Please refer to the warranty card included in the product packaging for specific terms, conditions, and duration of the warranty.

For technical assistance, service, or to inquire about spare parts, please contact Usha customer support:

- **Manufacturer:** Usha International Ltd
- **Contact Information:** Usha International LTD. Plot No. 15, Institutional Area, Sector 32, Gurugram 122 001, Haryana (India), Tel +91-124-4583100. Registered Office: Surya Kiran Building 19, Kasturba Gandhi Marg, New Delhi (India) 110 006.
- **Website:** Please visit the official Usha website for the most up-to-date support information.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B079RKGF6J

More documents and user manuals: **https://manuals.plus/**