JVC LT-32VF43I 32" FullHD S2

JVC LT-32VF43I Standard TV FullHD 32" User Manual

Model: LT-32VF43I 32" FullHD S2

1. Introduction

This user manual provides comprehensive instructions for the safe and efficient operation of your JVC LT-32VF43I 32" Full HD TV. Please read this manual thoroughly before using the product and retain it for future reference.

2. Safety Information

Always adhere to the following safety precautions to prevent electric shock, fire, or damage to the unit:

- Do not expose the TV to rain or moisture.
- Do not open the cabinet. Refer servicing to qualified personnel only.
- Ensure proper ventilation. Do not block ventilation openings.
- Protect the power cord from being walked on or pinched.
- Unplug the TV during lightning storms or when unused for long periods.
- Do not place heavy objects on top of the TV.
- Avoid placing the TV in direct sunlight or near heat sources.

3. Package Contents

Upon opening the package, verify that all the following items are included:

- JVC LT-32VF43I 32" Full HD TV Unit
- Remote Control
- User Manual (this document)
- Power Cord
- TV Stand Components (if applicable)

Note: The product description mentions "Manuale istruzioni, Telecomando" (Instruction manual, Remote control) as components included.

4. Product Overview

Familiarize yourself with the main components and connections of your JVC TV.

4.1 Front View



Figure 4.1: Front view of the JVC LT-32VF43I television, showing the screen and the JVC logo at the bottom center.

4.2 Side View





Figure 4.2: Side profile of the JVC LT-32VF43I TV, illustrating its depth and the power cable connection.

4.3 Rear Connections



Figure 4.3: Close-up of the rear panel connections, including HDMI, USB, SCART, VGA, and antenna inputs.

- **HDMI Ports (x2):** For connecting high-definition devices like Blu-ray players, game consoles, or set-top boxes.

- **USB Port (x1):** For connecting USB storage devices to play media files.
- **SCART Port (x1):** For connecting older analog devices.
- **PC VGA Input:** For connecting a computer.
- **Digital Audio Output (Optical):** For connecting to external audio systems.
- **Headphone Output:** For connecting headphones.
- **Antenna Input:** For connecting a terrestrial or satellite antenna.
- **Common Interface (CI+) Slot:** For inserting a CAM module for pay TV services.

4.4 Remote Control



Figure 4.4: The remote control for the JVC TV, featuring various buttons for power, channel, volume, menu navigation, and media playback.

The remote control allows you to operate all functions of your TV. Insert two AAA batteries (not included) into the battery compartment, ensuring correct polarity.

5. Setup

5.1 Attaching the Stand

To attach the stand to your JVC TV:

1. Carefully place the TV face down on a soft, clean surface to prevent screen damage.
2. Align the stand with the mounting holes on the bottom of the TV.
3. Secure the stand using the provided screws. Ensure they are tightened firmly.



Figure 5.1: Detail of the TV stand attached to the bottom of the JVC television unit.

5.2 Initial Power On and Channel Scan

After connecting the power cord and antenna:

1. Plug the TV into a power outlet.
2. Press the power button on the remote control or on the TV.
3. Follow the on-screen instructions to select your language, country, and perform an automatic channel scan for DVB-T2/C/S2 signals. The TV supports MPEG-4, HEVC, and H.265 standards.
4. The TV features automatic channel reordering.

6. Operating

6.1 Basic Operations

- **Power On/Off:** Press the **Power** button on the remote.
- **Channel Selection:** Use the **CH+/-** buttons or number buttons.
- **Volume Adjustment:** Use the **VOL+/-** buttons.
- **Mute:** Press the **Mute** button to temporarily turn off sound.
- **Source Selection:** Press the **Source** button to switch between HDMI, AV, PC, USB, and TV inputs.

6.2 Media Playback via USB

The TV includes a Media Player function via its USB 2.0 port.

1. Insert a USB storage device into the USB port on the TV.
2. Select the USB source from the input menu.
3. Navigate through your files (photos, music, videos) using the remote control and select the desired content to play.

6.3 Menu Navigation

Press the **MENU** button on the remote control to access the main menu. Use the arrow keys to navigate and **OK** to confirm selections.

- **Picture Settings:** Adjust brightness, contrast, color, and picture mode.
- **Sound Settings:** Adjust volume, sound mode, and use the built-in equalizer. Audio power is 2 x 6W RMS (10% THD).
- **Channel Settings:** Perform channel scans, edit channels, and manage favorite lists. The TV can store 200 analog channels and 800 digital/10000 satellite channels.
- **Time Settings:** Set the current time and configure the Sleep Timer function.
- **Parental Lock:** Set up a parental lock to restrict access to certain channels or programs.
- **Hotel Function:** This feature is available for hotel environments.

6.4 Teletext (Fast Text)

The TV supports Teletext with 1000 pages. Press the **TEXT** button on the remote control to access Teletext services.

7. Maintenance

- **Cleaning the Screen:** Use a soft, lint-free cloth specifically designed for electronics. Do not use abrasive cleaners or solvents.
- **Cleaning the Cabinet:** Wipe the TV cabinet with a soft, dry cloth.
- **Ventilation:** Ensure the ventilation openings are not blocked by dust or objects.
- **Power Cord:** Regularly check the power cord for any damage.

8. Troubleshooting

Problem	Possible Cause	Solution
No power	Power cord not connected; no power from outlet.	Check power cord connection; test outlet with another device.
No picture, but sound is present	Incorrect input source selected; antenna/cable not connected.	Press the **Source** button to select correct input; check antenna/cable connection.
No sound, but picture is present	Volume is too low or muted; external audio system issues.	Increase volume; press **Mute** button; check external audio connections.
Remote control not working	Batteries are dead or inserted incorrectly; obstacle between remote and TV.	Replace batteries; ensure correct polarity; remove obstacles; point remote directly at TV sensor.
Poor picture quality	Weak signal; incorrect picture settings.	Check antenna/cable connection; adjust picture settings in the menu.

If the problem persists after trying these solutions, please contact JVC customer support.

9. Specifications

Feature	Description
Screen Size	32 inches (81 cm)
Resolution	1920 x 1080 (Full HD)
Aspect Ratio	16:9
Backlight Type	Direct LED
Brightness	300 cd/m²
Dynamic Contrast	100,000:1
Viewing Angle	178° (V) / 178° (H)
Response Time	8 ms
HDMI Ports	2 (Version 1.4)
USB Ports	1 (Version 2.0)
Tuner Type	DVB-T2/C/S2 MPEG-4 - HEVC - H.265
CI/CI+ Slot	Yes (HD compatible)
Video Filter	3D Comb Filter
SCART Port	1
Composite Video Input	Yes
PC VGA Input	Yes (Sub D-15 pin)
PC Audio Input	Via side AV
Digital Audio Output	Optical
Headphone Output	Yes (Controllable by remote)
Audio System	Stereo with Equalizer
Audio Power	2 x 6W RMS (10% THD)
Teletext	Fast Text - 1000 pages
Analog Channel Memory	200 channels
Digital/Satellite Channel Memory	800 / 10000 channels
Sleep Timer	Yes
Parental Lock	Yes
Hotel Function	Yes
Dimensions (with stand)	Approx. 92 x 58 x 15.5 cm (Package dimensions)
Weight	Approx. 6.55 kg

10. Warranty and Support

For warranty information and technical support, please refer to the warranty card included with your product or visit the official JVC website. Keep your purchase receipt as proof of purchase.

Manufacturer: Vestel

Model Number: LT-32VF43I 32" FullHD S2

First Available: April 14, 2020