PINOLINO 201614

Pinolino Nicki Children's Seat for 4, Grey

Model: 201614 | Brand: PINOLINO

Introduction

This manual provides essential information for the safe assembly, operation, and maintenance of your Pinolino Nicki Children's Seat for 4. Please read these instructions carefully before use and retain them for future reference.

Image: The Pinolino Nicki Children's Seat for 4 in grey, featuring a table and two attached benches.

Safety Information

WARNING: Failure to follow these safety instructions may result in serious injury.

- **Wall Anchoring:** To prevent tipping, securely fasten the furniture to a solid wall using appropriate wall anchors. Wall anchoring hardware may not be included and should be selected based on your wall type.
- **Adult Supervision:** This product is intended for children aged 2 to 7 years. Always ensure children are supervised by an adult when using the seat and table.
- **Stable Surface:** Place the children's seat on a flat, stable, and level surface to prevent wobbling or accidental tipping.
- **Weight Limits:** Do not exceed the recommended weight capacity for each bench. (Specific weight capacity not provided; refer to product label if available).
- **No Standing:** Instruct children not to stand on the table or benches.
- **Regular Checks:** Periodically inspect all components for wear, damage, or loose fasteners. Tighten screws and bolts as needed.
- **Keep Clear:** Ensure the area around the seat is clear of obstacles to prevent tripping hazards.

Package Contents

Before beginning assembly, verify that all components listed below are present and undamaged. If any parts are missing or damaged, do not proceed with assembly and contact customer support.

- Tabletop section
- Bench seat sections (2)
- Leg frames / Support beams
- Assembly hardware (screws, bolts, washers, Allen key)

Setup and Assembly

Assembly requires two adults. Please follow these steps carefully.

1. Unpack all components and lay them out on a clean, soft surface to prevent scratches.
2. Attach the leg frames to the underside of the tabletop using the provided screws and Allen key. Ensure all connections are secure but do not overtighten initially.
3. Connect the bench seat sections to the leg frames. Align the pre-drilled holes and secure with the remaining screws and bolts.
4. Once all components are loosely assembled, place the unit upright and gently rock it to ensure it sits evenly. Then, fully tighten all screws and bolts.
5. Perform a final check to ensure all connections are tight and the seat is stable.

Image: A diagram illustrating the dimensions of the assembled children's seat: 90 cm length, 79 cm width, 50 cm height, and 28 cm seat height.

Image: A close-up view highlighting the solid wood construction and indicating space for up to four children. It also shows the grey and natural wood finish.

Operating Instructions (Usage)

- The Pinolino Nicki Children's Seat is designed for both indoor and outdoor use.
- Ensure the seat is placed on a stable, level surface to prevent accidental tipping.
- Always supervise children when they are using the seat and table.
- This product is suitable for children aged 2 to 7 years.

Image: Three children seated at the Pinolino Nicki Children's Seat outdoors, engaged in drawing and playing.

Maintenance

- **Cleaning:** Wipe the surfaces with a damp cloth. Avoid using abrasive cleaners or harsh chemicals, as these can damage the wood finish.
- **Fastener Checks:** Regularly check all screws and bolts for tightness. Retighten as necessary to maintain stability and safety.
- **Outdoor Use:** If used outdoors, protect the wood from prolonged exposure to direct sunlight and heavy rain. Consider applying a child-safe weather-protective finish periodically to extend the product's lifespan.
- **Storage:** When not in use for extended periods, especially during harsh weather, store the seat in a dry, sheltered area.

Troubleshooting

- **Wobbling or Instability:**

Solution: Ensure the seat is placed on a completely flat and level surface. Check all assembly screws and bolts and tighten them firmly.

- **Minor Scratches or Dents:**
  Solution: For minor surface imperfections, gently sand the affected area with fine-grit sandpaper and, if desired, apply a child-safe wood touch-up paint or sealant that matches the original finish.
- **Wood Splintering:**
  Solution: If small splinters appear, carefully sand the area smooth to prevent injury. Consider applying a clear, child-safe wood sealant.

Specifications

Model Number	201614
Dimensions (L x W x H)	90 x 79 x 50 cm
Seat Height	28 cm
Material	Solid Spruce Wood
Color	Grey
Product Weight	7 Kilograms
Recommended Age	2 to 7 years
Assembly Required	Yes

Warranty Information

This Pinolino product is covered by a standard manufacturer's warranty. For detailed information regarding warranty terms, duration, and conditions, please refer to the warranty card included with your purchase or visit the official Pinolino website. Please retain your proof of purchase for any warranty claims.

Support

Should you require assistance with assembly, have questions about product use, or need to report a missing or damaged part, please contact Pinolino customer service. You can typically find contact information on the Pinolino official website (www.pinolino.de) or through the retailer from whom you purchased the product.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question