Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

KitVision KSDIGGIT

Kitsound Diggit Outdoor Freestanding Bluetooth Garden Speaker User Manual

Model: KSDIGGIT | Brand: KitVision (Manufactured by KitSound)

Introduction

The Kitsound Diggit is a versatile outdoor Bluetooth speaker designed to deliver immersive 360-degree audio. Its robust, weather-resistant construction and unique removable stake make it ideal for various outdoor environments, from gardens to beaches. Enjoy extended playtime and easy connectivity with your Bluetooth-enabled devices.



Image: The Kitsound Diggit speaker, featuring a wood-look top and bottom with a grey fabric-covered body.

What's in the Box

- Kitsound Diggit Speaker
- USB Charging Cable
- User Manual (this document)
- Removable Ground Stake

Setup

1. Charging the Speaker

Before first use, fully charge your Kitsound Diggit speaker. Connect the supplied USB cable to the DC IN port on the

speaker and plug the other end into a compatible USB power source (e.g., computer USB port, USB wall adapter). The LED indicator will show charging status.

2. Powering On/Off

Press and hold the Power button (usually marked with a power symbol) located on the top panel of the speaker to turn it on or off. A sound prompt will indicate power status.

3. Bluetooth Pairing

1. Ensure the speaker is powered on and in pairing mode (indicated by a flashing LED).
2. On your Bluetooth-enabled device (smartphone, tablet, laptop), go to the Bluetooth settings.
3. Search for available devices and select "Kitsound Diggit" from the list.
4. Once connected, the LED indicator will become solid, and a sound prompt will confirm successful pairing.

4. Using the Removable Stake

For outdoor use, the Kitsound Diggit comes with a removable ground stake. Insert the stake firmly into the ground in your desired location. Then, attach the speaker to the top of the stake by aligning the bottom opening of the speaker with the stake and pushing down until secure. This elevates the speaker for optimal 360-degree audio dispersion.

Your browser does not support the video tag.

Video: Demonstrates the Kitsound Diggit speaker being used with its removable ground stake for outdoor placement.

Operating the Speaker

Controls

The top panel of the speaker features intuitive controls:

- **Power Button:** Press and hold to turn on/off.
- **Volume Up (+):** Increase playback volume.
- **Volume Down (-):** Decrease playback volume.
- **Play/Pause/Call Button:** Press to play/pause music. Press to answer/end calls.
- **Bluetooth Pairing Button:** Press to enter Bluetooth pairing mode.

360-Degree Audio

The Kitsound Diggit is engineered with dual-opposing 5W drivers to provide immersive 360-degree audio, ensuring consistent sound quality regardless of your position relative to the speaker.

Multi-Speaker Connectivity

For an enhanced audio experience, you can connect multiple Kitsound Diggit speakers together to create a wider soundstage. Refer to the specific pairing instructions for multi-speaker mode in the full manual (if applicable, as this feature is highlighted in a video but not detailed in text specs).

LED Light Ring

The speaker features an integrated LED light ring that adds an attractive visual element, particularly useful for evening outdoor use.

Maintenance

Weather Resistance

The Kitsound Diggit speaker boasts an IP55 rating, making it resistant to water jets and dust. While it can withstand splashes and light rain, it is not designed for submersion in water. Always ensure the charging port cover is securely closed when exposed to moisture.

Cleaning

To clean the speaker, use a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these may damage the finish or internal components.

Troubleshooting

- **No Power:** Ensure the speaker is fully charged. Connect the USB cable and allow it to charge for at least 30 minutes before attempting to power on again.
- **Cannot Pair Bluetooth:**
  - Ensure the speaker is in pairing mode (flashing LED).
  - Make sure Bluetooth is enabled on your device.
  - Move the speaker closer to your device.
  - Forget "Kitsound Diggit" from your device's Bluetooth list and try pairing again.
  - Restart both the speaker and your Bluetooth device.
- **No Sound:**
  - Check the volume levels on both the speaker and your connected device.
  - Ensure the speaker is successfully paired and connected to your device.
  - Try playing a different audio source.

Specifications

Feature	Detail
Model Name	KitSound Diggit
Speaker Type	Outdoor
Connectivity Protocol	Bluetooth
Power Source	Battery Powered (1 Lithium Ion battery required)
Speaker Maximum Output Power	10 Watts (2 x dual-opposing 5W drivers)
Waterproof Rating	IP55 (Resistant to water jets and dust)
Playtime	Up to 8 hours
Item Weight	12.3 ounces (approx. 348g)
Product Dimensions	6.3 x 2.44 x 2.44 inches (approx. 16 x 6.2 x 6.2 cm)
Included Components	USB cable, user manual, Kitsound Dig-it

Warranty and Support

For warranty information or technical support, please refer to the contact details provided on the product packaging or visit the official KitSound website. Keep your proof of purchase for any warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07B4XBZY5

More documents and user manuals: **https://manuals.plus/**