Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Blissun 9' Outdoor Patio Umbrella (ASIN: B07B4XZK72)

Blissun 9' Outdoor Patio Umbrella

User Instruction Manual

1. Introduction

Thank you for choosing the Blissun 9' Outdoor Patio Umbrella. This umbrella is designed to provide effective shade and enhance your outdoor living space. Featuring a durable polyester canopy, a sturdy powder-coated aluminum and iron frame, and convenient crank and tilt mechanisms, it offers both functionality and style for various outdoor settings.



Figure 1.1: Blissun 9' Outdoor Patio Umbrella (TAN)

2. Safety Information

- Always ensure the umbrella is securely placed in a heavy, stable umbrella base (not included) to prevent tipping or blowing over, especially in windy conditions.
- Do not use the umbrella in strong winds or severe weather conditions. Close and secure the umbrella when not in use or during inclement weather.
- Keep children and pets away from the umbrella during opening, closing, or tilting operations to prevent injury.
- Avoid placing the umbrella near open flames or heat sources.
- Inspect the umbrella regularly for any signs of damage or wear. Do not use if any parts are broken or compromised.

3. Package Contents

Please verify that all components are present before beginning assembly:

- Umbrella Canopy with Ribs (1)
- Upper Pole Section (1)
- Lower Pole Section (1)

- Crank Handle (pre-attached to pole)



Figure 3.1: Umbrella Components Overview

4. Setup and Assembly

Follow these steps to assemble your Blissun Patio Umbrella:

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, flat surface.
2. **Connect Pole Sections:** Insert the upper pole section (with the umbrella canopy attached) into the lower pole section. Ensure the spring button on the upper pole snaps securely into the corresponding hole on the lower pole.
3. **Insert into Base:** Place the assembled umbrella pole into a suitable, heavy umbrella base (sold separately). Ensure the pole is fully seated and secured within the base using any tightening screws or mechanisms provided by your base.



Figure 4.1: Pole Connection Detail

5. Operating Instructions

5.1. Opening the Umbrella

1. Ensure the umbrella pole is securely in its base.
2. Locate the crank handle on the pole.
3. Turn the crank handle clockwise to smoothly open the umbrella canopy until it is fully extended. Do not force the crank once the canopy is fully open.



Figure 5.1: Umbrella in Open Position

5.2. Tilting the Umbrella

The umbrella features a push-button tilt mechanism for adjustable shade:

1. With the umbrella fully open, locate the push-button on the upper pole section, just above the crank mechanism.
2. Press and hold the button while gently tilting the canopy to your desired angle.
3. Release the button to lock the umbrella in the tilted position.



Figure 5.2: Umbrella in Tilted Position

5.3. Closing the Umbrella

1. If the umbrella is tilted, first return it to the upright position by pressing the tilt button and gently pushing the canopy back to vertical.
2. Turn the crank handle counter-clockwise to retract the canopy until it is fully closed.
3. For long-term storage or during strong winds, it is recommended to secure the closed canopy with a tie strap (if included) or an umbrella cover.

6. Maintenance

- **Cleaning:** To clean the polyester fabric, wipe with a damp cloth. For stubborn stains, a mild soap solution can be used, followed by rinsing with clean water. Allow the canopy to air dry completely before closing or storing.
- **Frame Care:** The powder-coated aluminum and iron pole is designed for durability. Wipe down the pole and ribs

periodically to remove dirt and debris. Avoid using abrasive cleaners or harsh chemicals that could damage the finish.

- **Storage:** During off-season or extended periods of non-use, it is highly recommended to store the umbrella indoors in a dry, protected area. This will help prolong the life of the fabric and frame, and prevent premature fading or wear.

7. Troubleshooting

Problem	Possible Cause	Solution
Umbrella wobbles or tips over	Insufficiently heavy base; not properly secured in base; strong winds.	Ensure a heavy, stable base is used. Tighten all securing screws on the base. Close umbrella in windy conditions.
Crank mechanism is stiff or difficult to turn	Lack of lubrication; debris in mechanism; minor manufacturing variation.	Apply a silicone-based lubricant to the moving parts of the crank. Clean any visible debris. If new, continued use may ease stiffness.
Umbrella fabric fading	Prolonged exposure to direct sunlight.	This is normal wear for outdoor fabrics. To minimize fading, close the umbrella when not in use and consider using an umbrella cover.
Umbrella does not tilt	Tilt button not fully depressed; mechanism jammed.	Ensure the push-button is fully depressed. Check for any obstructions around the tilt mechanism.

8. Specifications

- **Model:** 9' Outdoor Patio Umbrella (ASIN: B07B4XZK72)
- **Canopy Diameter:** 9 feet
- **Fabric Type:** 100% Polyester
- **Frame Material:** Powder-coated Aluminum and Iron
- **Ribs:** 8 Sturdy Iron Ribs
- **Mechanism:** Crank Open System, Push Button Tilt
- **Care Instructions:** Wipe With Damp Cloth
- **Ideal Shade Area:** 42"- 54" round, square or rectangle table with 4 to 6 chairs

9. Warranty and Support

For warranty information and customer support, please refer to the product packaging or contact Blissun directly through their official website or the retailer where the product was purchased. Keep your purchase receipt as proof of purchase. **Blissun Customer Service:** Please visit the Blissun Store on Amazon for more information and contact options.

© 2025 Blissun. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

Why are the solar-powered lights on my Blissun 9-foot Patio Umbrella not working even though the switch is in the 'on' position?

If your Blissun 9' Patio Umbrella solar lights are not working despite the switch being 'on', please check the following common causes and solutions: Initial Charge: Solar lights require a full charge before first...

Read full answer

Open the live page

https://manuals.plus/asin/B07B4XZK72

More documents and user manuals: **https://manuals.plus/**