Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ZdalaMit AKB72915235

ZdalaMit AKB72915235 Replacement Remote Control User Manual for LG Plasma TVs

1. Introduction

This manual provides instructions for the ZdalaMit AKB72915235 replacement remote control, designed for use with various LG Plasma TV models. This remote is a direct replacement and does not require any programming or pairing. Simply insert batteries, and it is ready for operation.



Figure 1: Front view of the ZdalaMit AKB72915235 Replacement Remote Control.

2. Setup

2.1 Battery Installation

The remote control requires two (2) AAA batteries (not included) for operation. Follow these steps to install the batteries:

1. Locate the battery compartment cover on the back of the remote control.
2. Press down on the tab and slide the cover downwards to open the compartment.
3. Insert two new 1.5V AAA alkaline batteries, ensuring the positive (+) and negative (-) terminals match the diagrams inside the compartment.

4. Slide the battery compartment cover back into place until it clicks securely.

Once batteries are installed, the remote is ready for use with compatible LG Plasma TVs.



Figure 2: Rear view of the remote control showing the battery compartment.

3. Operating the Remote Control

To operate your LG Plasma TV, point the remote control directly at the TV's remote sensor. Ensure there are no obstructions between the remote and the TV.

3.1 Key Functions Overview



Figure 3: Angled view of the remote control highlighting various buttons.

- **POWER (●)**: Turns the TV on or off.
- **INPUT**: Selects the input source (e.g., HDMI, AV).
- **NUMBER PAD (0-9)**: Directly enters channel numbers.
- **VOL (+/-)**: Adjusts the volume level.
- **CH (▲/▼)**: Changes TV channels.
- **MUTE**: Mutes or restores the TV sound.

- **INFO**: Displays current program information.
- **HOME**: Accesses the TV's main menu or smart features.
- **Q.MENU**: Opens the Quick Menu for common settings.
- **NAVIGATION BUTTONS (◄ ▲ ► ▼)**: Navigates through menus and options.
- **ENTER**: Confirms a selection.
- **BACK**: Returns to the previous screen or menu.
- **EXIT**: Exits the current menu or function.
- **COLOR BUTTONS (Red, Green, Yellow, Blue)**: Used for specific functions within certain menus or applications.
- **PLAYBACK CONTROLS (Rewind, Play/Pause, Fast Forward, Stop)**: Controls media playback.

4. Maintenance

4.1 Cleaning

To clean the remote control, use a soft, dry cloth. Do not use liquid cleaners, sprays, or abrasive materials, as these can damage the remote's surface or internal components.

4.2 Battery Replacement

Replace batteries when the remote's response becomes inconsistent or stops working. Always replace both batteries at the same time with new 1.5V AAA alkaline batteries. Do not mix old and new batteries, or different types of batteries.

4.3 Storage

Store the remote control in a cool, dry place away from direct sunlight and extreme temperatures. If the remote will not be used for an extended period, it is recommended to remove the batteries to prevent leakage.

5. Troubleshooting

- **Remote not responding:**
  - Ensure batteries are correctly installed with the correct polarity.
  - Replace old batteries with new 1.5V AAA alkaline batteries.
  - Check for any obstructions between the remote control and the TV's remote sensor.
  - Ensure you are pointing the remote directly at the TV.
- **Specific buttons not working:**
  - This may indicate a worn-out button or a minor internal issue. Try replacing batteries first.
  - If the issue persists, the remote may need replacement.
- **TV not turning on/off:**
  - Verify the TV is plugged into a working power outlet.
  - Ensure the remote's power button is functioning (refer to "Remote not responding" steps).

6. Specifications

Model Number	AKB72915235 (Item Model Number: 43223-5368)
Brand	ZdalaMit

Product Dimensions	8 x 2 x 0.6 inches (20.3 x 5.1 x 1.5 cm)
Item Weight	3.2 ounces (90.7 grams)
Power Supply	2 x 1.5V AAA Batteries (not included)
Compatible Devices	LG Plasma Televisions

7. Compatible LG TV Models

This ZdalaMit AKB72915235 replacement remote control is compatible with a wide range of LG Plasma TV models, including but not limited to:

- 50PV400, 42PT350, 50PT350, 50PV450, 42PT200, 50PT200
- 42PJ340, 42PJ550, 50PJ550, 50PK340, 50PK350, 60PK280
- 42PT330, 50PT330, 60PV400, 50PV430, 60PV430, 60PV450
- 42PT250U, 50PT250U, 50PV550U, 60PV550U
- 42PT350C, 50PT350C, 50PV450C, 60PV450C, 60PV250
- 42PT200-UB, 42PT250U-UA, 50PT200-UB, 50PT250U-UA
- 42PT350-UD, 42PT350C-UD, 50PT350-UD, 50PT350C-UD
- 60PV250-UB, 50PV400-UB, 50PV450-UA, 50PV450C-UA
- 60PV400-UB, 60PV450-UA, 60PV450C-UA, 50PV550U-UC, 60PV550U-UC
- 50PJ340, 50PJ350, 50PK250, 60PK250, 50PJ250, 60PJ250, 42PJ350, 60PK29042, 50PJ350C

If your specific LG Plasma TV model is not listed, please verify compatibility with the seller before purchase.

8. Support

For technical assistance or inquiries regarding your ZdalaMit AKB72915235 replacement remote control, please contact the seller or manufacturer directly. Refer to your purchase documentation for specific contact information.

9. Warranty Information

Warranty terms and conditions for the ZdalaMit AKB72915235 replacement remote control are provided by the seller at the time of purchase. Please retain your proof of purchase for any warranty claims. For detailed warranty information, contact the seller directly.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07B8C6447

More documents and user manuals: **https://manuals.plus/**