NIXON A1211-1098

NIXON Siren SS A1211-100m Water Resistant Women's Digital Sport Watch User Manual

Model: A1211-1098

Introduction Features Setup Operation Maintenance Troubleshooting Specifications Support

1. Introduction

This manual provides comprehensive instructions for the NIXON Siren SS A1211-100m Water Resistant Women's Digital Sport Watch. Designed for both aquatic and terrestrial environments, this digital timepiece combines robust construction with essential functionalities for an active lifestyle.

The Siren SS features a 36mm watch face, an 18mm-16mm silicone band, and a stainless steel case, ensuring durability and comfort. Please read this manual thoroughly to understand the watch's capabilities and ensure proper use and maintenance.



Figure 1.1: Front view of the NIXON Siren SS watch. This image displays the digital time and date, highlighting the watch's sleek design and clear display.

2. Key Features

- **Digital Display:** Clear and easy-to-read digital interface.
- **Water Resistance:** Rated for 100 meters (10 ATM), suitable for swimming, surfing, and snorkeling.
- **Tide Updates:** Basic tide information for surf enthusiasts.
- **Durable Construction:** Features a custom stainless steel case and a tapered injection molded silicone band.
- **Secure Fit:** Patented locking looper on the silicone band ensures the watch stays securely on the wrist.
- **Comfortable Design:** Ultra-soft silicone band for extended wear.



Figure 2.1: The NIXON Siren SS watch in an active setting. This image demonstrates the watch's suitability for water sports and its comfortable fit during activities.

3. Setup

3.1 Initial Activation

The NIXON Siren SS watch comes with a pre-installed Lithium Ion battery. It is ready for use upon purchase. No initial charging is required.

3.2 Setting Time and Date

1. Locate the control buttons on the side of the watch case. Typically, there are buttons on the left and right sides.
2. Press and hold the **MODE** button (usually on the bottom left) until the time display begins to flash, indicating setup mode.
3. Use the **ADJUST** button (usually on the top right) to cycle through the settings (hours, minutes, year, month, day).
4. Use the **SET** button (usually on the bottom right) to change the value of the flashing digit.
5. Once all settings are correct, press the**MODE** button again to exit setup mode and save your changes.



Figure 3.1: Side view of the NIXON Siren SS watch. This image shows the placement of the control buttons used for setting time and accessing functions.

3.3 Band Adjustment

The silicone band is designed for a comfortable fit. Adjust the buckle to the desired hole on the strap to secure the watch firmly but comfortably on your wrist. The patented locking looper helps keep the excess strap in place.

4. Operating Instructions

4.1 Basic Time Display

In its default mode, the watch displays the current time (hours, minutes, seconds) and date (month, day).

4.2 Mode Switching

Press the **MODE** button (bottom left) to cycle through different functions. The NIXON Siren SS typically includes modes such as:

- **Time/Date Mode:** Standard display of current time and date.
- **Tide Mode:** Displays basic tide information. Use the **ADJUST** or **SET** buttons to view future or past tide data if available.
- **Chronograph (Stopwatch) Mode:** For timing events. Press **SET** to start/stop, and **ADJUST** to reset.
- **Timer Mode:** For countdowns. Set the desired time using **ADJUST** and **SET**, then press **SET** to start.



Figure 4.1: NIXON Siren SS watch displaying tide data. This image illustrates the watch's specialized functionality for tracking tide movements.

4.3 Backlight

Press the **LIGHT** button (usually top left) to illuminate the display for better visibility in low-light conditions. The backlight will typically remain on for a few seconds.

5. Maintenance

5.1 Cleaning

To clean your watch, wipe the case and band with a soft, damp cloth. For silicone bands, mild soap and water can be used. Avoid harsh chemicals or abrasive materials, as they may damage the watch's finish or seals.

5.2 Water Resistance Care

The Siren SS is water resistant to 100 meters. To maintain water resistance:

- Do not operate buttons while the watch is submerged in water.
- Avoid exposing the watch to extreme temperature changes (e.g., hot showers followed by cold water), which can affect seals.
- Rinse the watch with fresh water after exposure to saltwater or chlorine to prevent corrosion.
- Have the water resistance seals checked periodically by a qualified watch technician, especially after battery replacement.

5.3 Battery Replacement

The watch uses a Lithium Ion battery. When the display becomes dim or functions become erratic, it may be time for a battery replacement. It is recommended to have the battery replaced by a professional watch repair service to ensure the water resistance is maintained.



Figure 5.1: Rear view of the NIXON Siren SS watch case. This image shows the engraved details on the stainless steel case back, including water resistance rating and brand information.

5.4 Storage

When not in use for extended periods, store the watch in a cool, dry place away from direct sunlight and extreme temperatures.

6. Troubleshooting

Problem	Possible Cause	Solution
Display is blank or dim.	Low or dead battery.	Replace the battery. Contact a professional watch repair service.
Time is incorrect.	Time not set correctly or accidental button press.	Refer to Section 3.2 "Setting Time and Date" to reset the time.
Buttons are unresponsive.	Watch may be in a locked mode or internal issue.	Try pressing all buttons to see if it unlocks. If unresponsive, battery may be too low. If problem persists after battery replacement, seek professional service.

Problem	Possible Cause	Solution
Condensation inside the watch.	Exposure to extreme temperature changes or compromised water seal.	Immediately take the watch to a professional watch repair service to prevent internal damage.

7. Specifications

- **Model Number:** A1211-1098
- **Case Material:** Stainless Steel
- **Band Material:** Silicone
- **Watch Face Diameter:** 36mm
- **Band Width:** 18mm-16mm (tapered)
- **Water Resistance:** 100 meters (10 ATM)
- **Clasp Type:** Buckle
- **Movement:** Digital, China Movement
- **Battery:** 1 Lithium Ion battery (included)
- **Product Dimensions:** 4 x 6 x 5 inches
- **Item Weight:** 3.53 ounces

8. Warranty and Support

NIXON products are manufactured to high standards. For specific warranty information, please refer to the warranty card included with your purchase or visit the official NIXON website. For customer support, service, or to find authorized repair centers, please visit www.nixon.com.
Please retain your proof of purchase for any warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question