Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Lovehoney Butt Tingler

Lovehoney Butt Tingler Vibrating Butt Plug Instruction Manual

Model: Butt Tingler | Brand: Lovehoney

Introduction

Thank you for choosing the Lovehoney Butt Tingler Vibrating Butt Plug. This manual provides essential information for the safe and effective use, care, and maintenance of your product. Please read all instructions carefully before first use and retain this manual for future reference.

Product Overview

The Lovehoney Butt Tingler is a silicone vibrating butt plug designed for internal stimulation. It features a tapered tip for comfortable insertion and a flared base for safety. The device offers multiple vibration patterns and speeds for varied experiences.





Image: The Lovehoney Butt Tingler Vibrating Butt Plug, a black silicone device with a tapered tip and flared base.

Key Features:

- **Material:** Body-safe silicone.
- **Vibration Modes:** 3 speeds and 7 patterns for diverse sensations.
- **Design:** Tapered tip for easy insertion and a T-shaped flared base for secure use.
- **Waterproof:** 100% waterproof for versatile use and easy cleaning.
- **Power:** Requires 1 x AAA battery (not included).



Image: Close-up of the Butt Tingler highlighting its vibrating function with 3 speeds and 7 patterns.



Image: The T-shaped flared base of the Butt Tingler, designed for safety and comfort.



Image: Diagram showing the insertable length of 3.5 inches and a maximum girth of 3.75 inches.



Image: The Butt Tingler submerged in water, illustrating its 100% waterproof design.

Safety Information

- Always clean the product thoroughly before and after each use.
- Use only water-based lubricants with this product. Oil-based lubricants can damage silicone.
- Discontinue use immediately if you experience any discomfort or pain.
- Keep out of reach of children.
- Consult a healthcare professional if you have any health concerns or conditions before using this product.

Setup

Battery Installation:

1. Gently twist and pull the base of the butt plug to remove the vibrating bullet.
2. Unscrew the cap of the vibrating bullet.

3. Insert 1 x AAA battery into the bullet, ensuring correct polarity (+/-).
4. Screw the cap back onto the bullet securely.
5. Insert the vibrating bullet back into the base of the butt plug until it clicks into place.



Image: The Butt Tingler disassembled, showing the main body, the removable vibrating bullet, and a AAA battery, indicating battery requirement.

[redacted]

Video: This video demonstrates the process of inserting the AAA battery into the vibrating bullet and reassembling the Lovehoney Butt Tingler.

Operation

1. Ensure the battery is correctly installed.
2. Apply a generous amount of water-based lubricant to both the product and the desired area of the body.
3. Press the power button located on the base of the vibrating bullet to turn the device on.

4. Press the power button repeatedly to cycle through the 3 speeds and 7 vibration patterns.
5. To turn off, press and hold the power button for a few seconds until the vibrations stop.

Cleaning and Maintenance

1. Always clean the product immediately after use.
2. Wash the silicone body with warm water and a toy cleaner or mild soap.
3. Rinse thoroughly to remove all soap residue.
4. Pat dry with a lint-free cloth or allow to air dry completely.
5. Do not use cleaners containing alcohol, petroleum, or acetone, as these can damage the silicone.

Storage

Store the Lovehoney Butt Tingler in a clean, dry, and dust-free environment. Keep it separate from other toys made of different materials to prevent potential damage or reactions. Remove the battery if the product will not be used for an extended period.

Troubleshooting

Problem	Possible Cause	Solution
Device does not turn on or vibrate.	Battery is dead or incorrectly inserted.	Replace with a fresh AAA battery, ensuring correct polarity. Check that the vibrating bullet is fully inserted into the main body.
Vibrations are weak.	Low battery power.	Replace with a fresh AAA battery.
Difficulty changing modes.	Button not pressed correctly or battery low.	Ensure a firm press on the button. Replace battery if necessary.

Specifications

Feature	Detail
Product Dimensions	5.2 x 3.23 x 1.42 inches
Weight	3.25 ounces
Model Name	Butt Tingler
Material	Silicone
Battery Type	1 x AAA (not included)
Manufacturer	Lovehoney

Warranty and Support

For warranty information or product support, please contact Lovehoney customer service directly through their official website or the retailer from whom the product was purchased. Please have your proof of purchase and product model information available.

© 2024 Lovehoney. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07B9HCD2W

More documents and user manuals: **https://manuals.plus/**