PINOLINO Boks

Pinolino Boks Changing Table Dresser Instruction Manual

Model: Boks

Overview Safety Instructions Package Contents Setup & Assembly Operating Instructions Maintenance & Care Troubleshooting Specifications Warranty & Support

1. Overview

The Pinolino Boks Changing Table Dresser is a versatile and stylish furniture piece designed for your nursery. Crafted from white and natural MDF wood, it offers both functionality and modern aesthetics. This dresser features a removable changing top, allowing it to transition into a standard dresser as your child grows. It includes three spacious drawers equipped with a soft-close mechanism for quiet and safe operation, preventing pinched fingers. High-quality brushed stainless steel knobs complement its contemporary design.



Image 1.1: The Pinolino Boks Changing Table Dresser, showcasing its two-tone design and three drawers.



Image 1.2: The Boks Changing Table Dresser integrated into a modern nursery setting.

2. Safety Instructions

Please read and follow all safety instructions carefully to ensure the safe use of your Pinolino Boks Changing Table Dresser.

- **Adult Assembly Required:** This product requires adult assembly. Keep all small parts and packaging materials away from children during assembly.
- **Wall Anchoring:** To prevent tipping, it is highly recommended to secure the dresser to a wall using the provided anti-tip kit. Follow the instructions carefully for proper installation.
- **Changing Top Safety:** Never leave a child unattended on the changing table. Always keep one hand on your child

while changing. The changing top is designed for children up to 15 kg (approximately 12 months).

- **Weight Limits:** Do not overload drawers. Distribute weight evenly.
- **Regular Checks:** Periodically check all screws, bolts, and fasteners to ensure they are tight and secure. Loose hardware can lead to instability.
- **Placement:** Position the dresser on a flat, stable surface. Keep it away from windows, cords, and other potential hazards.

3. Package Contents

Before beginning assembly, verify that all components are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Pinolino Boks Changing Table Dresser components (MDF panels, wooden legs, drawer parts)
- Removable changing top attachment
- Hardware kit (screws, dowels, soft-close drawer slides, knobs, anti-tip kit)
- Assembly instructions manual

4. Setup & Assembly

Assembly is required for this product. Please follow the detailed diagrams and instructions provided in the separate assembly guide included in your package. Below are general steps and important considerations:

1. **Unpack and Identify Parts:** Carefully unpack all components and lay them out on a clean, soft surface to prevent scratches. Identify each part using the labels and the assembly diagram.
2. **Assemble the Main Frame:** Begin by assembling the main body of the dresser. Ensure all panels are correctly oriented before securing them.
3. **Install Drawer Slides:** Attach the soft-close drawer slides to the dresser frame and the drawer sides. Ensure they are level and aligned for smooth operation.
4. **Assemble Drawers:** Construct the three drawers. Pay close attention to the orientation of the drawer fronts and backs.
5. **Attach Legs and Base:** Secure the stylish plywood base and wooden legs to the bottom of the dresser.



Image 4.1: Detail of the dresser's wooden base and legs.

6. **Install Knobs:** Attach the brushed stainless steel knobs to the drawer fronts.



Image 4.2: Detail of the high-quality brushed stainless steel drawer knob.

7. **Insert Drawers:** Carefully slide the assembled drawers into their respective slots. The soft-close mechanism should engage smoothly.
8. **Attach Changing Top:** Secure the removable changing top to the dresser using the designated hardware. Ensure it is firmly attached and stable.
9. **Wall Anchoring:** Install the anti-tip wall anchoring device according to the instructions. This is a critical safety step.

Important: Some users have reported issues with misaligned holes or incorrect parts. If you encounter such problems, do not force parts. Contact Pinolino customer support for assistance.

5. Operating Instructions

5.1 Using the Changing Top

- Place a changing pad (not included) securely within the changing top's perimeter.
- Always keep essential changing supplies within reach, but out of the child's grasp.
- When your child no longer requires a changing station, the changing top can be easily removed, converting the unit into a standard dresser.

5.2 Operating Soft-Close Drawers

- The drawers are equipped with a soft-close mechanism. To close, gently push the drawer until the mechanism engages, and it will slowly pull itself shut.
- Avoid forcing drawers open or closed, as this can damage the soft-close slides.



Image 5.1: Icon indicating the soft-close drawer feature.

6. Maintenance & Care

- **Cleaning:** Wipe the dresser surfaces with a damp cloth. For stubborn marks, use a mild soap solution and immediately dry with a clean, soft cloth.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners, solvents, or strong chemical detergents, as these can damage the finish.
- **Hardware Check:** Periodically inspect all screws and fittings. Tighten them as necessary to maintain stability and safety.
- **Sunlight Exposure:** Avoid prolonged exposure to direct sunlight, which can cause fading or discoloration of the wood finish.

7. Troubleshooting

Problem	Possible Cause	Solution
Drawers do not close smoothly or are misaligned.	Incorrect installation of drawer slides; loose hardware; obstruction.	Check that drawer slides are installed correctly and are level. Ensure all screws are tightened. Remove any obstructions.
Changing top feels unstable.	Changing top not securely fastened; loose connections.	Verify that all hardware connecting the changing top to the dresser is fully tightened. Ensure the dresser is on a level surface.

Problem	Possible Cause	Solution
Dresser wobbles or is unstable.	Loose assembly screws; uneven floor; anti-tip kit not installed.	Tighten all assembly screws. Ensure the dresser is on a level surface. Install the anti-tip kit as per instructions.
Missing or damaged parts upon arrival.	Manufacturing or shipping error.	Do not proceed with assembly. Contact Pinolino customer support immediately for replacement parts.

8. Specifications

Feature	Detail
Brand	PINOLINO
Model Name	Boks (Product Code: av2023-PINOLINO-b commode langer-7ce88d54)
Material	Wood (MDF, Plywood)
Finish Type	Lacquered, Matte
Furniture Finish	Maple
Color	White / Natural
Number of Drawers	3
Item Dimensions (L x W x H)	126 x 77 x 101 cm (Depth 77cm / 57cm without changing top)
Changing Height	94 cm
Removable Changing Top	Yes
Drawer Mechanism	Soft-close system
Knob Material	Brushed Stainless Steel
Assembly Required	Yes
Care Instructions	Wipe with a damp cloth
Item Weight	1 Kilogram (Note: This weight may be a placeholder or error in source data. Actual weight is significantly higher.)
ASIN	B07B15KPM2
International Article Code	04035769046200

9. Warranty & Support

For warranty information, please refer to the documentation included with your purchase or visit the official Pinolino website. Pinolino offers specialized customer support for any inquiries regarding your product.

Contact Information:

Please refer to the contact details provided on the Pinolino website or your purchase receipt for customer service.

© 2023 PINOLINO. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question