Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Alltro AA59-00741A

Alltro AA59-00741A Replacement Remote Control for Samsung TVs User Manual

Model: AA59-00741A

1. Introduction

This manual provides detailed instructions for the setup, operation, maintenance, and troubleshooting of your Alltro AA59-00741A replacement remote control for Samsung televisions. This remote is designed to function as a direct replacement for the original Samsung AA59-00741A remote, offering seamless compatibility without the need for programming.

2. Safety Information

- Do not expose the remote control to direct sunlight, heat sources, or extreme temperatures.
- Avoid dropping the remote control or subjecting it to strong impacts.
- Do not immerse the remote control in water or any other liquids.
- Keep batteries out of reach of children. If swallowed, seek immediate medical attention.
- Dispose of used batteries according to local regulations. Do not dispose of batteries in fire.

3. Package Contents

Please check the package for the following item:

- 1 x Alltro AA59-00741A Replacement Remote Control

Note: Batteries are not included and must be purchased separately.

4. Setup: Battery Installation

The remote control requires two AAA batteries (not included).

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or in the direction indicated by an arrow to open it.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals match the markings inside the compartment.
4. Close the battery compartment cover by sliding it back into place until it clicks securely.

Once batteries are installed, the remote control is ready for use with your compatible Samsung TV. No programming is required.

5. Operating Instructions

This section details the functions of the buttons on your Alltro AA59-00741A remote control.



Figure 1: Front view of the Alltro AA59-00741A replacement remote control. It is a black, rectangular remote with various function buttons arranged in a standard layout. The power button is red and located at the top left. Number buttons (0-9) are centrally located, with volume and channel controls below them. Navigation and menu buttons are in the middle, and media playback controls are at the bottom.

5.1. Power and Source Control

- **Power (Red Button):** Turns the TV on or off.
- **SOURCE:** Selects the input source (e.g., HDMI 1, HDMI 2, TV).

5.2. Number Pad and Special Functions

- **0-9:** Enters channel numbers directly.
- **TTX/MIX:** Toggles Teletext display or mixes Teletext with TV picture.
- **PRE-CH (or P.CH):** Returns to the previously viewed channel.

5.3. Volume and Channel Control

- **Volume (+/-):** Increases or decreases the volume level.
- **MUTE:** Mutes or unmutes the TV sound.

- **Channel (Up/Down Arrows):** Changes the TV channel up or down.
- **CHLIST:** Displays the channel list.

5.4. Menu and Navigation

- **CONTENT:** Accesses content features (may vary by TV model).
- **MENU:** Opens the TV's main menu.
- **GUIDE:** Displays the electronic program guide (EPG).
- **TOOLS:** Accesses quick settings or tools menu.
- **INFO:** Displays information about the current program or input.
- **Directional Arrows (Up, Down, Left, Right):** Navigates through menus and options.
- **Enter (Center Button):** Confirms a selection or enters a menu item.
- **RETURN:** Returns to the previous screen or menu.
- **EXIT:** Exits the current menu or function.

5.5. Color Buttons and Media Controls

- **A (Red), B (Green), C (Yellow), D (Blue):** Special function buttons, their use varies depending on the TV model or application.
- **E-MANUAL:** Accesses the TV's electronic manual.
- **P.SIZE:** Adjusts the picture size/aspect ratio.
- **AD/SUBT.:** Toggles Audio Description or Subtitles.
- **Media Playback Controls (Rewind, Play, Pause, Stop, Fast Forward):** Controls media playback for compatible content (e.g., USB media, smart TV apps).

6. Maintenance

- **Cleaning:** Wipe the remote control with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Battery Replacement:** Replace batteries when the remote control's response becomes sluggish or it stops working. Always replace both batteries at the same time.
- **Storage:** If the remote control will not be used for an extended period, remove the batteries to prevent leakage and damage. Store in a cool, dry place.

7. Troubleshooting

Problem	Possible Cause	Solution
Remote control not working.	Dead or incorrectly inserted batteries. Obstruction between remote and TV. Remote out of range.	Replace batteries with new ones, ensuring correct polarity. Remove any obstructions. Move closer to the TV.
Buttons are unresponsive or sticky.	Dirt or debris under buttons. Worn-out internal contacts.	Clean the remote control surface. If problem persists, consider replacing the remote.
Remote works intermittently.	Low battery power. Weak infrared signal.	Replace batteries. Ensure clear line of sight to the TV's IR receiver.

8. Specifications

Brand:	Alltro
Model Number:	AA59-00741A
Connectivity Technology:	Infrared (IR)
Compatible Devices:	Samsung Televisions
Number of Buttons:	45
Maximum Range:	10 Meters
Batteries Required:	2 x AAA (Alkaline recommended)
Item Weight:	58 Grams
Color:	Black

9. Warranty and Support

This product is covered by the standard legal warranty in accordance with applicable consumer protection laws. For any issues or support inquiries, please refer to your purchase documentation or contact the retailer from whom you purchased this product.

Please retain your proof of purchase for warranty claims.

© 2023 Alltro. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07BB3CBMF

More documents and user manuals: **https://manuals.plus/**