NIXON A039471-00

Nixon R1G1 Watch - Men's User Manual

Model: A039471-00

Brand: NIXON

Introduction and Overview

The Nixon R1G1 Watch for Men offers a distinctive and original approach to analog timepiece design. This manual provides essential information for the proper setup, operation, and maintenance of your Nixon R1G1 watch, ensuring its longevity and optimal performance.

The R1G1 features a unique display with four hands housed within its sleek stainless steel and crystal casing. Two hands indicate seconds and minutes by rotating around the dial's center, while the hour and date are displayed on semicircle gauges, reminiscent of a speedometer. The watch is complemented by an imported leather band with a single tongue buckle.



Figure 1: Front view of the Nixon R1G1 Watch, showcasing its distinctive dial and leather strap. The watch features a stainless steel case and a unique display for time and date.

Product Features and Specifications

The Nixon R1G1 Watch is designed for casual wear, combining unique aesthetics with functional design. Below are its key features and specifications:

Feature	Specification
Housing Material	Stainless steel, hardened mineral crystal
Strap Material	Imported leather

Chronograph	No
Waterproof	No
Backlight	No
Alarms	No
Size	Large (35-41mm from 3 to 9 o'clock position)
Recommended Use	Casual wear

Setup

Upon receiving your Nixon R1G1 watch, perform the following initial setup steps:

1. **Unpacking:** Carefully remove the watch from its packaging. Inspect for any visible damage.
2. **Crown Position:** Locate the crown on the side of the watch case. The crown is typically used for setting the time and date.
3. **Initial Time Setting:**
    - Pull the crown out to its furthest position (usually the second click).
    - Rotate the crown to advance the minute and hour hands to the current time. Pay attention to AM/PM if the watch has a 24-hour indicator or date change mechanism.
    - Once the time is set, push the crown back in fully to start the watch movement.
4. **Date Setting:**
    - Pull the crown out to the first click position.
    - Rotate the crown in the appropriate direction (refer to operating instructions for specific direction) to adjust the date displayed on the semicircle gauge.
    - Once the date is set, push the crown back in fully.

Ensure the crown is fully pushed in after setting to prevent dust and moisture from entering the watch mechanism.

Operating Instructions

Understanding the unique display of your Nixon R1G1 watch is key to its operation:

- **Reading Time:**
    - The central hands indicate seconds and minutes, functioning like a traditional analog watch.
    - The hour is displayed on one of the semicircle gauges, with a dedicated hand pointing to the hour marker.
    - The date is displayed on the other semicircle gauge, with its own hand indicating the current day of the month.
- **Adjusting Time:**
    - Pull the crown out to the second click position.
    - Rotate the crown clockwise or counter-clockwise to move the hour and minute hands.
    - Push the crown back in fully to synchronize the watch.
- **Adjusting Date:**
    - Pull the crown out to the first click position.

- Rotate the crown to adjust the date. Typically, rotating in one direction changes the date. Avoid setting the date between 9 PM and 3 AM, as this can interfere with the automatic date change mechanism.
- Push the crown back in fully.

For optimal accuracy, set the time and date in a well-lit environment.

Maintenance

Proper care and maintenance will extend the life and appearance of your Nixon R1G1 watch:

- **Cleaning the Case and Crystal:**
  - Wipe the stainless steel case and mineral crystal with a soft, lint-free cloth.
  - For stubborn smudges, slightly dampen the cloth with water. Avoid using harsh chemicals or abrasive materials.
- **Leather Strap Care:**
  - Avoid prolonged exposure to direct sunlight, extreme temperatures, and moisture, as these can damage the leather.
  - If the strap gets wet, gently pat it dry with a soft cloth and allow it to air dry naturally, away from direct heat.
  - Consider using a leather conditioner periodically to keep the strap supple and prevent cracking.
- **Water Resistance:**
  Important: This watch is **not waterproof**. Avoid exposing it to water, including rain, showers, swimming, or submersion. Water damage is not covered under warranty.
- **Storage:**
  When not in use, store your watch in a cool, dry place, away from direct sunlight and strong magnetic fields.

Troubleshooting

If you encounter issues with your Nixon R1G1 watch, consider the following common troubleshooting steps:

- **Watch Not Running:**
  - Ensure the crown is fully pushed in. If it's pulled out, the watch will not run.
  - If the watch is battery-powered (most quartz watches are), the battery may need replacement. This typically requires professional service.
- **Time is Incorrect:**
  - Re-set the time following the "Adjusting Time" instructions in the Operating section.
  - If the watch consistently loses or gains significant time, it may require servicing.
- **Date Not Changing or Incorrect:**
  - Re-set the date following the "Adjusting Date" instructions.
  - Ensure you are not attempting to set the date during the watch's automatic date change cycle (typically between 9 PM and 3 AM).
- **Condensation Under Crystal:**
  This indicates moisture has entered the watch. As the watch is not waterproof, this is likely due to exposure to water or high humidity. Immediately seek professional service to prevent further damage.

For issues not resolved by these steps, or for internal repairs, it is recommended to contact an authorized Nixon service

center.

Warranty and Support

Your Nixon R1G1 Watch is covered by a **2-Year Manufacturer Warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use.

The warranty does not cover:

- Damage resulting from improper handling, lack of care, accidents, or normal wear and tear.
- Water damage, as this watch is not waterproof.
- Battery replacement.
- Damage caused by unauthorized repair or modification.

For warranty claims, service, or additional support, please visit the official NIXON website or contact their customer service department. Keep your proof of purchase for warranty validation.

NIXON Official Website: Visit the NIXON Store on Amazon

© 2023 NIXON. All rights reserved. This manual is for informational purposes only.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question