Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

DEWENWILS SP-058A/TR-034-8

DEWENWILS Outdoor Power Stake Timer

MODEL: SP-058A/TR-034-8

Introduction

The DEWENWILS Outdoor Power Stake Timer is a versatile and durable solution for automating your outdoor lighting and electrical devices. Designed for convenience and safety, this waterproof power stake features six grounded outlets, a 6-foot extension cord, and wireless remote control with a 100-foot range. Its photocell sensor enables automatic dusk-to-dawn operation, while multiple timer settings offer flexible scheduling for various applications, from holiday decorations to garden features.



Figure 1: The DEWENWILS Outdoor Power Stake Timer, showing the main unit, remote control, and power cord.

Safety Information

Please read and understand all safety instructions before installation and use. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- **Outdoor Use Only:** This device is designed for outdoor use. Ensure all connections are secure and protected from direct water exposure.
- **Grounded Outlets:** Always plug the power stake into a grounded GFCI (Ground Fault Circuit Interrupter) outlet for maximum safety.
- **Overload Protection:** The unit features an overload protection switch. Do not exceed the maximum load capacity of 1625W (13A). If an overload occurs, the switch will trip to prevent damage.
- **Waterproof Design:** Individual waterproof covers protect the outlets. Ensure covers are closed when not in use. The unit is designed to withstand rain and snow, but should not be submerged in water.
- **Cord Management:** Route the 6-foot extension cord safely to prevent tripping hazards and damage.



Figure 2: Waterproof covers on the outlets ensure protection against elements.

Package Contents

Verify that all items are present in the package:

- 1 x DEWENWILS Outdoor Power Stake Timer Unit
- 1 x Wireless Remote Control (with 1 CR2032 battery installed)
- 1 x 2-Section Ground Stake
- 1 x Instruction Manual

Setup

1. **Assemble the Ground Stake:** The ground stake comes in two sections. Screw the pointed section into the base section. Then, screw the assembled stake firmly into the bottom of the power stake timer unit.



Figure 3: Assembly of the ground stake.

2. **Placement:** Choose a suitable outdoor location for the power stake. Ensure it is placed on stable ground and at least 1 foot above ground level to prevent waterlogging. The photocell sensor should have unobstructed access to ambient light for optimal dusk-to-dawn operation.



Figure 4: Proper placement of the power stake in the ground.

3. **Connect to Power:** Plug the 6-foot extension cord of the power stake into a grounded GFCI outdoor outlet.
4. **Connect Devices:** Open the waterproof covers of the desired outlets and plug in your outdoor lights or appliances. Close the covers securely after plugging in devices.

Operating Instructions

The DEWENWILS Power Stake Timer offers multiple operating modes, controllable via the unit's buttons or the wireless remote.

Using the Remote Control:



Figure 5: The wireless remote control for convenient operation.

- **ON/OFF:** Press the **ON** button to turn all connected devices on. Press the**OFF** button to turn all connected devices off.
- **Timer Settings (2H/4H/6H/8H):** Press the desired hour button (e.g.,**2H** for 2 hours) to set the devices to turn off

automatically after the selected duration. The timer starts immediately upon selection.

- **Sensor Mode:** Press the **Sensor** button. The power stake will automatically turn on at dusk and turn off at dawn.
- **Timer Button:** This button on the remote cycles through the preset timer options (2H, 4H, 6H, 8H) and the Sensor mode.

Manual Operation (on the unit):



Figure 6: Control panel of the power stake timer.

- **Power Button:** The large gray button on the unit acts as a manual ON/OFF switch. Press once to turn on, press again to turn off.
- **Timer/Sensor Button:** The smaller gray button below the power indicator cycles through the timer settings (2H, 4H, 6H, 8H) and the Sensor mode. The corresponding LED indicator will light up to show the active mode.

Maintenance

- **Cleaning:** Disconnect the power stake from the outlet before cleaning. Wipe the unit with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** When not in use for extended periods, store the power stake in a cool, dry place away from direct sunlight and moisture.
- **Remote Battery Replacement:** The remote control uses one CR2032 button cell battery. If the remote's range decreases or it stops responding, replace the battery.

Troubleshooting

Problem	Possible Cause	Solution
Unit not turning on.	No power to the outlet; tripped GFCI; overload.	Check power source; reset GFCI; check for overload (reset overload protection switch on unit).
Remote not working.	Remote battery low/dead; out of range; interference.	Replace CR2032 battery; move closer to the unit (within 100ft); ensure no major obstructions.
Dusk-to-dawn not functioning correctly.	Sensor obstructed or dirty; insufficient light.	Clean the sensor; ensure the sensor is not blocked by objects or debris.
Timer not activating.	Incorrect timer setting; unit not receiving remote signal.	Verify timer mode is selected (LED indicator on); ensure remote is within range and battery is good.

Specifications

Feature	Detail
Model Number	SP-058A/TR-034-8
Voltage	125 Volts
Max Current	13 Amps
Max Power Rating	1625 Watts
Number of Outlets	6 Grounded Outlets
Cord Length	6 Feet (SJTW 16/3C)

Feature	Detail
Remote Control Range	Up to 100 Feet (RF Signal)
Timer Settings	Dusk-to-Dawn, 2H, 4H, 6H, 8H
Remote Battery Type	1 x CR2032 (included)
Material	Fireproof PPE
Certifications	UL Listed
Product Dimensions	5.3 x 3 x 8 inches
Item Weight	1 pound

Warranty and Support

DEWENWILS products are designed for reliability and performance. This product comes with a standard manufacturer's warranty. For detailed warranty information, technical support, or assistance with troubleshooting, please refer to the contact information provided in the original product packaging or visit the official DEWENWILS website.

© 2025 DEWENWILS. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07BNBBRYJ

More documents and user manuals: **https://manuals.plus/**