Kärcher 1.629-780.0

Kärcher WD 2 PREMIUM BASIC Wet and Dry Vacuum Cleaner

User Manual

Product Overview

The Kärcher WD 2 PREMIUM BASIC is a versatile wet and dry vacuum cleaner designed for various cleaning tasks. It features a robust stainless steel container, a powerful 1000W motor, and a compact design for easy storage and transport. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your vacuum cleaner.





Image: The Kärcher WD 2 PREMIUM BASIC wet and dry vacuum cleaner, showing its yellow and black body, stainless steel container, flexible hose, and floor nozzle.

Key Features:

- Accessory compartment and cable holder for organized storage.
- "Pull & Push" locking system for effortless opening and closing of the collection compartment.
- Parking position for tidy and ready-to-use accessories during work intervals.
- Ergonomic handle for comfortable product transport.
- Compact and space-saving design.

Setup and Assembly

Follow these steps to set up your Kärcher WD 2 PREMIUM BASIC vacuum cleaner before first use.

1. **Unpacking:** Carefully remove all components from the packaging. Ensure all parts listed in the "Included Components" section are present.
2. **Filter Installation:** For dry vacuuming, ensure the cloth filter bag is correctly installed inside the container. For wet vacuuming, the foam filter should be in place.



Image: Close-up view of the vacuum cleaner's interior, showing the black foam filter correctly positioned over the motor head for wet vacuuming.

3. **Hose Connection:** Insert the flexible suction hose into the suction port on the vacuum cleaner's head until it clicks into place.



Image: Top view of the Kärcher WD 2 PREMIUM BASIC, highlighting the yellow motor head with the power switch and the circular suction port where the hose connects.

4. **Accessory Attachment:** Attach the desired accessory (e.g., floor nozzle, crevice nozzle) to the end of the suction hose or extension tubes.



Image: The black floor nozzle attached to a black extension tube, ready for use.

Operating Instructions

General Operation:

1. **Power Connection:** Plug the power cord into a suitable electrical outlet (220-240V, 50/60Hz).
2. **Switching On/Off:** Use the power switch located on the top of the motor head to turn the vacuum cleaner ON (I) or OFF (O).



Image: A close-up view of the yellow motor head, showing the black power switch with 'I' (On) and 'O' (Off) markings, and the hose connection port.

3. **Parking Position:** When taking a break, you can conveniently store the suction tube and floor nozzle in the designated parking position on the unit.

Dry Vacuuming:

For dry vacuuming, ensure a dry filter bag is installed. The cloth filter is suitable for general dry dirt.



Image: A brown paper filter bag unfolded next to a black crevice nozzle, indicating accessories for dry vacuuming.

- Use the floor nozzle for large surfaces.
- Use the crevice nozzle for narrow gaps and corners.



Image: A black crevice nozzle, a long, flat accessory designed for reaching into tight spaces.

Wet Vacuuming:

Before wet vacuuming, remove the filter bag if installed. Ensure the foam filter is correctly in place to protect the motor from liquids.

- Do not vacuum flammable liquids.
- Monitor the fill level of the container to prevent overflow.

Maintenance

Regular maintenance ensures the longevity and optimal performance of your Kärcher WD 2 PREMIUM BASIC vacuum cleaner.

Cleaning the Container:

- After each use, especially after wet vacuuming, empty and clean the stainless steel container.
- Use the "Pull & Push" locking system to easily open and close the container.
- Wipe the interior with a damp cloth and allow it to air dry completely before reassembling.

Filter Maintenance:

- **Dry Filter Bag:** Replace the filter bag when it is full or suction power decreases significantly.
- **Foam Filter:** For wet vacuuming, clean the foam filter regularly by rinsing it under running water. Allow it to dry completely before reuse.

Accessory Care:

- Clean nozzles and tubes as needed to prevent blockages.
- Store accessories in the integrated accessory compartment.

Troubleshooting

Problem	Possible Cause	Solution
Vacuum cleaner does not switch on.	No power supply; power switch is off.	Check power cord connection; ensure power switch is in 'I' position.
Low suction power.	Filter bag full; filter clogged; hose/nozzle blocked.	Replace filter bag; clean foam filter; check and clear blockages in hose/nozzle.
Water leaks during wet vacuuming.	Container is full; foam filter not correctly installed.	Empty container; ensure foam filter is properly seated.

Specifications

Attribute	Value
Model Number	1.629-780.0
Power Consumption	1000 W
Real Suction Power	180 Air Watt
Container Capacity	15 Liters
Container Material	Stainless Steel
Nominal Diameter of Accessories	35 mm
Power Supply	220-240 V / 50/60 Hz
Weight (without accessories)	5.1 kg
Product Dimensions (L x W x H)	39.5 x 38.5 x 45.3 cm
Filter Type	Cloth (for dry), Foam (for wet)
Cordless	No

Warranty and Support

Information regarding product warranty and customer support for the Kärcher WD 2 PREMIUM BASIC Wet and Dry Vacuum Cleaner was not available in the provided product data. Please refer to the official Kärcher website or your purchase documentation for detailed warranty terms and contact information for support.
For further assistance, you may visit the official Kärcher store on Amazon:Kärcher Store

© 2024 Kärcher. All rights reserved.