Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

VTech 80-193822

VTech Kidizoom Smart Watch DX2 User Manual

Model: 80-193822

Introduction

Welcome to the user manual for your VTech Kidizoom Smart Watch DX2. This guide provides essential information on setting up, operating, maintaining, and troubleshooting your new smartwatch. Please read this manual thoroughly to ensure proper use and to fully enjoy all the features of your device.



Image: A child smiling while looking at the VTech Kidizoom Smart Watch DX2 worn on their wrist.

1. Setup

1.1 Unboxing and Initial Inspection

Carefully remove all contents from the packaging. Ensure the following items are present:

- VTech Kidizoom Smart Watch DX2
- Micro-USB Cable
- User Manual (this document)

Inspect the watch for any visible damage. If any components are missing or damaged, please contact VTech customer support.



Image: Front view of the VTech Kidizoom Smart Watch DX2 retail packaging, showing the watch and key features.

1.2 Charging the Device

Before first use, fully charge the Kidizoom Smart Watch DX2. The watch contains a rechargeable battery.

1. Connect the micro-USB cable to the charging port on the side of the watch.
2. Connect the other end of the USB cable to a computer's USB port or a USB wall adapter (not included).

3. The screen will indicate that the device is charging. A full charge typically takes a few hours.
4. Once fully charged, disconnect the USB cable.

Note: The average battery life is 1 to 3 days, depending on usage.

1.3 Powering On/Off

To power on the watch, press and hold the Power/Home button located on the side until the screen lights up.
To power off the watch, press and hold the Power/Home button until a power-off confirmation appears on the screen. Select "Yes" to confirm.

1.4 Initial Setup and Language Selection

Upon first power-on, you may be prompted to set the date, time, and language. Follow the on-screen instructions to configure these settings. Ensure you select your preferred language for optimal user experience.

1.5 Connecting to Explor@Park

The VTech Explor@Park platform allows you to download additional games, watch faces, and other content for your Kidizoom Smart Watch DX2.

1. Install the VTech Learning Lodge (Explor@Park) software on your computer.
2. Connect your watch to your computer using the micro-USB cable.
3. Follow the instructions within the Learning Lodge software to transfer content to your watch.



Image: Illustration of the VTech Kidizoom Smart Watch DX2 connected to a computer via USB, indicating file transfer capabilities.

2. Operating the Smart Watch

2.1 Basic Navigation

The Kidizoom Smart Watch DX2 features a 1.4-inch color touchscreen for easy navigation. Swipe left or right to browse through applications and menus. Tap an icon to select it.
The Power/Home button returns you to the main clock screen or the previous menu.



Image: Close-up of the VTech Kidizoom Smart Watch DX2 touchscreen displaying various app icons.

2.2 Time Functions

The watch offers various time-related features:

- **Clock Display:** Choose from over 50 digital and analog watch faces. Customize the background with your own photos.
- **Alarm:** Set multiple alarms with custom sounds, including recorded voice messages.
- **Timer:** A countdown timer for various activities.
- **Stopwatch:** Measure elapsed time.
- **Calendar:** View the current date.



Image: Screen showing various time-related applications on the VTech Kidizoom Smart Watch DX2, such as alarm, timer, and stopwatch.

2.3 Camera and Video Functions

The Kidizoom Smart Watch DX2 is equipped with two cameras:

- A front-facing camera for selfies.
- A side-facing camera for capturing photos and videos of your surroundings.

To access the camera, tap the Camera icon on the main menu.

1. **Taking Photos:** Tap the shutter icon to take a picture.
2. **Recording Videos:** Switch to video mode and tap the record icon to start/stop recording.
3. **Effects and Filters:** Explore various frames, filters, and stamps to customize your photos and videos.



Image: Diagram illustrating the two camera locations on the VTech Kidizoom Smart Watch DX2: one front-facing and one side-facing.

2.4 Voice Recorder

The watch includes a voice recorder function. You can record up to 60 seconds of audio and apply fun voice-changing effects.

2.5 Games and Activities

The watch comes pre-loaded with several games and activities designed for learning and fun:

- **Augmented Reality Games:** Such as "Monster Catcher," where you use the watch to find and capture virtual monsters in the real world.
- **Logic Games:** Three progressive logic games to train cognitive skills.
- **Active Games:** Activities like "Speed Race," "Crazy Dance," and "Jump Rope" that track movement using the built-in accelerometer.
- **Pedometer:** Counts steps taken during walking or running.



Image: Screen displaying a selection of games available on the VTech Kidizoom Smart Watch DX2.

2.6 Image Creator and Special Effects

Use the Image Creator to personalize your watch. You can create custom watch backgrounds from your own photos. The watch also features a face detector to apply fun effects to faces in photos.



Image: Screen showing the image creator interface on the VTech Kidizoom Smart Watch DX2, allowing users to customize images.

2.7 Other Applications

The watch also includes a calculator (downloadable via Explor@Park) and other utility applications.

3. Maintenance

3.1 Cleaning

To clean your VTech Kidizoom Smart Watch DX2, wipe it with a slightly damp cloth. Do not use chemical cleaners or abrasive materials, as these can damage the device.

3.2 Battery Care

The watch uses a rechargeable battery. To prolong battery life:

- Avoid fully discharging the battery frequently.
- Charge the watch regularly, especially if it will not be used for an extended period.
- Do not expose the watch to extreme temperatures.

3.3 Water Resistance

The VTech Kidizoom Smart Watch DX2 is **splash-proof**, meaning it can withstand minor splashes of water. It is **not waterproof** and should not be submerged in water, worn while swimming, or exposed to heavy rain.

4. Troubleshooting

If you encounter issues with your VTech Kidizoom Smart Watch DX2, please refer to the following common solutions:

Problem	Solution
Watch does not turn on	Ensure the battery is charged. Connect the watch to a power source using the USB cable and try turning it on after a few minutes.
Screen is unresponsive	Try restarting the watch by holding down the Power/Home button. If unresponsive, allow the battery to fully drain and then recharge.
Battery drains quickly	Reduce screen brightness, close unused applications, and limit continuous game-play or video recording. Ensure the watch is fully charged before use.
Cannot connect to computer/Explor@Park	Ensure the USB cable is properly connected to both the watch and the computer. Try a different USB port or restart your computer. Make sure the VTech Learning Lodge software is installed and up to date.

If the problem persists, please contact VTech customer support.

5. Specifications

Feature	Detail
Model Number	80-193822
Display	1.4-inch Color LCD Touchscreen (240 x 240 resolution)

Storage Capacity	256 MB
Cameras	Dual Cameras (Front and Side)
Connectivity	Micro-USB for charging and data transfer
Battery	Rechargeable (Alkaline composition)
Battery Life	Approximately 1-3 days (average 2 days)
Water Resistance	Splash-proof (Not submersible)
Dimensions	22.4 x 1.5 x 4.6 cm (approximate)
Weight	410 Grams
Recommended Age	Ages 4-9 years (Not suitable for children under 36 months)
Operating System	Android (Custom VTech OS)

6. Warranty Information

The VTech Kidizoom Smart Watch DX2 comes with a**2-year manufacturer's warranty**. This warranty covers defects in materials and workmanship under normal use. Please retain your proof of purchase for warranty claims.
For detailed warranty terms and conditions, please refer to the documentation included with your product or visit the official VTech website.

7. Safety Information

WARNING: Not recommended for children under 36 months due to small parts that could be ingested.
Always supervise young children when they are using electronic devices. Do not allow children to play with the USB cable unsupervised.

8. Customer Support

For further assistance, technical support, or to explore additional content for your watch, please visit the official VTech website or the Explor@Park platform:

- VTech Official Website
- VTech Explor@Park (Learning Lodge)

You can also refer to the contact information provided in your product packaging for local customer service.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07BQHZXNQ

More documents and user manuals: **https://manuals.plus/**