ZdalaMit NARF2_00349

ZdalaMit AKB69680401 Replacement Remote Control User Manual

Model: NARF2_00349

1. Introduction

This user manual provides instructions for the ZdalaMit AKB69680401 Replacement Remote Control, designed to be compatible with various LG HD LCD TV models. This remote offers a direct replacement solution, requiring no complex programming or pairing.

1.1. Compatibility

This remote control is compatible with the following LG TV models:

- 19LH20, 22LH20, 26LH20, 32LH20, 37LH20, 42LH20
- 32LH30, 37LH30, 42LH30, 47LH30
- 19LU55, 22LU55, 27LU55, 26LU55
- 32LF11, 37LF11, 47LF11, 42LF11, 47LF21
- 32LH40, 55LH400C, 32CL40, 42CL40, 47CL40
- 32LH41, 37LH41, 42LH41, 47LH41, 55LH41
- 37LH55, 42LH55, 47LH55, 55LH55
- 37LH40, 42LH40, 47LH40, 55LH40

2. Setup

The ZdalaMit AKB69680401 remote control is designed for immediate use without the need for programming or pairing. Simply install the batteries, and it will be ready to operate your compatible LG TV.

2.1. Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards to open it.

3. Insert two (2) 1.5V AA alkaline batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.



Figure 2.1: Battery compartment with cover removed, showing battery placement.

3. Operating Instructions

This remote control provides full functionality for your LG TV, mirroring the original remote's layout and features. Below are common button functions.



Figure 3.1: Front view of the remote control.

3.1. Key Functions

Button	Function
POWER	Turns the TV on or off.
INPUT	Selects the input source (e.g., HDMI, AV).
AV MODE	Adjusts audio/video settings.

Button	Function
ENERGY SAVING	Activates or deactivates energy-saving modes.
Number Buttons (0-9)	Direct channel selection.
LIST	Displays the channel list.
VOL +/-	Adjusts the volume level.
MUTE	Mutes or unmutes the TV sound.
CH ^/v	Changes channels up or down.
FLASHBK	Returns to the previously viewed channel.
PAGE ^/v	Navigates through pages in menus or lists.
Navigation Pad (Up, Down, Left, Right, ENTER)	Navigates through menus and confirms selections.
MENU	Opens the main TV menu.
Q.MENU	Opens the Quick Menu for frequently used settings.
RETURN	Returns to the previous screen or menu.
Colored Buttons (Red, Green, Yellow, Blue)	Context-sensitive functions within menus or applications.
MPLINK	Activates LG's Simplink (HDMI-CEC) function.
MARK	Marks items or functions.
FAV	Accesses favorite channels or content.

4. Maintenance

Proper care will extend the life of your remote control.

- Keep the remote control dry. Moisture can damage the internal circuitry.
- Avoid exposing the remote to extreme temperatures.
- Do not drop or subject the remote to strong impacts.
- Clean the remote with a soft, dry cloth. Do not use liquid cleaners or aerosol sprays.
- If the remote will not be used for an extended period, remove the batteries to prevent leakage.

5. Troubleshooting

If you experience issues with your remote control, try the following solutions:

5.1. Remote Not Responding

- **Check Batteries:** Ensure batteries are inserted correctly with the correct polarity (+/-). Replace old or depleted batteries with new 1.5V AA alkaline batteries.
- **Line of Sight:** Make sure there are no obstructions between the remote control and the TV's infrared

receiver.

- **Distance:** Ensure you are within the effective operating range of the TV's infrared receiver.
- **TV Power:** Confirm that the TV is powered on and not in standby mode.

5.2. Specific Buttons Not Working

- **Clean Contacts:** If certain buttons are unresponsive, there might be dirt or debris under the buttons. Gently clean around the buttons with a dry cotton swab. Do not attempt to disassemble the remote.

6. Specifications

Feature	Detail
Model Number	NARF2_00349
Compatible Devices	LG HD LCD Televisions (specific models listed in Section 1.1)
Power Supply	2 x 1.5V AA Alkaline Batteries (not included)
Product Dimensions	Approximately 5 x 1 x 1 inches (12.7 x 2.54 x 2.54 cm)
Item Weight	Approximately 2 ounces (56.7 grams)
Color	Black
Special Feature	Ergonomic design

7. Warranty and Support

This product is a replacement remote control. For specific warranty information, please refer to the terms provided by the retailer or contact the manufacturer, ZdalaMit, directly. User manuals are not typically included with this product, as stated in the product description.
For further assistance or inquiries, please contact the seller or manufacturer through the platform where the product was purchased.

© 2025 ZdalaMit. All rights reserved.
This manual is for informational purposes only.