ZdalaMit AKB73275675

ZdalaMit AKB73275675 Replacement Remote Control User Manual

For LG TV Models: 42CS578, 42CS570, 47CS570, 42CS570UD, 47CS570UD, 42CS570-UD, 47CS570-UD, 50LS4000, 50LS4000UA, 50LS4000-UA

Setup Operation Maintenance Troubleshooting Specifications Support

Introduction

This manual provides instructions for the ZdalaMit AKB73275675 replacement remote control, designed for use with various LG TV models. This remote control offers direct functionality without the need for programming or pairing. Simply install batteries to begin use.

Setup

Battery Installation

The remote control requires two (2) AAA alkaline batteries (not included). Follow these steps to install them:

1. Locate the battery compartment cover on the back of the remote control.
2. Press down on the tab and slide the cover downwards to open it.
3. Insert two new 1.5V AAA alkaline batteries, ensuring the positive (+) and negative (-) terminals match the diagrams inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.



Image: Back view of the remote control with the battery cover removed, illustrating the correct orientation for AAA battery insertion.

Initial Use

Once batteries are installed, the remote control is ready for immediate use with compatible LG TV models. No programming or pairing is required.

Operation

This remote control provides standard functions for your LG TV. Below is a general overview of common buttons and their functions.



Image: Front view of the remote control, highlighting the layout of buttons for various functions.

Key Functions

- **Power (●)**: Turns the TV on or off.
- **Input**: Selects the video input source (e.g., HDMI 1, AV).
- **Number Buttons (0-9)**: Directly select channels.
- **VOL +/-**: Adjusts the volume level.

- **CH ▲/▼**: Changes channels up or down.
- **MUTE**: Mutes or unmutes the TV audio.
- **MENU**: Accesses the TV's main menu.
- **Q.MENU**: Accesses the Quick Menu for common settings.
- **Navigation Buttons (Up, Down, Left, Right, ENTER)**: Navigate through menus and confirm selections.
- **BACK**: Returns to the previous screen or menu.
- **EXIT**: Exits the current menu or function.
- **Color Buttons (Red, Green, Yellow, Blue)**: Provide special functions depending on the TV mode or application.
- **Playback Controls (Play, Pause, Stop, Fast Forward, Rewind)**: Control media playback.

Maintenance

Cleaning

To clean the remote control, gently wipe it with a soft, dry cloth. Do not use liquid cleaners, sprays, or abrasive materials, as these can damage the remote's surface or internal components.

Battery Replacement

Replace batteries when the remote control becomes unresponsive or its range decreases. Always replace both batteries at the same time with new 1.5V AAA alkaline batteries. Do not mix old and new batteries or different types of batteries.

Troubleshooting

If you experience issues with your remote control, refer to the following common solutions:

Problem	Solution
Remote control is not working.	• Ensure batteries are installed correctly with the correct polarity. • Replace old batteries with new 1.5V AAA alkaline batteries. • Check for any obstructions between the remote control and the TV's infrared sensor. • Point the remote directly at the TV's sensor.
Buttons are unresponsive or intermittent.	• Replace batteries, even if they seem to have some power left. • Clean the remote control surface, especially around the buttons, to remove any dirt or debris that might be interfering. • Ensure the remote is within effective range of the TV.
Remote control does not control all TV functions.	• Verify that your TV model is listed as compatible with the AKB73275675 remote control. • Some advanced or smart TV functions may require the original manufacturer's remote or a specific smart remote. This remote is designed for basic and common TV functions.

Specifications

- **Model Number:** AKB73275675
- **Brand:** ZdalaMit
- **Compatible Devices:** LG Televisions (Specific models listed in header)
- **Power Supply:** 2 x 1.5V AAA Alkaline Batteries (not included)

- **Dimensions:** Approximately 6 x 2 x 0.5 inches (15.24 x 5.08 x 1.27 cm)
- **Item Weight:** Approximately 1.41 ounces (40 grams)
- **Color:** Black
- **Special Feature:** Ergonomic design

Support and Contact Information

For any questions or further assistance regarding your ZdalaMit AKB73275675 replacement remote control, please contact the seller or manufacturer directly through your purchase platform. Please have your product model number ready when contacting support.
Note: This product does not include a separate user manual or batteries in its packaging.

© 2024 ZdalaMit. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question