ZdalaMit BN59-00852A

ZdalaMit BN59-00852A Replacement Remote Control User Manual

Model: BN59-00852A

Introduction

This manual provides instructions for the ZdalaMit BN59-00852A replacement remote control. This remote is designed to function as a direct replacement for various Samsung LCD and Plasma TV models, requiring no programming or pairing.

Package Contents

- 1x ZdalaMit BN59-00852A Replacement Remote Control

Note: AAA batteries and a user manual are not included in the package. This document serves as the user manual.

Setup

Battery Installation

The remote control requires two (2) 1.5V AAA alkaline batteries for operation.

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards and remove it.
3. Insert two new AAA alkaline batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover by sliding it upwards until it clicks into place.

Once batteries are installed, the remote is ready for immediate use with compatible Samsung TVs; no programming or pairing is required.



Image: Rear view of the remote control, illustrating the battery compartment and proper battery orientation.

Basic Operation

This replacement remote control provides full functionality for your compatible Samsung LCD or Plasma TV. Simply point the remote towards your television and press the desired button.



Image: Front view of the remote control, displaying the layout of all functional buttons.

Key Functions:

- **POWER (TV)**: Turns the television on or off.
- **Number Buttons (0-9)**: Directly select channels.
- **VOL (+/-)**: Adjusts the volume level.
- **CH (up/down)**: Changes channels sequentially.
- **SOURCE**: Selects input sources (e.g., HDMI, AV).
- **MENU**: Accesses the TV's main menu.
- **Directional Pad (Up/Down/Left/Right) & ENTER**: Navigates through menus and confirms

selections.

- **EXIT**: Exits the current menu or function.
- **INFO**: Displays information about the current program or input.
- **TOOLS**: Accesses quick settings or contextual options.
- **CH LIST**: Displays the channel list.
- **FAV.CH**: Accesses favorite channels.
- **RETURN**: Returns to the previous screen or channel.
- **MEDIA.P**: Accesses media playback functions.
- **P.MODE**: Changes picture modes.
- **SRS**: Activates SRS sound enhancement.
- **MTS**: Selects Multi-channel Television Sound options.
- **P.SIZE**: Adjusts picture size/aspect ratio.
- **CC**: Activates or deactivates Closed Captions.
- **Playback Controls (Rewind, Play, Fast Forward, Stop, Pause)**: Controls media playback.

Compatibility

The ZdalaMit BN59-00852A remote control is compatible with a wide range of Samsung LCD and Plasma TV models, including but not limited to:
LN32B550, LN37B550, LN40B550, LN46B550, LN52B550, LN32B550K1F, LN37B550K1F, LN46B550K1FXZA, LN52B550K1FXZA, LN37B550K1FXZA, LN40B550K1FXZA, LN32B550K1FXZA, LN46B550K1FUZA, LN32B550K1FUZA, LN40B550K1FUZA, LN32B640, LN40B610, LN46B610, LN52B610, LN32B640R3F, LN52B630N1FXZA, LN40B610A5FUZA, LN52B610A5FXZA, LN32B640R3FXZA, LN46B610A5FXZA, LN40B610A5FXZA, LN46B610A5FUZA, LN40B550K1F, LN52B550K1F, LN40B610A5F, LN40B640R3F, LN46B610A5F, LN52B610A5F, LN46B550K1F, PN50B50T5F, PN58B50T5F, PN6B550T2F, PN6B590T5F, PNB550TF, PNB590T5F, CLP 550, PN50B560, PN58B560, PN63B550, PN63B590, PN50B550T2F, PN50B560T5F, PN58B550T2F, PN63B550T2F, PN63B550T2FXZA, BN68-02221B-00, PN58B550, PN63B590T5F, PN58B560T5F, PN50B550, PN50B560T5FXZA, PN63B590T5FXZA, PN58B560T5FXZA, PN50B550T2FXZA, PN58B550T2FXZA, PN58B560T5, PN58B550T2.
If your Samsung TV model is not listed, please verify its compatibility with the original remote control model BN59-00852A.

Troubleshooting

- **Remote not responding:**
  - Ensure new AAA alkaline batteries are correctly installed with the proper polarity (+/-).
  - Check if the batteries are depleted and replace them if necessary.
  - Ensure there are no obstructions between the remote control and the TV's infrared sensor.
  - Point the remote directly at the TV's sensor.
  - Test the remote from a closer distance to the TV.
- **Intermittent response:**
  - Replace batteries with new ones.
  - Clean the remote's infrared emitter and the TV's sensor with a soft, dry cloth.

Specifications

Model Number	BN59-00852A
Brand	ZdalaMit
Compatible Devices	Samsung LCD and Plasma Televisions
Power Supply	2 x 1.5V AAA Alkaline Batteries (not included)
Dimensions (L x W x H)	7 x 2 x 1 inches (approximately)
Item Weight	0.01 ounces (without batteries)
Color	Black
Special Feature	Ergonomic design

Care and Maintenance

- Keep the remote control dry. Avoid exposure to liquids or high humidity.
- Do not expose the remote to extreme temperatures.
- Clean the remote with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- If the remote will not be used for an extended period, remove the batteries to prevent leakage.
- Handle the remote with care; avoid dropping it or subjecting it to strong impacts.

Support

For any questions or assistance regarding your ZdalaMit BN59-00852A replacement remote control, please contact the seller or manufacturer directly.
Contact information for the seller (Delighted inc) can typically be found on your purchase receipt or order details page.