Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

BABY born 824771

BABY born City RC Scooter Instruction Manual

Model: 824771

1. Product Overview

The BABY born City RC Scooter is an exciting accessory designed for BABY born dolls up to 43 cm. It features remote control functionality, allowing the scooter to move forward and backward, and includes realistic light effects such as flashing turn signals. This product is intended to enhance imaginative play and provide interactive fun.



Figure 1: The BABY born City RC Scooter, remote control, and included sticker sheets.

2. Safety Information

WARNING!

- Not suitable for children under 36 months.
- Contains small parts. Choking hazard.

3. What's in the Box

Please check the contents of the package to ensure all items are present:

- 1 x BABY born City RC Scooter
- 1 x Remote Control
- 2 x Sticker Sheets for decoration

4. Setup

4.1 Battery Installation

The BABY born City RC Scooter and its remote control require batteries for operation. Batteries are not included.

1. Locate the battery compartments on both the scooter and the remote control.
2. Using a screwdriver (not included), open the battery compartment covers.
3. Insert the required batteries, ensuring correct polarity (+/-) as indicated inside the compartment. We recommend using brand-name alkaline manganese batteries (alkaline) for optimal performance, as they offer higher capacity, lower self-discharge, and better leak resistance compared to zinc-carbon batteries.
4. Close the battery compartment covers securely.

Note: *Do not use rechargeable batteries if their voltage is lower than 1.5 volts, as this can affect performance. Always check the batteries in both the remote control and the scooter if you experience issues.*



Figure 2: The scooter and remote control as packaged, indicating the need for initial setup and battery installation.

5. Operating Instructions

Once batteries are installed, you can begin operating your BABY born City RC Scooter.

1. Place your BABY born doll (up to 43 cm) securely on the scooter's seat.
2. Turn on the main power switch located on the scooter.
3. Use the 4-way remote control to steer the scooter:
    - Press the forward button to move the scooter straight ahead.

- Press the backward button to move the scooter in reverse.
- Use the left and right buttons to turn the scooter. The corresponding turn signals will flash during turns.

4. The scooter is designed to operate best on smooth, flat surfaces.

Tip: *If the scooter becomes unresponsive after a period of inactivity, turn the main power switch off and then on again to reactivate it.*



Figure 3: A BABY born doll positioned on the City RC Scooter, ready for play.



Figure 4: A detailed view of the scooter's front, highlighting the functional headlights and turn signals.

6. Maintenance

To ensure the longevity and proper functioning of your BABY born City RC Scooter, follow these maintenance guidelines:

- **Cleaning:** Wipe the scooter and remote control with a soft, damp cloth. Do not immerse in water.
- **Battery Care:** Always remove batteries from both the scooter and the remote control if the product will not be used for an extended period. This prevents potential battery leakage and damage.
- **Storage:** Store the product in a cool, dry place away from direct sunlight and extreme temperatures.
- **Inspection:** Periodically check for any loose screws, damaged parts, or frayed wires. Do not use the product if any damage is found.



Figure 5: Rear view of the scooter, illustrating its design for easy cleaning and inspection.

7. Troubleshooting

If you encounter issues with your BABY born City RC Scooter, refer to the following common problems and solutions:

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Scooter does not move or lights do not work.	Batteries are low, incorrectly installed, or missing.	Replace with fresh alkaline batteries. Ensure correct polarity. Check batteries in both scooter and remote control.
Scooter stops responding after a period of use.	Automatic power-saving mode activated.	Turn the main power switch off and then on again to reactivate the scooter.
Scooter struggles to move or gets stuck.	Operating on unsuitable surfaces (e.g., thick carpet, uneven terrain).	Ensure the scooter is used on smooth, flat surfaces. Avoid obstacles like carpet edges.
Remote control not pairing with scooter.	Interference or battery issue.	Ensure both devices have fresh batteries. Try moving closer to the scooter. Turn both off and on again.



Figure 6: A child interacting with the scooter and remote, demonstrating typical usage scenarios where troubleshooting might be needed.

8. Specifications

Feature	Detail
Product Dimensions (L x W x H)	20.3 x 40 x 35 cm
Product Weight	1.62 kilograms
Manufacturer Recommended Age	3 years and up
Model Number	824771
Main Material	Plastic
Battery Type Required	Alkaline (not included)
Remote Control Included	Yes
Special Features	Remote control and light effects

9. Warranty and Support

For information regarding warranty, returns, or technical support, please refer to the product packaging or contact the retailer or manufacturer directly. Keep your proof of purchase for any warranty claims.

© 2024 BABY born. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07BWSC4YT

More documents and user manuals: **https://manuals.plus/**