Paw Patrol 6043988

PAW Patrol Ultimate Rescue Fire Truck Instruction Manual

Model: 6043988 | Brand: Paw Patrol

1. Introduction

Welcome to the instruction manual for your PAW Patrol Ultimate Rescue Fire Truck. This guide provides essential information for the safe assembly, operation, and maintenance of your new toy. Please read all instructions carefully before use to ensure a fun and safe play experience.

Safety Information

WARNING: CHOKING HAZARD – Small parts. Not suitable for children under 3 years.
Adult supervision is recommended during play, especially when using projectile launchers and the extendable ladder. Keep all packaging materials away from children.

2. Package Contents

Please verify that all the following items are included in your package:

- 1 Ultimate Rescue Fire Truck
- 1 Mini Fire Cart
- 1 Marshall Figure
- 4 Projectile Launchers (Water Cannons)
- 1 Extendable Ladder (integrated)
- 1 Sticker Sheet
- 1 Instruction Sheet (this manual)



Image: The complete PAW Patrol Ultimate Rescue Fire Truck set, including the main truck, Marshall figure, mini fire cart, and water projectiles.

3. Setup

Battery Installation

The Ultimate Rescue Fire Truck requires 2 AAA batteries (included) for lights and sounds functionality.

1. Locate the battery compartment on the underside of the fire truck.
2. Using a Phillips head screwdriver (not included), carefully unscrew the battery compartment cover.
3. Insert 2 new AAA batteries, ensuring correct polarity (+ and - symbols match the markings inside the compartment).
4. Replace the cover and secure it with the screw. Do not overtighten.



Image: A child interacting with the fire truck, demonstrating its size and play features after setup.

Initial Assembly

No complex assembly is required. The main components are pre-assembled. You may apply the included stickers to the fire truck as desired, following the instructions on the sticker sheet for placement.

4. Operating Instructions

Extending the Ladder

The fire truck features an extendable ladder that can reach up to 2 feet (60 cm) tall. To extend, gently lift and pull the ladder upwards from its base until it locks into position. To retract, gently push it back down.



Image: The fire truck with its ladder fully extended, showcasing its height and functionality.

Activating Lights and Sounds

Press the button located on the top of the cab to activate the flashing lights and realistic fire truck sounds. Press again to turn off.

Launching Water Cannons

The truck is equipped with water cannon launchers at both the front and back. Four projectile launchers (water cannons) are included.

1. Load a projectile into the designated slot on the launcher.
2. To launch, either turn the yellow knob or press the button located near the launcher, depending on the specific cannon.



Image: Marshall figure positioned at a water cannon launcher, demonstrating the firing mechanism.

Deploying the Mini Fire Cart

The Mini Fire Cart is stored within a compartment of the main fire truck. Open the compartment door and roll out the Mini Fire Cart. Marshall (figure included) can be placed inside the Mini Fire Cart for separate play or smaller rescue missions.



Image: Marshall figure seated in the mini fire cart, which is separate from the main fire truck, ready for action.

Using the Working Claw Arm

A retractable working claw arm is located on the side of the truck. Extend the arm by pulling it out, and manipulate the claw to pick up small objects or figures, simulating rescue operations.



Image: A hand demonstrating the use of the working claw arm attached to the side of the fire truck.

5. Maintenance

Cleaning

To clean the fire truck and its accessories, wipe them with a damp cloth. Do not immerse the toy in water, as this may damage electronic components. Avoid using harsh chemicals or abrasive cleaners.

Storage

When not in use, store the fire truck and all its components in a cool, dry place away from direct sunlight. Ensure all small parts are kept together to prevent loss.

6. Troubleshooting

No Lights or Sounds

- Check that the batteries are inserted with correct polarity (+/-).
- Replace the batteries with new ones, even if they are included, as they may be for demonstration purposes.
- Ensure the battery compartment cover is securely closed.

Water Cannons Not Launching

- Ensure the projectiles are correctly loaded into the launcher mechanism.
- Verify that the launching mechanism (knob or button) is fully engaged when operated.

7. Specifications

Product Details

Feature	Detail
Model Number	6043988
Dimensions (L x W x H)	64.77 x 18.03 x 35.31 cm
Weight	3 kg
Material	Plastic
Batteries Required	2 AAA (included)
Recommended Age	36 months - 3 years (Manufacturer) / 3-9 years (Description)
Color	Multicolor

8. Warranty and Support

Spin Master Care Commitment

This product is covered by the Spin Master Care Commitment. If you experience an issue with a Spin Master product purchased from an authorized seller, Spin Master is committed to resolving it.
The Care Commitment is limited to the original end-user purchaser. You may be required to provide proof of purchase and/or a picture of your product to Spin Master to verify eligibility. Spin Master reserves the right to verify information, require valid proof of purchase, and to deny requests at its discretion.
For further assistance, product inquiries, or to learn more about the Spin Master Care Commitment, please visit the official Spin Master website or contact their customer support directly.

Visit Spin Master Official Website

© 2023 Paw Patrol. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question